

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [XBrand](#) /

› [XBrand 27-inch LED Mist Indoor Floor Fountain \(Model FM102BL\) Instruction Manual](#)

XBrand FM102BL

XBrand 27-inch LED Mist Indoor Floor Fountain (Model FM102BL) Instruction Manual

Model: FM102BL | Brand: XBrand

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your XBrand 27-inch LED Mist Indoor Floor Fountain. This freestanding water feature is designed to create a relaxing indoor atmosphere with adjustable mist and 12 color-changing LED lights, functioning as an indoor water fountain, mist fogger, humidifier, or ambient decor piece.

IMPORTANT SAFETY INFORMATION

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Use only with clean tap water.
- Ensure the fogger unit sensor is fully submerged in water for proper operation.
- For maximum fog, the sensor should have approximately 1/2 inch of water over it.
- Do not operate the fogger unit without sufficient water, as this can cause damage.
- Regularly clean the fountain to prevent mineral buildup and ensure optimal performance.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Glass Bowl
- Metal Stand (4-leg curved stand)
- Plastic Tower Stand
- Fogger Unit with Inline Control (ON/OFF switch, mist adjustment, LED light control)
- AC Adapter
- Splash Guard (small glass piece)

- Screwdriver (for stand assembly)

SETUP INSTRUCTIONS

1. Assemble the Metal Stand:

Attach the four curved legs to the circular base using the provided screws and screwdriver. Ensure all connections are secure for stability.

Your browser does not support the video tag.

This video demonstrates the step-by-step assembly of the metal stand, showing how to attach the legs securely.

2. Place the Glass Bowl:

Carefully place the large glass bowl onto the assembled metal stand, ensuring it is centered and stable.



Image showing the main fountain unit with the glass bowl resting on the metal stand.

3. Install the Fogger Unit:

Connect the fogger unit to the AC adapter. Place the fogger unit into the central well of the glass bowl, ensuring its sensor is positioned to be fully submerged in water. Then, place the plastic tower stand over the fogger unit, ensuring it is stable. Finally, position the small glass splash guard on top of the plastic tower stand, directly above the fogger unit.



This image highlights the fogger unit and plastic tower stand correctly placed within the glass bowl.

4. Add Water:

Fill the glass bowl with clean tap water until the fogger unit's sensor is fully submerged, with approximately 1/2 inch of water covering it for optimal mist production.



Image illustrating the process of adding water to the fountain, ensuring the fogger unit is adequately submerged.

5. Connect Power:

Plug the AC adapter into a standard electrical outlet.

OPERATING INSTRUCTIONS

1. Power On/Off and Mist Control:

Use the inline control switch on the power cord:

- Press once for low mist setting.
- Press twice for high mist setting.
- Press a third time to shut off the mister.



This image highlights the inline control switch used to manage mist output and LED lights.

2. LED Light Control:

Use the separate button on the inline control:

- Press once for multicolor changing LED lights.
- Subsequent presses (2-8 clicks) will activate constant colors.

- o Press a ninth time to shut off the LED lights.



Image demonstrating the fountain's 12 color-changing LED lights in action.

3. Aromatherapy (Optional):

Add a few drops of your favorite essential oil directly into the water in the glass bowl. The mist will diffuse the aroma.

MAINTENANCE

- **Water Level:** Regularly check the water level and refill as needed to ensure the fogger unit remains submerged. Operating without sufficient water can damage the fogger.
- **Cleaning:** Clean the glass bowl and fogger unit frequently (at least once a week) to prevent mineral buildup and maintain optimal mist production. Use a soft cloth and mild soap.
- **Fogger Unit Longevity:** The fogger unit is a consumable part. Its lifespan can be extended with proper cleaning and maintenance. Replacement fogger units may be purchased separately.
- If using essential oils, clean the bowl more frequently to prevent residue buildup.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist/Lights	Power connection loose or unit not plugged in.	Ensure AC adapter is securely plugged into the fountain and outlet.
No Mist/Lights	Insufficient water level.	Add tap water until the fogger unit sensor is fully submerged (approx. 1/2 inch over sensor).
No Mist/Lights	Fogger unit or LED lights are off via inline control.	Press the appropriate buttons on the inline control to activate mist and lights.
Weak Mist Production	Mineral buildup on fogger unit.	Clean the fogger unit thoroughly.
Weak Mist Production	Water level too high or too low.	Adjust water level to approximately 1/2 inch above the fogger unit sensor.

Problem	Possible Cause	Solution
Water Leaks	Improper assembly of the glass bowl on the stand.	Ensure the glass bowl is seated correctly and stably on the metal stand.
Water Leaks	Cracked or damaged glass bowl.	Inspect the glass bowl for any damage. Replace if necessary.
Fountain is Wobbly	Stand not assembled correctly or placed on an uneven surface.	Ensure all screws on the stand are tightened and the fountain is on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Brand	XBrand
Model Name	Floor Mist Fountain w/ Inline Control Glass Metal
Item Model Number	FM102BL
Product Dimensions	16"L x 16"W x 27"H
Item Weight	8 Pounds
Material	Glass, Metal, Plastic
Color	Blue
Power Source	Corded Electric
Special Feature	Lighted
Light Source Type	LED
Coverage	Medium to Large Room
Shape	Oval
Auto Shutoff	No
Included Components	Splash Guard, Bowl, Stands, Plastic tower stand, Fogger Unit, AC Adaptor
Assembly Required	No
Batteries Required	No
Recommended Uses	Home, Office
GTIN/UPC	608641904710

WARRANTY AND SUPPORT

This product comes with a one-year limited warranty on the fogger unit. For any questions or assistance regarding

your mist fountain, please contact XBrand customer support.

Please refer to the product packaging or the XBrand website for specific contact information and warranty claim procedures.