

[manuals.plus](#) /

› [Newpoint](#) /

› [Newpoint USB 4-port Hub \(Model UH140\) Instruction Manual](#)

Newpoint UH140

Newpoint USB 4-port Hub Instruction Manual

MODEL: UH140

1. Introduction

Thank you for choosing the Newpoint USB 4-port Hub. This device expands a single USB port into four, allowing you to connect multiple USB peripherals to your computer simultaneously. It is designed for ease of use and broad compatibility.



This image displays the Newpoint USB 4-port Hub within its original retail packaging. The hub itself is white with four USB ports visible, along with indicator lights. The packaging highlights features such as 'Plug and Play', 'Hot Swappable', and compatibility with Windows 98 and Mac OS 8.5. It also mentions an included 'A to A' Extension Cable and lists compatible devices like scanners, digital cameras, and printers.

2. Package Contents

Please verify that all items are present in your package:

- Newpoint USB 4-port Hub (Model UH140)
- AC Power Adapter
- Device Cable (USB A to B)
- USB "A" to "A" Extension Cable

3. Features

- **4-Port USB Expansion:** Connect up to four USB devices simultaneously.
- **Plug and Play:** Automatic detection and installation of peripherals.
- **Hot Swappable:** Add or remove devices without rebooting your computer.
- **Broad Compatibility:** Supports Windows 98 and Mac OS 8.5 and later.
- **Versatile Connectivity:** Ideal for scanners, digital cameras, gaming devices, printers, removable media drives, external hard drives, external CD-R/RW devices, mice, and keyboards.

4. System Requirements

- Available USB port on your computer.
- Operating System: Windows 98 or later, Mac OS 8.5 or later.

5. Setup

1. **Connect Power Adapter:** Plug the AC power adapter into the hub's power input port and then into a standard electrical outlet.
2. **Connect to Computer:** Use the provided device cable (USB A to B) to connect the hub's upstream USB port to an available USB port on your computer. If additional length is needed, use the included USB "A" to "A" extension cable.
3. **Install Drivers (if necessary):** For most modern operating systems, the hub will be automatically detected and drivers installed. If prompted, follow the on-screen instructions.
4. **Connect Peripherals:** Plug your USB devices (e.g., mouse, keyboard, printer) into the available downstream USB ports on the hub.

The hub is now ready for use. Indicator lights on the hub will illuminate to show active connections.

6. Operating Instructions

Once connected, the Newpoint USB 4-port Hub operates transparently. Simply plug your USB devices into any of the four available ports. The hub supports hot-swapping, meaning you can connect or disconnect devices without needing to restart your computer.

Each port provides standard USB power for connected devices. For devices requiring significant power, ensure the AC power adapter is connected to the hub.

7. Maintenance

- Keep the hub in a dry environment, away from moisture and extreme temperatures.
- Clean the hub with a soft, dry cloth. Do not use liquid cleaners or solvents.
- Avoid dropping or subjecting the hub to strong impacts.

8. Troubleshooting

Problem	Solution
---------	----------

Problem	Solution
Device not recognized.	<ul style="list-style-type: none"> ◦ Ensure the hub's AC power adapter is securely connected. ◦ Try connecting the device to a different port on the hub. ◦ Connect the device directly to your computer's USB port to verify device functionality. ◦ Restart your computer.
Hub not powered on (no indicator lights).	<ul style="list-style-type: none"> ◦ Verify the AC power adapter is correctly plugged into both the hub and a working electrical outlet. ◦ Ensure the USB cable connecting the hub to the computer is secure.
Slow data transfer speeds.	<ul style="list-style-type: none"> ◦ Ensure you are using USB 1.1 compatible devices and ports. This hub is designed for USB 1.1 speeds. ◦ Disconnect other high-bandwidth devices from the hub if possible.

9. Specifications

Feature	Detail
Model Number	UH140
Brand	Newpoint
Total USB Ports	4
Hardware Interface	USB (Universal Serial Bus)
Compatible Devices	Digital Cameras, Keyboards, Printers, Scanners, Gaming Devices, Removable Media Drives, External Hard Drives, External CD-R/RW Devices, Mice
Color	White
Item Weight	2.1 pounds (approximately 0.95 kg)
Package Dimensions	10.2 x 7.6 x 3.1 inches (approximately 25.9 x 19.3 x 7.9 cm)
Date First Available	May 6, 2005

10. Warranty Information

Specific warranty details are not provided in the available product information. Please refer to the product packaging or contact the manufacturer directly for warranty terms and conditions.

11. Support

For further assistance or technical support, please refer to the contact information provided on the product packaging or the official Newpoint website. As specific support contact details are not available in this

document, please consult the product's original documentation.

© 2023 Newpoint. All rights reserved.