

[Manuals.plus](#) /

› [Wilton](#) /

› Wilton Care Bears Cake Pan Model 2105-2424 Instruction Manual

Wilton 2105-2424

Wilton Care Bears Cake Pan Instruction Manual

Model: 2105-2424

INTRODUCTION

This manual provides essential instructions for the proper use, care, and maintenance of your Wilton Care Bears Cake Pan, Model 2105-2424. Designed for creating themed cakes, this aluminum pan is 13 x 9.5 x 2 inches deep and includes patterns for decorating popular Care Bear characters. Please read all instructions carefully before first use.

SETUP

- Initial Cleaning:** Before first use, wash the cake pan thoroughly with warm, soapy water. Rinse completely and dry immediately to prevent water spots.
- Preparation for Baking:** For best results and easy cake release, grease the interior of the pan generously with solid vegetable shortening, then dust lightly with flour. Tap out any excess flour. Alternatively, use a baking spray with flour.

OPERATING INSTRUCTIONS

Baking Your Cake

- Prepare your favorite cake batter according to recipe instructions. This pan is designed for a single cake mix.
- Pour the prepared batter into the greased and floured pan, filling it approximately two-thirds full.
- Bake according to your recipe's temperature and time guidelines. Baking times may vary slightly due to the pan's unique shape and material. Monitor for doneness by inserting a toothpick into the center; if it comes out clean, the cake is ready.
- Once baked, remove the pan from the oven and let it cool on a wire rack for 10-15 minutes before inverting the cake onto the rack to cool completely.

Decorating Your Care Bears Cake

The pan includes instructions and patterns for decorating four popular Care Bear characters. These patterns serve as a guide for applying frosting and details to achieve the desired design.



Image: The Wilton Care Bears Cake Pan, showing its distinctive shape for baking themed cakes.



Image: An example of a finished cake decorated using the Wilton Care Bears Cake Pan, showcasing a green Care Bear design.

MAINTENANCE AND CARE

- **Cleaning:** This cake pan is dishwasher safe, but hand washing is recommended to prolong its lifespan and maintain its finish. Use warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners or scouring pads that can scratch the aluminum surface.
- **Drying:** Dry the pan thoroughly immediately after washing to prevent water spots and potential mineral buildup.
- **Storage:** Store the pan in a dry place. Stacking pans without protection may lead to scratches; consider placing a paper towel or cloth between stacked pans.

- **Oven Safety:** The pan is oven safe. Do not use on stovetops or under broiler.

TROUBLESHOOTING

- **Cake Sticking to Pan:** Ensure the pan is thoroughly greased and floured before adding batter. For intricate designs, ensure all crevices are coated. Allow the cake to cool for the recommended time before attempting to invert.
- **Uneven Baking:** Oven temperature fluctuations or uneven batter distribution can cause this. Ensure your oven is preheated correctly and consider rotating the pan halfway through baking.
- **Discoloration of Pan:** Aluminum pans can sometimes discolor with certain ingredients or detergents. This is typically cosmetic and does not affect baking performance. To restore shine, a solution of cream of tartar and water can be used.

SPECIFICATIONS

Feature	Detail
Brand	Wilton
Model Number	2105-2424
Material	Aluminum
Product Dimensions	1.85 x 10.15 x 14.25 inches
Capacity	Designed for one cake mix (approximately 13 x 9.5 x 2 inches deep)
Item Weight	3.2 ounces
Care Instructions	Hand Wash (Dishwasher Safe)
Oven Safe	Yes
Special Feature	Includes decorating patterns for Care Bear characters

WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the official Wilton website or contact Wilton customer service directly. Details are typically available on the manufacturer's packaging or their official online resources. Visit the official Wilton website for additional resources:www.wilton.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0009Q93NK>

More documents and user manuals: **<https://manuals.plus/>**