

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Selkirk](#) /

› [Selkirk 8T-SC 8-inch Stainless Steel Storm Collar Instruction Manual](#)

Selkirk 8T-SC

Selkirk 8T-SC 8-inch Stainless Steel Storm Collar Instruction Manual

1. INTRODUCTION

This manual provides essential instructions for the proper installation, maintenance, and care of your Selkirk 8T-SC 8-inch Stainless Steel Storm Collar. Adhering to these guidelines ensures optimal performance and longevity of the product. Please read this manual thoroughly before beginning installation.

2. PRODUCT OVERVIEW

The Selkirk 8T-SC is an 8-inch diameter storm collar designed for use with chimney pipes. Its primary function is to prevent water and moisture from entering the chimney system where the pipe penetrates the roof flashing. Constructed from stainless steel, it offers durability and resistance to environmental elements.

3. SAFETY INFORMATION

Always prioritize safety during installation. Wear appropriate personal protective equipment, including gloves and eye protection. Ensure stable footing when working on roofs or at heights. If you are unsure about any step, consult a qualified professional. Improper installation can lead to property damage or personal injury.

4. PACKAGE CONTENTS

- One (1) Selkirk 8T-SC 8-inch Stainless Steel Storm Collar

5. SETUP AND INSTALLATION

Follow these steps for proper installation of the storm collar:

1. **Positioning:** Slide the storm collar down the chimney pipe until it rests firmly on top of the roof flashing. Ensure it is level and centered around the pipe.
2. **Engaging Tabs:** The storm collar features tabs designed to secure it around the pipe. Carefully engage these tabs to create a snug fit.

3. **Initial Sealing:** Apply a suitable high-temperature, weather-resistant sealant around the entire circumference where the storm collar meets the chimney pipe. This creates the primary weather seal.
4. **Additional Sealing:** After engaging the tabs and sealing the collar to the pipe, place additional sealant in any slot or tab openings. This critical step prevents moisture infiltration through these potential entry points.



Image: The Selkirk 8T-SC 8-inch Stainless Steel Storm Collar. A label on the collar provides a key instruction: "AFTER ENGAGING TABS AND SEALING COLLAR TO PIPE PLACE ADDITIONAL SEALANT IN SLOT/TAB OPENINGS TO PREVENT MOISTURE INFILTRATION."

6. OPERATING INSTRUCTIONS

The Selkirk 8T-SC Storm Collar is a passive component of your chimney system. Once correctly installed and sealed, it requires no active operation. Its function is to continuously protect against water intrusion.

7. MAINTENANCE

Regular inspection and minimal maintenance will ensure the storm collar's effectiveness:

- **Annual Inspection:** Annually, or after severe weather, inspect the storm collar for any signs of damage, corrosion, or sealant degradation.
- **Sealant Check:** Verify that the sealant around the pipe and in the tab openings remains intact and free of cracks. Reapply sealant as necessary to maintain a watertight seal.
- **Cleaning:** Remove any debris, such as leaves or dirt, that may accumulate around the collar.

8. TROUBLESHOOTING

Most issues related to a storm collar stem from improper installation or degraded sealant.

- **Water Leakage:** If water is observed entering the chimney system at the roof penetration point, the most common cause is a compromised seal. Inspect the sealant around the storm collar and reapply as needed. Ensure all tab openings are properly sealed.
- **Loose Collar:** If the collar appears loose, ensure the tabs are fully engaged and consider adding additional sealant to secure it more firmly.

9. SPECIFICATIONS

Brand	Selkirk
Model Number	8T-SC (Selkirk - 208810)
Material	Stainless Steel
Color	Galvanized Steel finish
Nominal Diameter	8 inches
Item Weight	8 ounces (0.5 lbs)
Product Dimensions	12.25 x 2.25 x 12.25 inches
Manufacturer	Jensen (Home Improvement)

10. WARRANTY AND SUPPORT

This Selkirk product is covered by a manufacturer's limited warranty. For specific warranty terms, conditions, and duration, please refer to the official Selkirk website or contact their customer support directly. Keep your purchase receipt as proof of purchase.

For technical assistance or further inquiries, please visit the [Selkirk Corporation website](#) or contact their customer service department.