

- Manuals.plus /
- > [Truck-Lite](#) /
- > Truck-Lite 60700 Grommet User Manual

Truck-Lite 60700

Truck-Lite 60700 Grommet User Manual

Brand: **Truck-Lite** | Model: **60700**

1. PRODUCT OVERVIEW

The Truck-Lite 60700 is a durable lamp grommet designed for automotive lighting applications. It is specifically engineered to provide a secure and vibration-resistant mounting solution for various lamps, particularly those in the 60 series. This component ensures that the lamp remains firmly in place, protecting it from environmental factors and operational stresses.



An image showing the black, oval-shaped Truck-Lite 60700 lamp grommet. The grommet is designed to securely hold a lamp in place within a vehicle's body panel.

2. WHAT'S IN THE BOX

Each package of the Truck-Lite 60700 Grommet typically contains the following:

- Truck-Lite 60700 Grommet (Quantity as ordered)

3. SPECIFICATIONS

Manufacturer	Truck-Lite
Brand	Truck-Lite
Model Name	Lamp Grommet
Item Model Number	60700
Item Weight	3.2 ounces
Product Dimensions	7.25 x 3 x 1 inches
Fit Type	Vehicle Specific
Exterior Finish	Painted (referring to the lamp it holds, the grommet itself is rubber)
National Stock Number	5325-01-163-6558
Date First Available	June 16, 2005

4. INSTALLATION INSTRUCTIONS

The Truck-Lite 60700 Grommet is designed for straightforward installation to secure compatible lamps. Follow these general steps for proper fitment:

1. **Prepare the Mounting Surface:** Ensure the mounting hole in the vehicle's body panel is clean, dry, and free from debris or burrs. The hole should be appropriately sized for the grommet to ensure a snug fit.
2. **Insert the Grommet:** Carefully insert the grommet into the prepared mounting hole. Apply even pressure around the edges until the grommet is fully seated and its flange rests flush against the panel on both sides. A small amount of silicone lubricant (non-petroleum based) can assist with insertion if needed, but avoid excessive force.
3. **Install the Lamp:** Once the grommet is securely in place, align the compatible lamp with the grommet's inner opening. Push the lamp firmly into the grommet until it snaps into position. The grommet's flexible material will grip the lamp, holding it securely.
4. **Verify Security:** Gently tug on the installed lamp to ensure it is firmly seated and does not wobble. Proper installation will prevent the lamp from dislodging due to vehicle vibration or movement.

Note: Always refer to the specific lamp manufacturer's instructions for any additional mounting requirements or recommendations.

5. FUNCTION AND PURPOSE

The primary function of the Truck-Lite 60700 Grommet is to provide a resilient and protective mounting for vehicle lamps. It serves several key purposes:

- **Secure Mounting:** Holds the lamp firmly in place within the vehicle's body or housing.

- **Vibration Dampening:** Absorbs shocks and vibrations, extending the lifespan of the lamp and its electrical connections.
- **Environmental Seal:** Helps to create a seal around the lamp, protecting it from moisture, dust, and road debris.
- **Insulation:** Provides electrical insulation between the lamp and the vehicle's metal body.

6. MAINTENANCE

The Truck-Lite 60700 Grommet requires minimal maintenance. Regular inspection is recommended to ensure its continued performance:

- **Visual Inspection:** Periodically check the grommet for signs of wear, cracking, hardening, or deterioration, especially in harsh weather conditions or environments with significant UV exposure.
- **Cleanliness:** Keep the area around the grommet clean to prevent accumulation of dirt or corrosive materials that could degrade the rubber over time.
- **Secure Fit:** Ensure the lamp remains securely seated within the grommet. If the lamp becomes loose, inspect the grommet for damage or consider replacement.

7. TROUBLESHOOTING

While the Truck-Lite 60700 Grommet is a simple component, some issues may arise:

- **Lamp is Loose:**
 - **Cause:** Grommet may be worn, damaged, or improperly installed.
 - **Solution:** Remove the lamp and inspect the grommet. If it shows signs of damage or excessive wear, replace it. Ensure the grommet is fully seated in the mounting hole and the lamp is pushed firmly into the grommet.
- **Difficulty Installing Grommet:**
 - **Cause:** Mounting hole may be too small, or grommet is stiff.
 - **Solution:** Verify the mounting hole dimensions are correct for the 60700 grommet. A small amount of silicone lubricant can aid insertion. Do not force the grommet, as this can cause damage.

8. WARRANTY AND SUPPORT INFORMATION

Specific warranty details for the Truck-Lite 60700 Grommet are not provided in the product information. For warranty claims, technical support, or further assistance, please contact Truck-Lite directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.

You can typically find contact information on the [Truck-Lite official website](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0009X1K34>

More documents and user manuals: <https://manuals.plus/>