

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Kero World](#) /

› [Kero World 32225 KW-24C Replacement Wicks User Manual](#)

## Kero World 32225

# Kero World 32225 KW-24C Replacement Wicks User Manual

Model: 32225 | Brand: Kero World

[Overview](#)

[Installation](#)

[Operating](#)

[Maintenance](#)

[Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

## PRODUCT OVERVIEW

The Kero World 32225 KW-24C Replacement Wicks are designed to provide optimal performance for compatible kerosene heaters. These wicks feature a durable cotton-fiberglass construction with a burn-free fiberglass top, ensuring efficient fuel flow and consistent heat output. The design aims to reduce carbon build-up and facilitate easier installation.



*Image: Kero World 32225 KW-24C Replacement Wick, showing its construction with an orange band and white fibrous material.*

## Product Features

- **Advanced Technology:** Provides maximum performance through modern wick technology.
- **Reduced Carbon Build-up:** Exclusive black top FIBER-GRAPH burning surface reduces carbon build-up by up to 38% compared to traditional white top wicks.
- **Easy Installation:** Manufactured to exact specifications for a straightforward installation process.
- **Precise Fit:** Ensures correct length, diameter, and thickness for a proper fit in compatible heaters.
- **Efficient Combustion:** Superior design combines smooth fuel flow and a high-temperature burning surface for a more complete combustion process.

## Product Overview Video

Your browser does not support the video tag.

*Video: A brief overview of the Kero World 32225 replacement wick, highlighting its features and compatibility.*

## INSTALLATION INSTRUCTIONS

---

Follow these steps carefully to replace the wick in your kerosene heater. Always ensure the heater is turned off and completely cool before beginning any maintenance or installation.

### Wick Replacement & Installation Video Guide

Your browser does not support the video tag.

*Video: Detailed step-by-step guide on how to replace and install the 32225 Kerosene Heater Wick.*

1. **Prepare the Heater:** Ensure the kerosene heater is turned off and completely cool before beginning the installation. Disconnect it from any power source if applicable.
2. **Remove the Wick Housing:** Carefully detach the wick housing according to your heater's manufacturer's instructions. This usually involves unscrewing or unlatching components.
3. **Remove the Old Wick:** Gently pull out the old wick from the burner assembly. Dispose of the old wick properly.
4. **Clean up Residue:** Use a towel or brush to wipe away any residue left on the burner or surrounding areas. Ensure the area is clean before installing the new wick.
5. **Insert the New Wick:** Place the new Kero World 32225 replacement wick into the burner, ensuring it fits snugly and evenly. The wick should be properly seated.
6. **Adjust the Wick Height:** Use the adjustment knob on your heater to set the wick height to the recommended level for optimal flame. Refer to your heater's manual for specific height recommendations.
7. **Reassemble the Heater:** Securely reattach the wick housing and any other components that were removed. Ensure all parts are correctly aligned and fastened.
8. **Test the Heater:** Fill the fuel tank with kerosene, light the heater, and observe the flame for proper operation. Allow the wick to saturate with fuel for at least 30 minutes before lighting for the first time.

## OPERATING YOUR KEROSENE HEATER

---

After successful wick installation, follow your heater's specific operating instructions. Generally, ensure proper ventilation, use only 1-K kerosene, and monitor the flame for consistent and clean burning. Adjust the wick height as needed to maintain an optimal flame, typically a blue flame with yellow tips.

## MAINTENANCE

---

Regular maintenance ensures the longevity and efficient operation of your kerosene heater and wick. Beyond wick replacement, periodically inspect the burner for any carbon buildup and clean as necessary. Keep the fuel tank clean and free of debris. Store kerosene in a cool, dry place in an approved container.

## TROUBLESHOOTING

---

- **Uneven Flame or Poor Heating:** This often indicates a worn-out wick or carbon buildup. Replace the wick following the installation steps, or clean the burner assembly.
- **Difficulty Lighting:** Ensure the wick is properly saturated with kerosene. If the igniter is faulty, it may need replacement.
- **Excessive Smoke or Odor:** This can be caused by using incorrect fuel (not 1-K kerosene), an improperly adjusted wick, or a dirty burner. Adjust the wick height, ensure proper fuel, and clean the heater.
- **Wick Not Moving Up/Down:** Check for obstructions or damage to the wick adjustment mechanism. Ensure the wick is installed correctly and not jammed.

## SPECIFICATIONS

---

<b>Manufacturer</b>	Kero World
<b>Model Number</b>	32225
<b>Product Dimensions</b>	11.5 x 7.5 x 0.5 inches
<b>Item Weight</b>	5 ounces
<b>Material</b>	Fiberglass
<b>Unit Count</b>	4.0 Count
<b>UPC</b>	885569415454, 787543787925, 013204322250, 885262015111, 885284469091

## WARRANTY & SUPPORT

---

### Warranty Information

This product comes with a **1-year warranty** from the manufacturer, Kero World. For specific details regarding warranty claims or coverage, please refer to the documentation included with your purchase or contact Kero World customer service.

### Customer Support

For additional support, product inquiries, or to explore other Kero World products, please visit the official Kero World store:

[Visit the Kero World Store on Amazon](#)