

Winner International SHL 704

Winner International The Club SHL 704 Airbag and Steering Wheel Shield

Model: SHL 704

1. INTRODUCTION AND PRODUCT OVERVIEW

The Club SHL 704 Airbag and Steering Wheel Shield is an accessory designed to enhance the security provided by an existing Club steering wheel lock (**Note: The Club steering wheel lock is not included with this product**). Manufactured by Winner International, this shield adds an additional layer of protection against vehicle theft, specifically targeting the prevention of airbag removal and steering wheel cutting.

Its unique design features a high-tech, super-hard metal shell that covers the central portion of the steering wheel, making it significantly more difficult for potential thieves to cut the steering wheel or access the airbag. This product serves as a highly visible deterrent, discouraging theft attempts before they even begin.

Key Features:

- **Enhanced Security:** High-tech, super-hard metal shell prevents removal of the steering wheel and vehicle's airbag.
- **Theft Deterrent:** Unique design reinforces security by preventing steering wheel cutting, a common method used to bypass traditional steering wheel locks.
- **Compact Storage:** Folds down to a quarter circle, approximately 9-1/4 inches deep by 13-1/4 inches wide, for convenient storage.
- **High Visibility:** Acts as a strong visual deterrent against theft.
- **Universal Fit:** Nearly universal, fits standard steering wheels between 14-1/2 to 16 inches in diameter with 3/4 to 1-1/2 inch grip thickness and up to 1/2 inch above airbags and rise.



The Club SHL 704 Airbag and Steering Wheel Shield in its retail packaging, illustrating its quarter-circle design and how it integrates with a Club steering wheel lock to protect the airbag and steering wheel.

2. SETUP AND INSTALLATION

The Club SHL 704 Airbag and Steering Wheel Shield is designed to be used in conjunction with a compatible Club steering wheel lock. Ensure you have a Club steering wheel lock available before proceeding with installation.

Compatibility Check:

Verify that your vehicle's steering wheel meets the following specifications for optimal fit:

- **Steering Wheel Diameter:** 14-1/2 to 16 inches.
- **Grip Thickness:** 3/4 to 1-1/2 inches.
- **Clearance Above Airbag:** Up to 1/2 inch.

Installation Steps:

1. **Prepare Your Vehicle:** Ensure your vehicle is parked securely and the engine is off.
2. **Position the Shield:** Unfold The Club SHL 704 Airbag and Steering Wheel Shield. Place the shield over the central portion of your steering wheel, ensuring it covers the airbag and the area where the Club lock will attach. The shield is designed to fit snugly around the steering wheel's inner circumference.
3. **Install The Club Lock:** While holding the shield in place with one hand, attach your compatible Club steering wheel lock as you normally would. The shield is designed with openings that allow the arms of the Club lock to pass through and secure the steering wheel.
4. **Secure the Lock:** Engage and lock your Club steering wheel lock according to its specific instructions. The shield should be firmly held in place by the Club lock, preventing its removal without first disengaging the lock.
5. **Verify Installation:** Gently attempt to move the shield and the steering wheel. Neither should move freely. The shield should feel secure and integrated with the Club lock.

The installation process is designed to be quick and straightforward, typically taking only a few seconds once familiar with the steps.

Your browser does not support the video tag.

Product Overview Video: This video demonstrates the physical characteristics and general handling of The Club SHL 704 Airbag and Steering Wheel Shield, including its compact form and how it is positioned on a steering wheel. It highlights the product's design for ease of use and its role in vehicle security.

3. OPERATING INSTRUCTIONS

Once properly installed with your Club steering wheel lock, The Club SHL 704 Airbag and Steering Wheel Shield operates passively as a robust security enhancement and visual deterrent.

Daily Use:

1. **Installation:** Follow the setup instructions (Section 2) each time you wish to secure your vehicle.
2. **Removal:** To remove the shield, first unlock and remove your Club steering wheel lock. Once the Club lock is detached, the SHL 704 shield can be easily removed from the steering wheel.
3. **Storage:** For convenient storage, the shield folds down to a compact quarter-circle shape. Store it in a safe place within your vehicle, such as the trunk or under a seat, to prevent it from becoming a projectile during sudden stops or accidents.

4. MAINTENANCE

Regular maintenance of your Club SHL 704 Airbag and Steering Wheel Shield will ensure its longevity and continued effectiveness.

Cleaning:

- Wipe the shield with a soft, damp cloth to remove dust and grime.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.

Inspection:

- Periodically inspect the shield for any signs of damage, such as cracks, dents, or deformation.
- Ensure that the folding mechanism operates smoothly and that the shield retains its structural integrity.

- If any significant damage is observed, discontinue use and consider replacing the product to maintain optimal security.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with The Club SHL 704 Airbag and Steering Wheel Shield.

Issue: The shield does not fit my steering wheel.

- **Solution:** Re-check the compatibility requirements in Section 2. Ensure your steering wheel diameter, grip thickness, and airbag clearance fall within the specified ranges (14-1/2 to 16 inches diameter, 3/4 to 1-1/2 inches grip thickness, up to 1/2 inch above airbag). If your steering wheel is outside these dimensions, the shield may not be compatible.

Issue: The shield feels loose after installing The Club lock.

- **Solution:** Ensure that your Club steering wheel lock is properly and tightly secured. The SHL 704 shield relies on the clamping action of the Club lock to hold it firmly in place. If the Club lock itself is loose or not fully engaged, the shield will also feel loose. Verify that the Club lock's arms are correctly positioned through the shield's openings and are gripping the steering wheel securely.

Issue: Difficulty installing The Club lock with the shield.

- **Solution:** It may require holding the shield with one hand while positioning and engaging the Club lock with the other. Practice the installation a few times to become familiar with the process. Ensure the shield is centered and aligned before attempting to attach the Club lock.

6. SPECIFICATIONS

Attribute	Detail
Brand	Winner International
Model Number	SHL 704
Item Weight	2.86 pounds
Item Diameter	16 Inches (maximum compatible steering wheel diameter)
Color	White
Automotive Fit Type	Universal Fit (within specified dimensions)
Material	High-tech super hard metal shell
Folded Dimensions	Approximately 9-1/4 inches deep by 13-1/4 inches wide (quarter circle)
UPC	015291007041
ASIN	B000AMOENW
What's in the Box	Steering Wheel Shield (The Club steering wheel lock sold separately)

7. WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to inquire about replacement parts, please contact Winner International customer service directly. Details can typically be found on the product packaging or the official Winner International website.

It is recommended to retain your proof of purchase for any warranty claims.