

manuals.plus /

- › [PARAMOUNT](#) /
- › [Star Trek: Enterprise: The Complete Series DVD Instruction Manual](#)

PARAMOUNT B000AOEMXM

Star Trek: Enterprise: The Complete Series DVD Instruction Manual

Model: B000AOEMXM

PRODUCT OVERVIEW

This manual provides instructions for the Star Trek: Enterprise: The Complete Series DVD set. This collection includes all four seasons of the television series, chronicling the voyages of Captain Jonathan Archer and the crew of the Enterprise NX-01. The set contains 27 discs, offering over 70 hours of content, including all episodes and a variety of bonus features.



Image: The complete DVD box set for Star Trek: Enterprise, featuring the series logo and main cast.

SETUP INSTRUCTIONS

1. **Unpack the DVD Set:** Carefully remove the DVD cases from the outer packaging. Each season is typically housed in its own case within the complete series box.
2. **Select a Disc:** Choose the desired season and disc from the collection. Handle discs by their edges to avoid fingerprints.
3. **Insert into DVD Player:** Place the selected DVD into a compatible DVD player. Ensure the disc is inserted

correctly, usually label-side up.

4. **Connect to Display:** Ensure your DVD player is properly connected to your television or display device according to your player's instructions.

OPERATING INSTRUCTIONS

- **Power On:** Turn on your DVD player and television. Select the correct input source on your television for the DVD player.
- **Main Menu:** The disc should automatically load to a main menu. Use your DVD player's remote control to navigate the menu.
- **Playing Episodes:** Select "Play All" or choose individual episodes from the episode selection menu.
- **Accessing Special Features:** Navigate to the "Special Features" or "Bonus Features" section on the main menu to access content such as deleted scenes, commentaries, featurettes, outtakes, and photo galleries.
- **Language and Subtitles:** If available, select audio language or subtitle options from the disc's menu or directly via your DVD player's remote control. The discs are primarily in English and include closed captions.
- **Pausing and Stopping:** Use the standard pause, play, stop, fast-forward, and rewind functions on your DVD player's remote.

MAINTENANCE

- **Disc Cleaning:** To clean discs, gently wipe them with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store discs in their original cases, away from direct sunlight, extreme temperatures, and high humidity. This helps prevent scratches and warping.
- **Handling:** Always handle discs by the edges or the center hole to avoid leaving fingerprints on the playback surface.

TROUBLESHOOTING

Disc Not Playing or Skipping:

- Ensure the disc is clean and free of smudges or scratches. Clean as per maintenance instructions.
- Verify the disc is inserted correctly into the DVD player.
- Try playing another DVD to confirm your player is functioning correctly.
- Some older DVD players may have difficulty reading newer discs; ensure your player is up-to-date or try on a different player.

No Audio or Video:

- Check all audio and video cables connecting your DVD player to your television.
- Ensure your television is set to the correct input source.
- Verify the volume on your television and DVD player is turned up and not muted.

Menu Navigation Issues:

- Ensure your DVD player's remote control has fresh batteries and is pointed directly at the player.
- Restart the DVD player by powering it off and on.

SPECIFICATIONS

Product Title	Star Trek: Enterprise: The Complete Series
Format	DVD, Closed-captioned, Multiple Formats, NTSC
Number of Discs	27
Run Time	70 hours and 23 minutes
Release Date	November 1, 2005
Language	English
Studio	PARAMOUNT
MPAA Rating	Unrated (Not Rated)
Aspect Ratio	1.78:1
Product Dimensions	7.7 x 6.6 x 7.9 inches; 4.15 Pounds
ASIN	B000AOEMXM
Item Model Number	908485566088

WARRANTY AND SUPPORT

For specific warranty information regarding this DVD set, please refer to the documentation provided by your retailer at the time of purchase. General product support for media products is typically handled by the manufacturer, Paramount. For further assistance, please consult the official Paramount Home Entertainment website or customer service channels.