

## Solac AS3220

# Solac AS3220 Apollo Silent Bagless Canister Vacuum Cleaner User Manual

Model: AS3220

## 1. INTRODUCTION

---

Thank you for choosing the Solac AS3220 Apollo Silent Bagless Canister Vacuum Cleaner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your appliance. Please read these instructions carefully before first use and keep them for future reference.

## 2. SAFETY INSTRUCTIONS

---

- Always ensure the power supply voltage matches the rating label on the vacuum cleaner.
- Do not use the vacuum cleaner to pick up water or other liquids, hot ashes, sharp objects, or flammable substances.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug the appliance from the power outlet before cleaning or performing any maintenance.
- Do not operate the vacuum cleaner with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is intended for domestic use only.

## 3. PACKAGE CONTENTS

---

Carefully unpack your Solac AS3220 Apollo Silent vacuum cleaner and check that all items are present and in good condition. The package should contain:

- Solac AS3220 Vacuum Cleaner Unit
- Flexible Hose
- Telescopic Tube
- Floor Nozzle

- Crevice Tool
- Upholstery Brush
- User Manual

## 4. SETUP

---

Follow these steps to assemble your vacuum cleaner before first use:

1. **Attach the Flexible Hose:** Insert the hose connector firmly into the suction inlet on the main vacuum cleaner unit until it clicks into place.
2. **Connect the Telescopic Tube:** Attach the handle end of the flexible hose to the wider end of the telescopic tube.
3. **Attach the Floor Nozzle:** Connect the floor nozzle to the narrower end of the telescopic tube. Ensure it is securely fitted.



*Image 1: The Solac AS3220 Apollo Silent vacuum cleaner floor nozzle. This image shows the main floor cleaning attachment, featuring the 'Solac' brand logo and 'XXL' marking, indicating a wide cleaning path. It includes a foot-operated switch for adjusting brush settings.*

4. **Power Connection:** Extend the power cord from the vacuum cleaner and plug it into a suitable electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

Your Solac AS3220 Apollo Silent vacuum cleaner is designed for efficient cleaning on various surfaces.

- **Power On/Off:** Press the power button located on the main unit to start or stop the vacuum cleaner.
- **Cord Rewind:** Press the cord rewind button to automatically retract the power cord. Always hold the plug when rewinding to prevent injury.

- **Adjusting Suction:** Use the air flow control slider on the hose handle to adjust the suction power for different cleaning tasks. Close the slider for maximum suction, open it to reduce suction for delicate surfaces.
- **Using the Floor Nozzle:** The floor nozzle typically has a switch to adjust for hard floors or carpets. Press the switch with your foot to extend or retract the brushes as needed.
- **Using Attachments:** For specific cleaning tasks, detach the floor nozzle and attach the crevice tool for narrow spaces or the upholstery brush for furniture and curtains.

## 6. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

### 6.1 Emptying the Dust Container

1. Ensure the vacuum cleaner is unplugged from the power outlet.
2. Locate the dust container release button on the main unit. Press it to detach the dust container.
3. Carefully remove the dust container from the vacuum cleaner.
4. Open the dust container over a waste bin and empty its contents.
5. Close the dust container and reattach it to the vacuum cleaner unit until it clicks securely into place.

### 6.2 Cleaning the Filters

The Solac AS3220 uses a cartridge filter system. Filters should be cleaned regularly to maintain suction power.

1. With the dust container removed, locate the filters. There is typically a pre-motor filter and an exhaust filter.
2. Remove the filters according to the markings on the filter housing.
3. Tap the filters gently over a waste bin to remove loose dust. For thorough cleaning, rinse the filters under cold running water.
4. Allow the filters to air dry completely for at least 24 hours before reinserting them. Do not use a hairdryer or other heating devices.
5. Reinsert the dry filters into their respective compartments and reattach the dust container.

### 6.3 Cleaning Attachments

Wipe attachments with a damp cloth. Ensure they are dry before reattaching them to the vacuum cleaner.

## 7. TROUBLESHOOTING

---

Before contacting customer service, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply. Power button not pressed.	Check if the plug is securely inserted into the outlet. Press the power button firmly.

Problem	Possible Cause	Solution
Poor suction power.	Dust container full. Filters are dirty. Hose or attachments blocked.	Empty the dust container. Clean or replace the filters. Check and clear any blockages in the hose, telescopic tube, or attachments.
Unusual noise during operation.	Blockage in the air path. Motor issue.	Check for and remove any blockages. If the noise persists, contact customer support.
Dust escaping from the vacuum.	Dust container not properly closed. Filters not correctly installed or damaged.	Ensure the dust container is securely latched. Check filter installation and condition; replace if damaged.

## 8. SPECIFICATIONS

- **Model Number:** AS3220
- **Brand:** Solac
- **Power:** 1800 Watts
- **Noise Level:** 71 Decibels
- **Filter Type:** Cartridge
- **Special Feature:** Bagless
- **Form Factor:** Canister
- **Weight:** Approximately 9.62 Kilograms
- **Dimensions (Package):** 52.6 x 36.2 x 33.4 cm

## 9. WARRANTY AND SUPPORT

Your Solac AS3220 Apollo Silent vacuum cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, spare parts, or service inquiries, please contact your local Solac authorized service center or visit the official Solac website.