

Timex T2H451

Timex Men's Easy Reader Watch T2H451 Instruction Manual

Model: T2H451

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Timex Men's Easy Reader Watch, Model T2H451. Designed for clear readability and classic style, this timepiece offers reliable timekeeping and practical features.





Front view of the Timex Men's Easy Reader Watch, Model T2H451, featuring a white dial with large Arabic numerals and a silver-tone stainless steel expansion band.

2. KEY FEATURES

- **Easy-to-Read Dial:** White dial with full Arabic numerals for clear visibility.
- **Date Window:** Convenient date display at the 3 o'clock position.
- **Indiglo Night-Light:** Electroluminescent backlight for easy reading in low-light conditions.
- **Durable Construction:** Silver-tone 35mm brass case with a mineral glass crystal.
- **Comfortable Band:** Silver-tone 18mm stainless steel expansion band, designed to fit up to an 8-inch wrist circumference.
- **Water Resistance:** Water resistant to 30 meters (100 feet), suitable for splashes or brief immersion, but not for swimming or bathing.

3. SETUP

3.1 Activating the Watch

Your watch may arrive with a small plastic spacer under the crown (the knob on the side). This spacer prevents the battery from draining during storage and shipping. To activate the watch:

1. Carefully remove the plastic spacer from under the crown.
2. Push the crown fully inward towards the watch case. The second hand should begin to move, indicating the watch is active.

Your browser does not support the video tag.

Video demonstrating the Timex Men's Easy Reader Watch, highlighting its features and appearance.

3.2 Setting Time and Date

To ensure accurate timekeeping and date display, follow these steps:

1. **Pull the Crown:** Gently pull the crown out to the outermost position. The second hand will stop.
2. **Set the Time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands. Advance the hands past 12 o'clock to determine if it's AM or PM (the date will change around midnight).
3. **Set the Date:** Once the time is set, push the crown halfway back in (to the middle position). Rotate the crown to adjust the date in the date window. If your watch also has a day display, rotate the crown in the opposite direction to set the day.
4. **Final Adjustment:** Once the desired date and time are set, push the crown fully back into the watch case. The second hand will resume movement.

4. OPERATING INSTRUCTIONS

4.1 Using the Indiglo Night-Light

The Indiglo night-light illuminates the entire watch dial for easy viewing in the dark.

- To activate the Indiglo night-light, simply press and hold the crown.
- The light will remain on as long as the crown is pressed. Release the crown to turn off the light.



The Timex Easy Reader Watch with its Indiglo night-light feature activated, showing the illuminated dial in a dark setting.

5. MAINTENANCE

5.1 Water Resistance

Your Timex Easy Reader Watch is water resistant to 30 meters (100 feet). This means it is protected against splashes, rain, or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

5.2 Battery Replacement

The watch uses a CR2016 Lithium Metal 3.0V battery. Battery life can vary depending on usage, especially frequent use of the Indiglo feature. When the watch stops or the Indiglo light dims significantly, it's time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.3 Cleaning

To clean your watch, wipe the case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

6. TROUBLESHOOTING

- **Watch Not Running:** Ensure the plastic spacer has been removed from under the crown and the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Indiglo Not Working:** If the Indiglo night-light does not illuminate when the crown is pressed, the battery may be low or depleted.
- **Date Not Changing:** Ensure the time is set correctly, passing midnight to advance the date. If the date is stuck, try resetting it manually as described in Section 3.2.

- **Water Inside Watch:** If moisture appears inside the watch, immediately take it to a qualified watch technician for inspection and repair to prevent further damage.

7. SPECIFICATIONS



Brand	Timex
Model Number	T2H451
Case Material	Brass
Case Diameter	35mm
Band Material	Stainless Steel
Band Width	18mm
Crystal Material	Mineral Glass
Movement	Quartz
Battery Type	1 Lithium Metal CR2016 (included)
Water Resistance	30m (100ft)
Product Dimensions	3.5 x 2.8 x 2.5 inches; 2.08 ounces





8. WARRANTY AND SUPPORT

Your Timex watch is covered by a manufacturer's warranty. For specific warranty details, registration, or to locate an authorized service center, please refer to the official Timex website or the warranty card included with your purchase.

For additional support or inquiries, visit the [Timex Store on Amazon](#).

Related Documents - T2H451

	<p>Timex Kids Digital Watch User Guide - Operation and Features</p> <p>Comprehensive user guide for the Timex Kids digital watch (model 791-095007). Covers features, basic operations, setting time and date, chronograph, alarm, timer, INDIGLO night light, water resistance, strap adjustments, battery information, and warranty details.</p>
	<p>Timex Watch User Manual: Features, Operation, and Care</p> <p>Comprehensive user manual for Timex watches, detailing features like analog and digital time, multiple time zones, alarms, chronographs, timers, water resistance, and bracelet adjustment.</p>

	<p>Timex W-209 Watch User Manual: Features, Operation, and Warranty</p> <p>Comprehensive guide to operating your Timex W-209 watch, covering time setting, chronograph, timer, alarms, occasions, INDIGLO night-light, water resistance, battery, and international warranty information.</p>
	<p>Timex T200 Watch User Guide and Instructions</p> <p>Comprehensive user guide for the Timex T200 watch, covering functions, basic operation, time, date, alarms, chronograph, timers, water resistance, and battery information.</p>
	<p>Timex Small Digital Watch User Manual - Model 11W</p> <p>Official user guide for the Timex Small Digital watch (Model 11W). Learn how to set time, date, use the chronograph, alarm, and Indiglo night-light. Includes warranty information.</p>
	<p>Timex Watch User Manual and Operating Instructions</p> <p>Comprehensive user manual and operating instructions for Timex watches, covering setup, features, maintenance, and warranty. Available in multiple languages including English, French, Spanish, Portuguese, Italian, German, Dutch, Czech, Hungarian, Polish, Romanian, Turkish, Russian, Japanese, and Chinese.</p>