

Hasbro 85803

Hasbro Star Wars The Saga Collection Bib Fortuna Action Figure Instruction Manual

Model: 85803

1. INTRODUCTION

Thank you for choosing the Hasbro Star Wars The Saga Collection Bib Fortuna action figure. This collectible figure commemorates a memorable storyline from the film *Return of the Jedi*. It is designed for collectors and enthusiasts aged 4 and up, featuring a detailed action figure, a display stand, and an exclusive hologram figure.

2. SETUP AND ASSEMBLY

Your Bib Fortuna action figure comes ready for display with minimal assembly required. Carefully remove all components from the packaging.

2.1 Components

- Bib Fortuna Action Figure
- Display Stand
- Exclusive Hologram Figure
- Accessory: Knife

2.2 Displaying the Figure

Place the Bib Fortuna action figure onto the provided display stand. The stand is designed to securely hold the figure upright for exhibition.



Figure 1: Bib Fortuna action figure positioned on its display stand.

The exclusive hologram figure can be displayed alongside Bib Fortuna or in another preferred location. This figure is typically a translucent blue representation of another character from the Star Wars universe.



Figure 2: The exclusive hologram figure, often depicting a character like Boba Fett.

3. OPERATING AND POSING

The Bib Fortuna action figure features several points of articulation for posing:

- **Head:** Ball-jointed for varied head positions.
- **Neck:** Swivel articulation.
- **Elbows:** Swivel articulation.
- **Wrists:** Swivel articulation.

Carefully manipulate the joints to achieve desired poses. Avoid excessive force to prevent damage. The figure's soft, flexible head-tails (lekku) allow for head movement despite their design.

The included knife accessory can be placed in the figure's hand or tucked into its belt, as depicted in various media.

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your action figure, follow these care guidelines:

- **Cleaning:** Dust the figure regularly with a soft, dry cloth. For stubborn dirt, lightly dampen a cloth with water and gently wipe the surface. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation.
- **Handling:** Handle the figure by its main body parts. Avoid pulling on smaller accessories or delicate areas.

5. TROUBLESHOOTING

If you encounter any issues with your action figure, consider the following:

- **Stiff Joints:** If a joint is stiff, gently warm the area with a hairdryer on a low setting for a few seconds (hold at a safe distance) to make the plastic more pliable. Do not overheat.

- **Loose Accessories:** Ensure accessories are properly seated in the figure's hands or attachment points.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	1.75 x 6 x 8.87 inches
Item Weight	3.52 ounces
Item Model Number	85803
Manufacturer Recommended Age	4 - 11 years
Release Date	June 12, 2006
Manufacturer	Hasbro

7. WARRANTY AND SUPPORT

For information regarding product warranty or to contact customer support, please refer to the official Hasbro website or the contact details provided on the product packaging. You can also visit the [Hasbro Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

