

BRIO 33710

BRIO World 33710 - My First Railway Battery Operated Train Set

INSTRUCTION MANUAL

Introduction

Welcome to the BRIO World 33710 - My First Railway Battery Operated Train Set, the perfect beginner's set for your young one. This comprehensive 25 piece set includes trains, tracks, elevated supports, and a tunnel, designed to spark creativity and imagination. Activated by a simple press on the arrow button on top of the hood, this set offers a delightful playtime experience. Its compatibility with all other BRIO railway toys allows the set to grow with your child, expanding their play and exploration. Playing with this train set helps in developing key skills like spatial awareness and fine motor coordination. Safety is a top priority for BRIO, with over 1000 safety tests conducted annually to ensure all products conform to safety standards. Above all, the train set is certified by the Forest Stewardship Council, making it a sustainable choice that supports responsible forestry. So, gift your child a fun, safe, and educational play experience with the BRIO World 33710 - My First Railway Battery Operated Train Set.

What's Included

Your BRIO World 33710 set contains the following components:

- Engine
- Wagon
- Reel
- Ramps (4)
- Stacking Curve




Image: The BRIO World 33710 set, showing the packaging and all included components laid out, including the train, wagon, tracks, ramps, and stacking curve.

Setup Instructions

Battery Installation

The battery-operated engine requires one AA battery (not included). To install the battery, carefully open the battery compartment on the underside of the engine. Insert the AA battery, ensuring correct polarity (+/-), then close the compartment securely.

Track Assembly

Connect the wooden track pieces by aligning the interlocking ends. The set includes straight and curved tracks, allowing for various layout configurations. Use the elevated supports (yellow pieces) to create inclines and bridges for dynamic play. The red and green stacking curves can be used to create tunnels or elevated sections.

Video: This video demonstrates the assembly of the BRIO World 33710 train set, including track connection and train operation.



Image: An overhead view of the assembled BRIO World 33710 train set, showcasing the track layout with elevated sections and the train on the tracks.

Operating Instructions

Starting and Stopping the Train

To start the battery-operated train, simply press the arrow button located on top of the engine. Press the button again to stop the train. The train is designed to run smoothly along the wooden tracks, through tunnels, and over elevated sections.

Expanding Your Railway

This set is compatible with all other BRIO railway toys, allowing you to expand your child's play and exploration as they grow. Additional tracks, trains, and accessories can be seamlessly integrated.



Image: Two children, a boy and a girl, are shown playing together with the BRIO World 33710 train set on the floor, demonstrating interactive play.

Maintenance and Care

To ensure the longevity of your BRIO train set, follow these simple care guidelines:

- Wipe wooden parts with a clean, damp cloth. Do not immerse in water.
- Avoid exposing the set to extreme temperatures or direct sunlight, which can cause warping or fading.
- Remove batteries from the engine if the toy will not be used for an extended period to prevent leakage.
- Regularly check track connections for any loose parts to ensure smooth operation.

Troubleshooting

Problem	Solution
Train does not move.	Check if the battery is correctly installed and has sufficient power. Replace with a new AA battery if necessary. Ensure the train is placed correctly on the tracks.
Train derails frequently.	Verify that all track pieces are securely connected and laid on a flat, stable surface. Check for any obstructions on the track.
Track pieces do not connect properly.	Ensure the correct ends of the track pieces are aligned. Some pieces may be designed for specific connections.

Product Specifications

Feature	Detail
Product Dimensions	18.9 x 27.56 x 0.01 inches
Item Weight	2.26 pounds
Model Number	33710
Manufacturer Recommended Age	18 months - 5 years
Batteries	1 AA battery (not included)
Manufacturer	BRIO
Number of Pieces	25

Safety Information

BRIO prioritizes child safety. This product undergoes over 1000 safety tests annually to ensure it conforms to all safety standards. Always supervise young children during play.

- Designed for toddlers aged 18 months and up.
- Made with durable, child-safe materials.
- No small parts that pose a choking hazard for the recommended age group.

Environmental Responsibility

The BRIO World 33710 train set is certified by the Forest Stewardship Council (FSC), ensuring that the wood used comes from responsibly managed forests. Choosing this product supports sustainable forestry practices.

Warranty and Support

For warranty information or customer support, please visit the official BRIO website or contact their customer service department. Keep your purchase receipt as proof of purchase.

© 2025 BRIO. All rights reserved.

Documents - BRIO – 33710

[\[pdf\]](#) Installation Guide

3705 896 F MFR Battery Train LR 7312350337105 PINFO 33710 battery instruction ravensburger de spieleanleitungen ecm Spielanleitungen |||



EN Drive/stop button DE Fahr-/Stopptaste FR Bouton lecture/stop Battery-operated play functions: Press down the drive/stop button to make the engine go forward. Press again and the engine will stop. Note The engine needs to be driving in the forward direction when driving up an ascending track. ...

lang:en score:28 filesize: 700.07 K page_count: 2 document date: 2023-04-24

[pdf]



36002 MFR Light Up Rainbow Set NEW LR Bekijk de CE markering BRIO My First Railway Treinbaan bol original media s NWyE476DlpLK |||


PRODUCT NUMBER PRODUCT NAME 36002 MFR Light Up Rainbow Set

CONCEPT My First TYPE OF PACKAGE Clos ... quirements of EN71 and ASTM

F963. Conforme aux xigences de scurit EN71 et ASTM F963. 36002 33727 **33710**

36002 ...

lang:en score:19 filesize: 1.28 M page_count: 1 document date: 2022-06-14



[Billboard International Buyer's Guide 1992](#)

The 1992 Billboard International Buyer's Guide is a comprehensive directory for the music and home video industries, listing record labels, music publishers, home video companies, and industry services and suppliers worldwide. It includes contact information, key personnel, and label details for businesses in the music and entertainment sectors.

lang:en score:16 filesize: 29.26 M page_count: 317 document date: 2019-07-11



[Productos de alta calidad para el hogar y el entretenimiento](#)

Descubra una amplia gama de productos de alta calidad, desde electrónica y artículos para el hogar hasta juguetes y accesorios para niños. Encuentre las últimas novedades y ofertas.


lang:de score:14 filesize: 1.88 M page_count: 33 document date: 2019-03-01



[Produktkatalog: Elektronik, Spielzeug, Haushalt & mehr](#)

Entdecken Sie eine breite Auswahl an Produkten, darunter Elektronik, Spielzeug, Haushaltswaren und Zubehör. Finden Sie hochwertige Artikel von führenden Marken.

lang:en score:12 filesize: 1.47 M page_count: 23 document date: 2019-07-08



[\[pdf\]](#) User Manual Troubleshooting Guide

RIDER s PERPETUAL TROUBLESHOOTER S Radio set service manuals 1930 to 1954 Rider Auto repair Repair Manual Vol II 1935 worldradiohistory Archive BOOKS |||

Specialized AUTO RADIO MANUAL ALAI 33111 III III VOLUME II by John F. Rider JOHN F. RIDER Pu ... 10 On WHITE 40,000 C/ R3 n GREEN R 3300 R9 SLUE 1 nuGeRAY TRANSFORMERS Code Part No. No. Ti **33710** T2 33720 T3 25651 T4 33790 T5 25371 T6 25606 Name of Part No. 1 R. F. T. Oscillator T. No. 1 ...
lang:en **score:11** filesize: 30.45 M page_count: 417 document date: 2021-09-17