

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Mr. Coffee](#) /

› [Mr. Coffee IDS77 12-Cup Electric Coffee Grinder Instruction Manual](#)

Mr. Coffee IDS77

Mr. Coffee IDS77 12-Cup Electric Coffee Grinder Instruction Manual

INTRODUCTION

The Mr. Coffee 12-Cup Electric Coffee Grinder and Spice Grinder (Model IDS77) is designed to provide freshly ground coffee beans with variable grind settings. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance.



Figure 1: Assembled Mr. Coffee 12-Cup Electric Coffee Grinder.

IMPORTANT SAFETY INFORMATION

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended household use.

PRODUCT FEATURES

- **Automatic Coffee and Spice Grinder:** Features variable settings for Coarse, Medium, or Fine grinds.
- **Chamber Maid Cleaning System:** Sweeps chamber walls to reduce mess and waste, ensuring thorough cleaning.
- **Removable Grinding Chamber:** Allows for easy filling, optimal pouring, and hassle-free cleaning.
- **Exact Measure:** Precisely grinds for 4 to 12 cups of coffee.
- **3 Grind Settings:** Choose between Coarse, Medium, or Fine depending on your brewing method.
- **Cord Length:** 25 inches.



Figure 2: Key features of the Mr. Coffee Electric Coffee Grinder.

SETUP

1. Unpacking and Initial Cleaning

Carefully remove all packaging materials. Wash the removable grinding chamber and lid in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the grinder base with a damp cloth.

2. Assembling the Grinder

Place the clean, dry grinding chamber back into the grinder base. Ensure it is securely seated. Place the lid onto the grinding chamber and twist it clockwise until it locks into place. The grinder will not operate unless the lid is properly secured.

3. Filling with Coffee Beans

Open the flip-open lid on the grinding chamber. Fill the chamber with fresh, whole coffee beans. Do not fill past the 'MAX FILL' line indicated on the chamber. Refer to the 'Coffee Measurement Chart' in the Operating section for recommended quantities.



Figure 3: Filling the grinding chamber with coffee beans.

OPERATING INSTRUCTIONS

1. Select Cup Quantity

Plug the grinder into a standard electrical outlet. Use the 'Cups' arrow buttons (up/down) to select the desired number of cups (4, 6, 8, 10, or 12). The corresponding LED indicator will illuminate.

2. Select Grind Setting

Use the 'Grind' arrow buttons (up/down) to select your preferred grind setting: Fine, Medium, or Coarse. The corresponding LED indicator will illuminate.





Figure 4: Adjusting cup quantity and grind settings.

3. Start Grinding

Press and hold the 'Grind' button located on the top of the lid. The grinder will begin operation. Release the button to stop grinding manually, or allow the automatic shut-off timer to complete the cycle based on your selected settings.

Coffee Measurement Chart

To Brew	Ground Coffee (Tbsp.)
12 Cups	9 Tbsp.
10 Cups	7.5 Tbsp.
8 Cups	6.5 Tbsp.
6 Cups	4.5 Tbsp.
4 Cups	3 Tbsp.

Note: 1 level tablespoon (Tbsp.) = 5 gr. / 0.17 oz. Use more or less coffee to suit your taste.



Figure 5: Freshly ground coffee from the grinder.

MAINTENANCE AND CLEANING

1. Cleaning the Grinding Chamber

After each use, unplug the grinder. Remove the lid and then twist the grinding chamber counter-clockwise to remove it from the base. Empty any remaining ground coffee. The removable grinding chamber can be washed in warm, soapy water or placed on the top rack of a dishwasher. The Chamber Maid Cleaning System helps dislodge grounds from the chamber walls during removal.

2. Cleaning the Lid and Base

Wipe the lid with a damp cloth. The grinder base should only be wiped with a damp cloth; never immerse the base in water or any other liquid.

3. Storage

Ensure all parts are completely dry before reassembling and storing the grinder. The power cord can be wrapped around the base for compact storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder does not turn on.	Not plugged in.	Ensure the power cord is securely plugged into a working outlet.
	Lid not properly secured.	Ensure the lid is twisted clockwise until it locks into place. The safety interlock prevents operation if the lid is open.
	Grinding chamber not properly seated.	Ensure the removable grinding chamber is correctly placed and locked into the base.
Inconsistent grind.	Overfilling the chamber.	Do not fill coffee beans past the 'MAX FILL' line.
	Insufficient grinding time.	Allow the grinder to run for the full automatic cycle or hold the button longer for a finer grind.
Grounds stick to chamber walls.	Static electricity or coffee oils.	Utilize the Chamber Maid Cleaning System by twisting the chamber after grinding. Clean the chamber regularly.

SPECIFICATIONS

Feature	Detail
Model Number	IDS77
Brand	Mr. Coffee
Color	Black
Style	3 Grind Settings
Product Dimensions	5"L x 4"W x 9"H
Recommended Uses	Grinding coffee beans and spices
Power	120VAC, 60Hz, 170W
Material	Plastic
Item Weight	0.01 ounces

WARRANTY AND SUPPORT

Limited Warranty

This Mr. Coffee IDS77 Electric Coffee Grinder comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal household use. It does not cover damage resulting from misuse, accident, alteration, or commercial use.

Customer Support

For warranty claims, technical assistance, or product inquiries, please contact Mr. Coffee Customer Service. Contact information can typically be found on the official Mr. Coffee website or on the product

packaging.