

Manuals.plus /

› TV Guide /

› TV Guide Presents Classic Television DVD Set Instruction Manual

TV Guide B000BUNE4I

TV Guide Presents Classic Television DVD Set

Instruction Manual

1. INTRODUCTION

This manual provides essential information for enjoying your *TV Guide Presents Classic Television* DVD set. This collection features 30 episodes across 5 DVDs, showcasing a variety of classic genres including Sci-Fi, Detectives, Comedies, and Westerns. The content is digitally remastered and sound enhanced for an optimal viewing experience.




Image 1.1: Front cover of the *TV Guide Presents Classic Television* DVD set. The cover displays the TV Guide logo, the title, and images of various classic television stars, indicating 30 episodes on 5 DVDs, and highlights genres like Classic

2. CONTENTS OF THE DVD SET

Your *TV Guide Presents Classic Television* DVD set includes:

- 5 DVDs containing a total of 30 classic television episodes.
- Episodes spanning various genres: Classic Sci-Fi, Classic Detectives, Classic Television (general), Classic Comedies, and Classic Westerns.
- Interactive trivia from the editors of TV Guide.

The set also includes specific shows such as *The Lucy Show* and *Bonanza*, with over 6 hours of content on 3 DVDs for the '60s Greatest Shows compilation.

3. VIEWING INSTRUCTIONS

To play the DVDs in this set, follow these general steps:

1. **Insert DVD:** Gently place one of the DVDs into your DVD player or computer's DVD drive with the label side facing up.
2. **Power On:** Ensure your DVD player and television (or computer) are powered on.
3. **Select Input:** Use your television remote to select the correct input source (e.g., HDMI 1, Video 1) that corresponds to your DVD player.
4. **Menu Navigation:** Once the DVD loads, a main menu should appear. Use your DVD player's remote control (or computer's mouse/keyboard) to navigate through the menu options.
5. **Select Episode:** Choose the desired episode or feature from the menu.
6. **Play:** Press the 'Play' button to begin viewing.

Refer to your specific DVD player's instruction manual for detailed operation if you encounter difficulties.

4. SPECIAL FEATURES

This DVD set includes special interactive trivia content from the editors of TV Guide. To access this feature:

- Navigate to the main menu of the relevant DVD.
- Look for an option labeled 'Trivia' or 'Special Features'.
- Select this option to engage with the trivia content.

5. CARE AND HANDLING OF DVDs

Proper care ensures the longevity and optimal performance of your DVDs:

- **Storage:** Store DVDs in their original cases, away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Always hold DVDs by the edges or the center hole to avoid touching the playing surface.
- **Cleaning:** If a DVD becomes dirty, gently wipe the playing surface with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh chemicals.

- **Avoid Scratches:** Prevent scratches by keeping DVDs away from rough surfaces and sharp objects.

6. TROUBLESHOOTING

If you experience issues while playing your DVDs, consider the following:

- **Disc Not Playing/Skipping:**
 - Check the disc for visible smudges or scratches. Clean the disc as described in Section 5.
 - Ensure the disc is inserted correctly into the DVD player.
 - Try playing another DVD to determine if the issue is with the disc or the player.
- **No Audio/Video:**
 - Verify all cables connecting your DVD player to your television or audio system are securely connected.
 - Ensure your television is set to the correct input source.
 - Check the volume level on both your television and audio system.
- **Menu Navigation Issues:**
 - Ensure your DVD player's remote control has fresh batteries.
 - Point the remote directly at the DVD player's sensor.

If problems persist, consult your DVD player's manual or contact the manufacturer of your DVD player.

7. SPECIFICATIONS

Feature	Detail
Product Title	TV Guide Presents Classic Television
ASIN (Model)	B000BUNE4I
Media Format	DVD, Black & White, Box set
Number of Discs	5
Total Episodes	30
Studio	Genius Entertainment
Package Dimensions	7.7 x 6.5 x 1.5 inches
Item Weight	15.2 ounces

8. WARRANTY AND SUPPORT

For issues related to the physical quality of the discs or packaging, please refer to the retailer's return policy where the product was purchased. As this is a media product, specific manufacturer warranties typically cover defects in manufacturing for a limited period.

For general inquiries or support regarding the content, please contact the publisher, Genius Entertainment, or refer to their official website for contact information.

