



Manuals.plus /

- › Standard Motor Products /
- › Standard Motor Products CP1050 Fuel Vapor Canister Instruction Manual

Standard Motor Products CP1050

Standard Motor Products CP1050 Fuel Vapor Canister Instruction Manual

Model: CP1050 | Brand: Standard Motor Products

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Standard Motor Products CP1050 Fuel Vapor Canister. Please read this manual thoroughly before proceeding with any procedures to ensure safe and correct usage.

SAFETY INFORMATION

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling automotive components.
- Ensure the vehicle's engine is off and cooled down before beginning any installation or maintenance.
- Disconnect the vehicle's battery to prevent accidental electrical shorts or activation of systems.
- Work in a well-ventilated area to avoid inhaling fuel vapors.
- Refer to the vehicle's service manual for specific instructions related to your vehicle model.

PACKAGE CONTENTS

- 1 x Standard Motor Products CP1050 Fuel Vapor Canister

PRODUCT OVERVIEW

The Standard Motor Products CP1050 is a fuel vapor canister designed to capture and store fuel vapors from the vehicle's fuel tank. This component is crucial for the Evaporative Emission Control (EVAP) system, preventing harmful gasoline vapors from escaping into the atmosphere. It features a durable construction suitable for vehicle-specific applications.




Image: A black rectangular fuel vapor canister with two connection ports visible on one end. This component is integral to a vehicle's emission control system.

SETUP AND INSTALLATION

Installation of the fuel vapor canister typically involves replacing an existing unit. Professional installation is recommended due to the complexity of vehicle emission systems.

1. **Preparation:** Park the vehicle on a level surface, engage the parking brake, and turn off the engine. Allow the engine to cool. Disconnect the negative terminal of the battery.
2. **Locate Canister:** Identify the location of the existing fuel vapor canister. This is often found near the fuel tank or in the engine bay, depending on the vehicle model.
3. **Disconnect Hoses and Electrical Connectors:** Carefully disconnect all vacuum hoses and electrical connectors attached to the old canister. Note their positions for correct reinstallation.
4. **Remove Old Canister:** Unbolt or unclip the old canister from its mounting bracket.
5. **Install New Canister:** Position the new Standard Motor Products CP1050 canister in the mounting bracket and secure it.
6. **Reconnect Hoses and Electrical Connectors:** Reattach all vacuum hoses and electrical connectors to their correct ports on the new canister. Ensure all connections are secure and free from leaks.
7. **Final Steps:** Reconnect the vehicle's battery. Start the engine and check for any diagnostic trouble codes (DTCs) or unusual odors.

OPERATING PRINCIPLES

The fuel vapor canister operates as part of the EVAP system. When the engine is off, fuel vapors from the tank are absorbed by activated charcoal within the canister. During engine operation, particularly under specific conditions (e.g., cruising), the engine's vacuum system purges these stored vapors into the engine's intake manifold, where they are burned as part of the combustion process. This prevents the release of raw fuel vapors into the atmosphere, contributing to reduced emissions.

MAINTENANCE

Fuel vapor canisters are generally designed to be maintenance-free and are replaced only when they fail. However, regular inspection of the EVAP system components can help identify potential issues.

- **Visual Inspection:** Periodically inspect the canister and its connecting hoses for cracks, damage, or loose connections.
- **Check for Leaks:** Look for any signs of fuel leakage around the canister or hoses.
- **Diagnostic Codes:** If your vehicle's 'Check Engine' light illuminates with an EVAP system code, it may indicate a canister issue. Consult a qualified technician for diagnosis.

TROUBLESHOOTING

Common issues related to a faulty fuel vapor canister and potential solutions:

Symptom	Possible Cause	Solution
"Check Engine" light with EVAP code	Clogged or saturated canister, faulty purge valve, or leak in EVAP system.	Inspect canister and hoses. Test purge valve. Replace canister if saturated or damaged.
Strong fuel odor	Canister overflow, cracked canister, or loose hose connections.	Check for visible damage or leaks. Ensure fuel tank is not overfilled. Replace canister if damaged.
Difficulty refueling	Restricted EVAP system, often due to a clogged canister.	Inspect canister and vent valve. Replacement of the canister may be necessary.

SPECIFICATIONS

Feature	Detail
Model Number	CP1050
Brand	Standard Motor Products
Fuel Type Compatibility	Gasoline
Fit Type	Vehicle Specific
Item Weight	1.5 pounds
Product Dimensions (L x W x H)	15.75 x 6.25 x 7.75 inches
Material	Alloy Steel, Aluminum, Metal, Stainless Steel
Manufacturer Part Number	CP1050
UPC	091769264178

WARRANTY INFORMATION

Standard Motor Products typically offers a limited warranty on its automotive parts. For specific warranty terms and conditions applicable to your CP1050 Fuel Vapor Canister, please refer to the warranty documentation included with your purchase or visit the official Standard Motor Products website. Keep your proof of purchase for warranty claims.

SUPPORT

For technical assistance, installation questions, or warranty inquiries, please contact Standard Motor Products customer support. You can typically find contact information on their official website or through your authorized retailer.

Note: Always consult a certified automotive technician for complex repairs or if you are unsure about any installation or diagnostic procedures.