

Standard Motor Products LS237

Standard Motor Products LS237 Neutral/Backup Switch
Instruction Manual

Model: LS237

1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the Standard Motor Products LS237 Neutral/Backup Switch. Please read this manual thoroughly before proceeding with any installation or service to ensure safe and correct usage.

2. SAFETY INFORMATION

WARNING:

- Always disconnect the vehicle's battery before performing any electrical work to prevent electrical shock or damage to the vehicle's electrical system.
- Wear appropriate personal protective equipment, including safety glasses and gloves.
- Improper installation can lead to vehicle malfunction, injury, or property damage. If you are unsure about any step, consult a qualified automotive technician.
- Ensure all connections are secure and properly insulated to prevent short circuits.
- This product is designed for specific vehicle applications. Verify compatibility before installation.

3. PRODUCT OVERVIEW

The Standard Motor Products LS237 is a Neutral/Backup Switch designed for automotive applications. It functions as an ON-OFF switch with a Normally Open contact type, typically used to control backup lights or as part of a neutral safety interlock system. The switch features a threaded body for secure mounting and two electrical terminals for connection.




Figure 1: Standard Motor Products LS237 Neutral/Backup Switch. This black and white image displays the switch with a threaded metal body, a plunger at one end, and two electrical terminals with wires protected by a woven sleeve at the other end.

4. SETUP AND INSTALLATION

Installation of the LS237 Neutral/Backup Switch requires specific automotive knowledge and tools. It is highly recommended that installation be performed by a certified automotive technician.

General Installation Steps (Consult Vehicle Service Manual for Specifics):

1. **Preparation:** Park the vehicle on a level surface, engage the parking brake, and disconnect the negative terminal of the battery.
2. **Locate Existing Switch:** Identify the location of the existing neutral/backup switch on your vehicle. This is typically found on the transmission or shifter assembly.
3. **Remove Old Switch:** Carefully disconnect the electrical connector from the old switch. Use an appropriate wrench to unscrew and remove the old switch. Be prepared for potential fluid leakage if the switch is installed in a transmission housing.
4. **Install New Switch:** Apply thread sealant (if recommended by vehicle manufacturer) to the threads of the new

LS237 switch. Screw the new switch into place and tighten to the vehicle manufacturer's specified torque.

5. **Connect Wiring:** Reconnect the electrical connector to the new switch, ensuring a secure connection.
6. **Test Functionality:** Reconnect the vehicle's battery. Test the functionality of the neutral safety interlock (if applicable) and the backup lights to ensure the switch is operating correctly.

Refer to your vehicle's specific service manual for detailed instructions and torque specifications.

5. OPERATING INSTRUCTIONS

The Standard Motor Products LS237 Neutral/Backup Switch operates automatically as part of your vehicle's electrical system. Its primary functions include:

- **Neutral Safety:** In vehicles equipped with this feature, the switch prevents the engine from starting unless the transmission is in Park or Neutral. This is a critical safety mechanism.
- **Backup Lights:** The switch activates the vehicle's backup lights when the transmission is shifted into Reverse, signaling to others that the vehicle is backing up.

No direct user interaction is required for the operation of this switch once correctly installed.

6. MAINTENANCE

The LS237 Neutral/Backup Switch is designed for long-term, maintenance-free operation under normal conditions. Regular maintenance is generally not required for the switch itself. However, it is advisable to:

- Periodically inspect the electrical connections for corrosion or damage.
- Ensure the wiring harness leading to the switch is free from chafing or excessive tension.
- If the switch is exposed to harsh environmental conditions, occasional cleaning of external surfaces may be beneficial, ensuring no liquids enter the electrical connections.

7. TROUBLESHOOTING

If you experience issues related to the neutral safety function or backup lights, the LS237 switch may be a potential cause. Here are some common troubleshooting steps:

- **Engine Does Not Start in Park/Neutral:**
 - Check battery charge and connections.
 - Verify the transmission is fully engaged in Park or Neutral.
 - Inspect the switch wiring for loose connections or damage.
 - Test the switch continuity with a multimeter (consult a service manual for correct pinout and values).
- **Backup Lights Not Working:**
 - Check backup light bulbs for failure.
 - Inspect the fuse for the backup light circuit.
 - Verify the transmission is fully engaged in Reverse.
 - Inspect the switch wiring for loose connections or damage.
 - Test the switch continuity when in Reverse.

If troubleshooting does not resolve the issue, professional diagnosis and repair are recommended.

8. SPECIFICATIONS

Feature	Specification
Model Number	LS237
Brand	Standard Motor Products
Operation Mode	ON-OFF
Current Rating	20 Amps
Operating Voltage	5 Volts
Contact Type	Normally Open
Connector Type	Crimp
Terminal Type	Screw
Material	Metal
Product Dimensions (L x W x H)	2.16 x 1.94 x 4.13 inches
Item Weight	0.32 ounces
UPC	091769179649

9. WARRANTY AND SUPPORT

Standard Motor Products stands behind the quality of its products. For specific warranty information, please refer to the warranty documentation included with your purchase or visit the official Standard Motor Products website. For technical support, installation assistance, or warranty claims, please contact Standard Motor Products customer service through their official channels. When contacting support, please have your product model number (LS237) and purchase details available.

Manufacturer: Standard Motor Products

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000C81J7S>

More documents and user manuals: <https://manuals.plus/>