Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ACDelco 334-2212

ACDelco Gold 334-2212 Remanufactured Alternator Instruction Manual

Your guide to installation, operation, and maintenance.

1. Product Overview

The ACDelco Gold 334-2212 Remanufactured Alternator is designed as a high-quality replacement component for various vehicles. This alternator undergoes a rigorous remanufacturing process, which includes disassembling existing units, replacing worn components with new ones, and electronically testing rotors and stators. These parts are then sealed with a secondary insulating coating to prevent electrical shorts. The unit incorporates high-quality bearings with high-temperature lubricant and double-lipped rubber seals to minimize friction, vibration, and noise. Each remanufactured alternator is performance-tested to ensure it meets ACDelco's specifications for durability and service life.



Figure 1: Front view of the ACDelco Gold 334-2212 Remanufactured Alternator, showing the pulley and main housing.

2. Key Features

- **Remanufactured Quality:** Utilizes consistent quality processes, ensuring components are not merely rebuilt but restored to specified performance standards.
- **Enhanced Durability:** Features high-quality bearings with high-temperature lubricant and double-lipped rubber seals to reduce friction, vibration, and noise.
- **Electrical Integrity:** Rotors and stators are electronically tested and sealed with a secondary insulating coating to prevent electrical shorts.
- **Performance Tested:** Each unit is performance-tested and inspected to meet expectations for quality design and component specifications.

3. What's in the Box

Upon opening the product packaging, you should find the following item:

- One (1) ACDelco Gold 334-2212 Remanufactured Alternator

4. Specifications

Specification	Detail
Brand	ACDelco
Model	Reman Alternator (Chrysler If 60 Amps)
Item Model Number	334-2212
Manufacturer Part Number	334-2212
OEM Part Number	19135770
Item Weight	13.27 pounds
Product Dimensions	8.1 x 7.6 x 7 inches
Exterior Finish	Machined

5. Setup and Installation

Installation of an automotive alternator requires specific tools, technical knowledge, and adherence to safety procedures. It is highly recommended that installation be performed by a qualified automotive technician.

5.1 Safety Precautions

- Always disconnect the vehicle's battery terminals (negative first) before beginning any work on the electrical system.
- Ensure the vehicle is on a stable, level surface and properly supported if lifted.
- Wear appropriate personal protective equipment, including safety glasses and gloves.
- Refer to your vehicle's specific service manual for detailed removal and installation instructions.

5.2 General Installation Steps (Consult Vehicle Manual for Specifics)

1. **Disconnect Battery:** Disconnect the negative (-) battery cable, then the positive (+) cable.
2. **Access Alternator:** Locate the alternator and identify any components that need to be removed for access (e.g., belts, hoses, brackets).
3. **Remove Drive Belt:** Loosen the tensioner and remove the serpentine or V-belt from the alternator pulley.
4. **Disconnect Wiring:** Carefully disconnect all electrical connections from the old alternator (main power wire, regulator wires). Note their positions for reinstallation.
5. **Remove Mounting Bolts:** Unbolt the old alternator from its mounting brackets.
6. **Install New Alternator:** Position the new ACDelco Gold 334-2212 Alternator into place and secure it with the mounting bolts. Do not overtighten.

7. **Reconnect Wiring:** Reconnect all electrical connections securely. Ensure proper polarity for the main power wire.
8. **Reinstall Drive Belt:** Route the drive belt correctly around all pulleys and tension it to the manufacturer's specifications.
9. **Reconnect Battery:** Reconnect the positive (+) battery cable, then the negative (-) cable.
10. **Test System:** Start the vehicle and check the charging system voltage with a multimeter. It should typically be between 13.5V and 14.8V.




Figure 2: Rear view, highlighting electrical connection points.




Figure 3: Side view, illustrating the mounting bracket and overall profile.

6. Operation

The alternator is a crucial component of your vehicle's electrical system. Its primary function is to generate electrical power to operate the vehicle's electrical components (lights, radio, air conditioning, etc.) and to recharge the vehicle's battery while the engine is running. When the engine starts, the serpentine belt drives the alternator pulley, which in turn spins the internal rotor. This rotation creates a magnetic field that induces an alternating current (AC) in the stator windings. A rectifier then converts this AC into direct current (DC), which is regulated by the voltage regulator to maintain a stable output voltage, typically around 13.5 to 14.8 volts, suitable for the vehicle's electrical system and battery charging.

7. Maintenance

While the ACDelco Gold 334-2212 Remanufactured Alternator is designed for long-term reliability, periodic checks of related components can help ensure optimal performance and longevity of your vehicle's charging system.

- **Belt Inspection:** Regularly inspect the serpentine belt for cracks, fraying, or excessive wear. Ensure it is properly tensioned according to your vehicle's specifications. A loose or worn belt can lead to insufficient charging.
- **Battery Health:** Maintain your vehicle's battery. A weak or failing battery can put additional strain on the alternator.
- **Wiring Connections:** Periodically check all electrical connections to the alternator for corrosion or looseness. Clean any corrosion with a wire brush and battery terminal cleaner.
- **Avoid Overloading:** Minimize the use of excessive electrical accessories when the engine is at low RPMs, as this can strain the charging system.

8. Troubleshooting

If you experience issues with your vehicle's charging system after installing the alternator, consider the following common troubleshooting steps. Always consult a qualified technician for diagnosis and repair.

8.1 Common Symptoms and Potential Causes

- **Battery Warning Light On:** This typically indicates a problem with the charging system. It could be a faulty alternator, a loose or broken serpentine belt, or wiring issues.
- **Dim Headlights or Interior Lights:** Insufficient power generation from the alternator can lead to dimming lights, especially at idle.
- **Battery Not Charging:** If the battery consistently drains or fails to hold a charge, the alternator may not be producing enough voltage or current.
- **Unusual Noises:** Whining, grinding, or squealing noises from the alternator area can indicate worn bearings, a loose pulley, or a failing drive belt.

8.2 Diagnostic Steps

1. **Check Belt:** Ensure the serpentine belt is properly installed, tensioned, and in good condition.
2. **Inspect Wiring:** Verify all electrical connections to the alternator are clean, tight, and free of corrosion.
3. **Battery Test:** Have your battery tested to ensure it is capable of holding a charge.
4. **Voltage Output Test:** With the engine running, use a multimeter to measure the voltage across the battery terminals. A healthy charging system should show approximately 13.5V to 14.8V. If it's significantly lower or higher, the alternator or voltage regulator may be faulty.

9. Warranty and Support

This ACDelco Gold 334-2212 Remanufactured Alternator is typically backed by a return policy that allows for refund or replacement within 365 days, when purchased through authorized channels like Amazon. For specific warranty details, claims, or technical support, please refer to the documentation provided with your purchase or contact ACDelco customer service directly.
For further assistance, you may visit the official ACDelco website or consult an authorized service center.

© 2025 ACDelco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000C9LP3A

More documents and user manuals: **https://manuals.plus/**