

[Manuals.plus](#) /

› [SYLVANIA](#) /

› SYLVANIA 5008 Basic Miniature Bulb Instruction Manual

SYLVANIA 5008

SYLVANIA 5008 Basic Miniature Bulb Instruction Manual

1. PRODUCT OVERVIEW

The SYLVANIA 5008 Basic Miniature Bulb is engineered to meet industry standards for performance and longevity in various automotive applications. These bulbs are designed for durability, reduced maintenance, and enhanced safety.






Image 1: Front view of the SYLVANIA 5008 Basic Miniature Bulb, showing the clear glass envelope and metal base.

Key Features:

- Constructed from high-quality materials for long-lasting durability.
- Manufactured by a trusted Original Equipment Manufacturer (OEM) light source supplier.
- Designed for straightforward installation as a direct replacement bulb.
- Approved for on-road use.
- For optimal performance, replace bulbs in pairs as light output diminishes over time.

2. IMPORTANT SAFETY INFORMATION

- Always ensure the vehicle's ignition is off and the lighting circuit is de-energized before attempting installation or removal of bulbs.
- Allow bulbs to cool completely before handling to prevent burns.
- Avoid touching the glass portion of the bulb directly with bare hands. Oils from skin can create hot spots and reduce bulb life. Use gloves or a clean cloth.
- Dispose of old bulbs responsibly according to local regulations.
- If a bulb breaks, carefully clean up glass fragments.

- Keep bulbs out of reach of children.

3. INSTALLATION INSTRUCTIONS

General Installation Guidelines:

The SYLVANIA 5008 bulb is designed for direct replacement in compatible automotive applications. Refer to your vehicle's owner's manual for specific instructions on accessing and replacing bulbs in your particular make and model.

1. **Identify the Bulb Location:** Consult your vehicle's owner's manual to locate the specific light assembly (e.g., brake light, turn signal, interior light) that uses the 5008 bulb.
2. **Access the Bulb:** Depending on the vehicle and bulb location, you may need to remove a lens cover, trim panel, or access panel.
3. **Remove the Old Bulb:** Carefully twist or pull the old bulb from its socket. Note the orientation if applicable.
4. **Insert the New Bulb:** Align the base of the new SYLVANIA 5008 bulb with the socket. Gently push and/or twist until it is securely seated. Ensure a firm connection.
5. **Test Functionality:** Before reassembling, test the light function to ensure the new bulb is working correctly.
6. **Reassemble:** Securely reattach any covers, panels, or lenses removed during the process.





Image 2: Side view of the SYLVANIA 5008 bulb, highlighting the metal base and contact points for proper insertion into a socket.

4. OPERATION

Basic Functionality:

Once properly installed, the SYLVANIA 5008 Basic Miniature Bulb operates as part of your vehicle's electrical system. It will illuminate when the corresponding circuit is activated (e.g., turning on headlights, applying brakes, or opening a door for interior lights). The bulb provides consistent light output for its intended application.

5. MAINTENANCE

General Maintenance Tips:

- **Regular Inspection:** Periodically check all exterior and interior lights to ensure they are functioning correctly.
- **Replace in Pairs:** For critical lighting functions like headlights or brake lights, it is recommended to replace bulbs in pairs. This ensures balanced light output and consistent visibility, as bulbs dim over time.
- **Clean Lenses:** Keep light assembly lenses clean from dirt and debris to maximize light output.

6. TROUBLESHOOTING

Common Issues and Solutions:

Issue	Possible Cause	Solution
Bulb does not illuminate	• Improper installation • Blown fuse • Faulty wiring/socket • Defective bulb	• Re-seat the bulb firmly in the socket. • Check and replace any blown fuses in the vehicle's fuse box. • Inspect wiring and socket for corrosion or damage. Consult a professional if necessary. • Replace the bulb with a new one.
Bulb flickers or is dim	• Loose connection • Corroded socket • Aging bulb	• Ensure the bulb is securely seated. • Clean any corrosion from the socket contacts. • Replace the bulb, preferably in pairs for consistent brightness.

7. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	SYLVANIA
Model Number	5008
Wattage	10 watts
UPC	046135393938
Manufacturer Part Number	5008.TP

8. WARRANTY AND CUSTOMER SUPPORT

For specific warranty information regarding your SYLVANIA 5008 Basic Miniature Bulb, please refer to the packaging or the official SYLVANIA website. For technical assistance or customer support, please visit the [SYLVANIA Store on Amazon](#) or contact SYLVANIA customer service directly.

9. ADDITIONAL RESOURCES

A detailed User Guide in PDF format is available for download:

[Download User Guide \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question