

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [IBM](#) /

› [IBM 25P4726 Jazz Infinity 2 PC Speaker System User Manual](#)

## IBM 25P4726

# IBM 25P4726 Jazz Infinity 2 PC Speaker System User Manual

Model: 25P4726

## INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your IBM 25P4726 Jazz Infinity 2 PC Speaker System. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

The IBM 25P4726 is an active multimedia speaker system designed for use with desktop and laptop computers, providing stereo audio output. Please note that an AC adapter is not included with this specific model and must be acquired separately if required for power.

## PACKAGE CONTENTS

Verify that your package contains the following items:

- Two (2) IBM Jazz Infinity 2 Satellite Speakers
- One (1) IBM Jazz Infinity 2 Subwoofer Unit (as depicted in product imagery)
- Integrated USB cable for connectivity
- Integrated audio cable (3.5mm jack)
- *Note: An AC power adapter is not included with this model (25P4726) and must be supplied by the user.*

## PRODUCT OVERVIEW



**Image 1:** The IBM Jazz Infinity 2 PC Speaker System, featuring two black satellite speakers and a central subwoofer unit.

The right satellite speaker includes volume and power controls. The subwoofer unit displays its main driver and port.

The IBM Jazz Infinity 2 PC Speaker System is designed to deliver enhanced audio for your computer. It typically consists of two satellite speakers and a central subwoofer unit. The satellite speakers provide stereo sound, while the subwoofer enhances bass frequencies. Controls for power and volume are located on one of the satellite speakers.

## SETUP INSTRUCTIONS

- Positioning Speakers:** Place the two satellite speakers on either side of your computer monitor for optimal stereo separation. Ensure the subwoofer unit is placed on a stable surface, preferably on the floor near your computer, to maximize bass response.
- Connect Satellite Speakers to Subwoofer:** Connect the cables from the satellite speakers to the corresponding input ports on the subwoofer unit. These connections are typically color-coded or clearly labeled.
- Connect to Computer:**
  - Audio Connection:** Plug the 3.5mm audio jack from the speaker system into the audio output (headphone or line-out) port on your computer.
  - USB Connection:** Plug the USB cable from the speaker system into an available USB port on your computer. This connection is typically for power and/or digital audio signal.
- Power Connection:** Connect an appropriate AC power adapter (*not included with model 25P4726*) to the power input port on the speaker system, then plug the adapter into a standard electrical outlet.
- Power On:** Locate the power button on one of the satellite speakers and press it to turn on the system. The power indicator light should illuminate.

## OPERATING INSTRUCTIONS

- Power On/Off:** Press the power button, usually located on the right satellite speaker, to turn the speakers

on or off. A green LED indicator typically shows the power status.

- **Volume Control:** Rotate the volume knob, also on the right satellite speaker, clockwise to increase volume and counter-clockwise to decrease volume.
- **Audio Playback:** Once connected and powered on, your computer's audio output should automatically route through the speakers. Adjust the volume on both your computer and the speakers for desired sound levels.

## Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Keep cables tidy and untangled to prevent damage and ensure a stable connection.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place.

## Troubleshooting

Problem	Possible Solution
No sound from speakers	<ul style="list-style-type: none"><li>◦ Ensure speakers are powered on (green LED illuminated).</li><li>◦ Check all cable connections (audio jack, USB, power adapter).</li><li>◦ Verify the AC power adapter is correctly connected and functional.</li><li>◦ Increase speaker volume and computer volume.</li><li>◦ Check computer's audio output settings to ensure speakers are selected as the default device.</li></ul>
Distorted or poor sound quality	<ul style="list-style-type: none"><li>◦ Reduce volume on both speakers and computer.</li><li>◦ Ensure audio cables are fully inserted and not damaged.</li><li>◦ Test with another audio source if possible.</li><li>◦ Check for interference from other electronic devices.</li></ul>
Speakers not recognized by computer	<ul style="list-style-type: none"><li>◦ Reconnect the USB cable to a different USB port.</li><li>◦ Restart your computer.</li><li>◦ Check device manager for driver issues (Windows) or System Information (macOS).</li></ul>

## Specifications



- **Model:** IBM 25P4726 Jazz Infinity 2
- **Speaker Type:** Multimedia
- **Audio Output Mode:** Stereo (2.0 Channel Configuration)
- **Connectivity Technology:** USB
- **Power Source:** Corded Electric (Requires external AC adapter, not included)
- **Compatible Devices:** Desktop, Laptop
- **Recommended Uses:** For Computers, Personal Audio
- **Control Method:** Rotary Volume Knob, Push-button Power


- **Color:** Black
- **Included Components:** 2 Satellite Speakers (as part of a 2.1 system)
- **Item Weight:** Approximately 2 Pounds (for the entire system)
- **Mounting Type:** Tabletop Mount
- **Audio Driver Type:** Dynamic Driver
- **Waterproof:** No

## WARRANTY AND SUPPORT

This product comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the documentation provided at the time of purchase or contact IBM customer support. For technical support or service inquiries, please visit the official IBM support website or contact their customer service department. Contact information may vary by region.

## Related Documents - 25P4726

	<p><a href="#"><u>IBM 3270 Information Display System: 3274 Control Unit Description and Programmer's Guide</u></a></p> <p>A comprehensive technical manual detailing the IBM 3270 Information Display System, with a specific focus on the IBM 3274 Control Unit. It covers functional and programming aspects, data streams, operations, and integration within IBM environments.</p>
	<p><a href="#"><u>TIME-LIFE Step-by-Step Guide to the IBM PCjr</u></a></p> <p>A comprehensive, step-by-step guide to the IBM PCjr personal computer, covering hardware setup, system components, the DOS operating system, BASIC programming, educational and entertainment software, productivity applications like word processing and spreadsheets, and computer communications. It provides detailed instructions, examples, and tips for users of all levels.</p>
	<p><a href="#"><u>IBM 1130 Disk Monitor System, Version 2: Programmer's and Operator's Guide</u></a></p> <p>A comprehensive technical manual detailing the IBM 1130 Disk Monitor System, Version 2. This guide covers system configuration, programming techniques, operating procedures, and utility programs for the IBM 1130 computing system, intended for programmers and operators.</p>
	<p><a href="#"><u>IBM 7094 Model 2 Installation &amp; Testing Guide for Customer Engineers</u></a></p> <p>Official installation and testing manual for the IBM 7094 Model 2 Data Processing System. Covers CE procedures, cabling, system setup, safety, and diagnostics for this vintage computer.</p>

	<p><b><a href="#">IBM Personal Computer AT Technical Reference Manual</a></b></p> <p>Comprehensive technical reference guide for the IBM Personal Computer AT, detailing hardware specifications, system board, BIOS, keyboard, coprocessor, and power supply.</p>