

[Manuals.plus](#) /

› [Standard Motor Products](#) /

› Standard Motor Products DS313 Toggle Switch User Manual

Standard Motor Products DS313

Standard Motor Products DS313 Toggle Switch User Manual

Model: DS313

Brand: Standard Motor Products

1. INTRODUCTION

The Standard Motor Products DS313 Toggle Switch is a robust electrical component designed for various automotive and general electrical applications. This manual provides essential information for proper installation, safe operation, and basic maintenance to ensure the longevity and reliable performance of your toggle switch.

Key features include:

- Panel Mount design for secure installation.
- Quick Connect terminals for easy wiring.
- Durable Metal construction with Copper Alloy contacts.

2. PRODUCT OVERVIEW



Image: Standard Motor Products DS313 Toggle Switch. This image displays the red-colored toggle lever, the threaded mounting collar, and the three copper quick-connect terminals at the base of the switch body. The switch body itself appears to be made of a translucent red material, allowing some internal components to be seen.

3. INSTALLATION AND SETUP

3.1 Safety Precautions

- Always disconnect power to the circuit before installing or servicing the switch.
- Ensure proper insulation and avoid short circuits.
- If you are unsure about any step, consult a qualified electrician or automotive technician.
- Wear appropriate personal protective equipment (PPE) such as safety glasses.

3.2 Mounting Instructions

1. Select a suitable location for panel mounting. Ensure there is enough space behind the panel for wiring.
2. Drill a hole of appropriate diameter (refer to product dimensions for exact size, typically around 0.5 inches or 12.7mm) in the panel.
3. Insert the threaded portion of the switch through the drilled hole.
4. Secure the switch using the provided nut on the front side of the panel, tightening it firmly but not excessively.

3.3 Wiring

The DS313 Toggle Switch typically features three quick-connect terminals. While specific wiring may vary based on application, a common configuration involves:

- **Power Input:** Connect the positive power source to one of the outer terminals (often marked 'POWER' or '+').
- **Load Output:** Connect the device or circuit you wish to control to the other outer terminal (often marked 'LOAD' or 'ACC').
- **Ground:** Connect the center terminal to a reliable ground point (often marked 'GROUND' or '-'). This terminal is typically for the internal illumination of the switch, if present.

Always refer to your specific application's wiring diagram or consult a professional for complex installations.

4. OPERATION

The Standard Motor Products DS313 is a simple ON/OFF toggle switch. To operate:

- Move the toggle lever to one position (e.g., UP) to close the circuit and turn the connected device ON.
- Move the toggle lever to the opposite position (e.g., DOWN) to open the circuit and turn the connected device OFF.

The switch provides a tactile click when changing positions, indicating a positive engagement.

5. MAINTENANCE

The DS313 Toggle Switch is designed for durability and requires minimal maintenance. However, periodic checks can help ensure optimal performance:

- **Cleaning:** If the switch becomes dirty, wipe it with a clean, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Connection Check:** Periodically inspect the wiring connections to ensure they are secure and free from corrosion. Loose connections can lead to intermittent operation or failure.
- **Physical Inspection:** Check the toggle lever and switch body for any signs of physical damage, cracks, or excessive wear.

No internal user-serviceable parts are present. Do not attempt to disassemble the switch.

6. TROUBLESHOOTING

If you experience issues with your DS313 Toggle Switch, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Switch does not activate connected device.	No power to the switch; Incorrect wiring; Faulty device; Blown fuse in circuit.	Verify power supply to the switch; Check all wiring connections for correctness and security; Test the connected device independently; Inspect and replace any blown fuses.
Intermittent operation (device turns on/off randomly).	Loose wiring connections; Corroded terminals; Internal switch fault.	Secure all wiring connections; Clean any corrosion from terminals; If problem persists, the switch may be faulty and require replacement.
Switch lever feels loose or does not stay in position.	Internal mechanical failure.	The switch is likely faulty and needs to be replaced.

If troubleshooting steps do not resolve the issue, the switch may need to be replaced. Always ensure power is disconnected before attempting any repairs or replacements.

7. SPECIFICATIONS

Below are the technical specifications for the Standard Motor Products DS313 Toggle Switch:

Specification	Detail
Model Number	DS313
Brand	Standard Motor Products
Mounting Type	Panel Mount
Material	Metal
Connector Type	Quick Connect
Contact Material	Copper Alloy
Insulation Resistance	100 Megaohms
Operation Mode	Motor, Electrical
Item Weight	0.01 ounces
Product Dimensions	3.58 x 2.39 x 1.46 inches

8. WARRANTY AND SUPPORT

Standard Motor Products stands behind the quality of its products. For specific warranty information, please refer to the warranty documentation included with your purchase or visit the official Standard Motor Products website.

If you require technical assistance, have questions about installation, or need to report a defective product, please contact Standard Motor Products customer support through their official channels. When contacting support, please have your product model number (DS313) and purchase information readily available.

© 2025 Standard Motor Products. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000CPJQOE>

More documents and user manuals: <https://manuals.plus/>