

[Manuals.plus](#) /

› [BANDAI](#) /

› BANDAI Hobby HG #4 Nirvash Spec 2 Model Kit Instruction Manual

BANDAI BAN141039

BANDAI Hobby HG #4 Nirvash Spec 2 Model Kit Instruction Manual

1. PRODUCT OVERVIEW

The BANDAI Hobby HG #4 Nirvash Spec 2 is a highly detailed model kit representing the upgraded LFO version from the "Eureka Seven" series. This kit is designed for assembly and display, featuring articulation for dynamic posing. This model kit includes pre-colored plastic parts, minimizing the need for paint. Assembly does not require glue, but a hobby nipper is necessary to remove parts from the runners cleanly.



Image 1.1: Fully assembled Nirvash Spec 2 model kit. This image displays the model's complete form, showcasing its red, white, and black color scheme with gold accents. The model is standing upright, ready for posing.

2. SAFETY INFORMATION

- This product contains small parts and is not suitable for children under 8 years of age. Adult supervision is recommended during assembly.
- Use a hobby nipper for part removal. Exercise caution to prevent injury.
- Keep plastic bags and other packaging materials away from children to avoid suffocation hazards.
- Ensure proper ventilation if using paints or adhesives (though not required for basic assembly).

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package should contain:

- Multiple plastic runners with model parts.
- Instruction manual (this document).
- Sticker sheet for detail application.
- Rifle weapon accessory.
- Blade weapon accessory.
- Ref Board accessory.
- Display stand for the Ref Board.



Image 3.1: Example of plastic runners containing model parts. This image shows the various plastic frames (runners) from which individual parts are detached for assembly.

4. ASSEMBLY INSTRUCTIONS

Follow the numbered steps in the included pictorial guide for detailed assembly. The general process involves:

1. **Part Preparation:** Carefully remove each part from its runner using a hobby nipper. Trim any excess plastic (nubs) with a hobby knife or file for a clean finish.
2. **Sub-Assembly:** Assemble smaller sections first, such as limbs, head, and torso, as indicated in the manual.
3. **Main Assembly:** Connect the sub-assemblies to form the complete model.
4. **Accessory Assembly:** Assemble the rifle, blade weapon, and Ref Board.
5. **Detailing:** Apply stickers as shown in the manual for enhanced visual detail.



Image 4.1: Illustration of hands assembling a model kit part. This image demonstrates the process of connecting two plastic components, highlighting the snap-fit design.



Image 4.2: Assembled Nirvash Spec 2 model kit alongside its Ref Board accessory. The model is shown standing next to the large, surfboard-like Ref Board, which can be used for dynamic display.

5. OPERATING INSTRUCTIONS (POSING AND DISPLAY)

The Nirvash Spec 2 model features multiple points of articulation, allowing for a wide range of poses. Handle the model with care to avoid damaging joints or parts.

- **Joint Movement:** Gently move joints to achieve desired poses. Avoid excessive force, especially when moving a joint for the first time.
- **Weapon Attachment:** The rifle and blade weapon can be held in the model's hands. Ensure they are securely fitted.
- **Ref Board Display:** The included display stand allows the Nirvash to be posed "riding" the Ref Board, replicating scenes from the "Eureka Seven" series. Attach the model to the stand as per the pictorial guide.

6. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your model kit.

- **Cleaning:** Dust the model regularly with a soft brush or a can of compressed air. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the model away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation.
- **Joint Care:** If joints become loose over time, a small amount of clear nail polish or hobby-grade joint tightener can be applied to the ball joint to restore friction. Allow to dry completely before moving.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Parts do not fit together.	Excess plastic (nubs) remaining on the part; incorrect part orientation.	Carefully trim nubs with a hobby knife. Refer to the manual to ensure correct part orientation.
Joints are too loose.	Wear and tear; manufacturing tolerance.	Apply a thin coat of clear nail polish or hobby-grade joint tightener to the ball joint. Allow to dry.
Stickers do not adhere well.	Dust or oil on the surface; improper application.	Clean the surface before applying. Use tweezers for precise placement and press firmly.
Parts break during assembly.	Excessive force; improper tool use.	Use minimal force. Ensure parts are aligned correctly. For broken parts, hobby cement may be used for repair.

8. SPECIFICATIONS

Brand: BANDAI
Model Name: HG #4 Nirvash Spec 2
Model Number: BAN141039
UPC: 787799442685
Material: Plastic
Color: Multicolor (primarily red, white, black)
Item Dimensions (L x W x H): 7 x 12 x 2 inches (packaging)
Item Weight: 16 ounces
Number of Pieces: 1 (referring to the complete model kit unit)
Included Components: Rifle, Blade Weapon, Ref Board, Display Stand
Assembly: No glue required, pre-colored plastic.
Manufacturer: Bluefin Distribution Toys

9. WARRANTY AND SUPPORT

This product is sold with **No Warranty** as per manufacturer specifications. However, products bearing the official Bluefin Distribution logo are tested and comply with all U.S. consumer product safety regulations and are eligible for consumer support.

For consumer support regarding authentic licensed items from an approved U.S. retailer, please contact Bluefin Distribution Toys directly. Contact information can typically be found on their official website or the product packaging. For general inquiries or additional resources, you may visit the [BANDAI Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question