

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [SCHLAGE](#) /

> [Schlage SP455A3 Kick Down Door Holder Instruction Manual](#)

SCHLAGE 455A3

Schlage SP455A3 Kick Down Door Holder Instruction Manual

Model: 455A3 | Brand: SCHLAGE

1. PRODUCT OVERVIEW

The Schlage SP455A3 Kick Down Door Holder is designed to provide a simple and effective method for holding doors open. Constructed from cast aluminum with a bright brass finish, it features a 4-inch arm and a durable rubber foot for secure engagement with the floor surface. This unit is activated and released with a touch of the foot, offering convenient operation.



Figure 1: Schlage SP455A3 Kick Down Door Holder. This image displays the door holder with its 4-inch arm and rubber foot, presented in a bright brass finish.

Key Features:

- **Simple Operation:** Engage and release the door holder with a foot.
- **Durable Construction:** Made from cast aluminum for longevity.
- **Secure Hold:** Features a rubber bottom to prevent slipping.
- **Optimal Clearance:** Designed for doors with a door-to-floor clearance of 2 inches or less.
- **Finish:** Bright Brass.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Schlage SP455A3 Kick Down Door Holder (1 unit)
- Mounting Hardware (screws)

3. INSTALLATION INSTRUCTIONS

This door holder is designed for door mount installation. Ensure the door-to-floor clearance is 2 inches or

less for proper function.

Tools Required:

- Pencil
- Measuring Tape
- Drill with appropriate drill bit (for pilot holes)
- Screwdriver (Phillips head recommended)

Installation Steps:

1. **Determine Mounting Location:** Position the door holder on the lower edge of the door, ensuring it is within reach for foot operation and that the rubber foot will make firm contact with the floor when engaged. The ideal location allows the door to open to the desired angle.
2. **Check Clearance:** With the door holder temporarily held in place, ensure that the distance from the bottom of the door to the floor is 2 inches or less. This ensures the rubber foot can effectively engage the floor.
3. **Mark Screw Holes:** Using a pencil, mark the locations for the mounting screws through the pre-drilled holes on the door holder base.
4. **Drill Pilot Holes:** Carefully drill pilot holes at the marked locations. Use a drill bit slightly smaller than the screw diameter to prevent wood splitting.
5. **Attach Door Holder:** Align the door holder with the pilot holes and secure it firmly to the door using the provided mounting screws and a screwdriver. Do not overtighten.
6. **Test Operation:** Once installed, test the door holder by pushing down on the arm with your foot to engage it and lifting it to release.

4. OPERATING INSTRUCTIONS

The Schlage SP455A3 Kick Down Door Holder is designed for simple, foot-activated use.

1. **To Engage:** With your foot, gently press down on the top of the door holder's arm until the rubber foot makes firm contact with the floor and the door is held in place.
2. **To Release:** With your foot, gently lift the arm of the door holder upwards. The rubber foot will disengage from the floor, allowing the door to move freely.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your door holder.

- **Cleaning:** Wipe the metal components with a soft, damp cloth to remove dust and grime. Avoid abrasive cleaners that may damage the finish.
- **Rubber Foot Inspection:** Periodically check the rubber foot for wear or damage. A worn rubber foot may reduce the holder's ability to grip the floor. Replacement rubber tips may be available from the manufacturer.
- **Tighten Screws:** If the door holder becomes loose, gently tighten the mounting screws. Do not overtighten.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Door holder does not hold the door securely.	<ul style="list-style-type: none"> • Door-to-floor clearance exceeds 2 inches. • Worn or damaged rubber foot. • Screws are loose. 	<ul style="list-style-type: none"> • Ensure proper door-to-floor clearance. The door holder may not be suitable for doors with larger gaps. • Inspect and replace the rubber foot if necessary. • Tighten mounting screws.
Door holder feels loose on the door.	Mounting screws are loose.	Tighten mounting screws with a screwdriver.

7. SPECIFICATIONS

Attribute	Detail
Brand	SCHLAGE
Model Number	455A3
Mounting Type	Door Mount
Material	Aluminum, Brass, Rubber
Color/Finish	Bright Brass
Arm Length / Size	4 inches (4 in H)
Door-to-Floor Clearance	2 inches or less
Item Weight	2.4 ounces
Product Dimensions	9.43 x 4.26 x 5.95 inches
Included Components	Door holder, Mounting Hardware
Batteries Required	No

8. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your product or visit the official SCHLAGE website. SCHLAGE products are backed by a commitment to quality and durability.

If you require technical assistance or have questions regarding your Schlage SP455A3 Kick Down Door Holder, please contact SCHLAGE customer support. Contact details are typically available on the manufacturer's website or product packaging.