

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Weed Eater](#) /

› [Poulan PP1000E 7-Inch Pro Lawn Edger Attachment User Manual](#)

Weed Eater 952711607

Poulan PP1000E 7-Inch Pro Lawn Edger Attachment User Manual

Model: 952711607

INTRODUCTION

Welcome to the user manual for your Poulan PP1000E 7-Inch Pro Lawn Edger Attachment. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your edger attachment. Please read this manual thoroughly before operation.

This edger attachment is designed to be compatible with Poulan Pro split-shaft trimmers and most major brand trimmers with detachable shafts. It features a 7-inch hardened steel blade and an adjustable cutting depth up to 2 inches.

IMPORTANT SAFETY INFORMATION

Always wear appropriate personal protective equipment (PPE) including eye protection, hearing protection, and sturdy footwear when operating the edger attachment.

Ensure the edger attachment is securely connected to the power head before starting.

Keep hands, feet, and clothing away from the rotating blade.

Operate the edger on stable ground and maintain a firm grip on the trimmer.

Be aware of the Proposition 65 Warning regarding potential chemical exposure.

PRODUCT COMPONENTS

The Poulan PP1000E edger attachment consists of the following key components:

- 7-inch Hardened Steel Blade: For precise cutting of lawn edges.
- Heavy-Duty Gear Box: Ensures durability and reliable performance.
- Large Wheel: Provides stability and easy maneuverability during operation.
- Attachment Shaft: Connects to compatible split-shaft trimmers.
- Barrier Handlebar: Designed to protect against accidental contact with the blade.



Image: The Poulan PP1000E 7-Inch Pro Lawn Edger Attachment, showing the edger head with its blade, gear box, and wheel, connected to the attachment shaft.

SETUP AND ASSEMBLY

The Poulan PP1000E edger attachment is part of the ProLink Rapid Attachment System, designed for quick and easy installation.

Compatibility

This attachment is compatible with:

- Poulan Pro split-shaft trimmers, including models: PR25CD, PR25SD, PR25BC, PR28CD, PR28SD, PR28BCB, PR28PS.

- Most major brand trimmers with detachable shafts.

Installation Steps

1. Ensure your trimmer's engine is off and cool.
2. Locate the attachment point on your trimmer's lower shaft.
3. Align the edger attachment shaft with the trimmer's attachment point.
4. Push the attachment firmly into place until you hear a "click," indicating it is securely locked.
5. Verify the attachment is firmly seated by gently pulling on it.

Note: This product is an edger attachment and does not come with an upper shaft or motor. It requires a compatible power head for operation.

OPERATING INSTRUCTIONS

Starting the Edger

1. Ensure the edger attachment is securely installed on your power head.
2. Start your trimmer's engine according to its specific instructions.
3. Allow the engine to warm up for a few moments.

Adjusting Cutting Depth

The cutting depth of the edger can be adjusted up to 2 inches. Refer to the markings on the edger head for precise depth settings.

Edging Technique

1. Position the edger blade along the edge you wish to trim (e.g., sidewalk, driveway, flower bed).
2. Use the large wheel as a guide to maintain a consistent line.
3. Apply steady, even pressure and move the edger forward slowly.
4. For overgrown areas, multiple passes at shallower depths may be required to achieve a clean edge.
5. Maintain a firm grip on the trimmer and control the direction of the edger.

Tip: Practice on a less visible area first to get accustomed to the edger's operation and depth control.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your edger attachment.

After Each Use

- Clean the blade and the edger head of any grass, dirt, or debris. A stiff brush can be used.
- Inspect the blade for any damage, dullness, or excessive wear.
- Check all fasteners and connections for tightness.

Blade Care

The 7-inch hardened steel blade is designed for durability. If the blade becomes dull or damaged, it should be replaced. Refer to your trimmer's manual or Poulan Pro service information for replacement blade part numbers and instructions.

Storage

When not in use, store the edger attachment in a clean, dry place, away from direct sunlight and extreme temperatures. A shaft cover is provided for storage.

TROUBLESHOOTING

This section addresses common issues you might encounter with your edger attachment.

Problem	Possible Cause	Solution
Edger not cutting effectively	Dull or damaged blade; Incorrect cutting depth; Engine RPM too low.	Inspect and replace blade if necessary; Adjust cutting depth; Ensure trimmer engine is running at optimal RPM.
Attachment not fitting securely	Improper alignment; Debris in connection point; Incompatible trimmer.	Ensure proper alignment and push until it clicks; Clean connection point; Verify trimmer compatibility (refer to "Setup" section).
Edger bogs down during operation	Overgrown material; Too deep cutting depth; Insufficient trimmer power.	Make multiple shallower passes; Reduce cutting depth; Ensure trimmer engine is powerful enough for the task.

SPECIFICATIONS

Model: PP1000E

Item Model Number: 952711607

Blade Size: 7 inches

Maximum Cutting Depth: 2 inches

Product Dimensions: 27.8 x 9.5 x 11.8 inches

Item Weight: 2.38 pounds

Manufacturer: Poulan

Compatibility: Poulan Pro split-shaft trimmers (PR25CD, PR25SD, PR25BC, PR28CD, PR28SD, PR28BCB, PR28PS) and most major brand trimmers with detachable shafts.

WARRANTY INFORMATION

This Poulan Pro edger attachment is backed by a 2-year limited warranty. For specific terms and conditions, please refer to the warranty documentation included with your purchase or contact Poulan customer support.



SUPPORT AND CONTACT

For further assistance, technical support, or warranty claims, please contact Poulan customer service.

You may also find additional resources and information on the official Weed Eater website: [Visit the Weed Eater Store on Amazon.](#)

A User Guide (PDF) is also available for download: [Download User Guide \(PDF\).](#)

Related Documents - 952711607

	<p><u>Weed Eater 1400T Trimmer Operator's Manual - Safety, Assembly, Operation, Maintenance</u></p> <p>Comprehensive operator's manual for the Weed Eater 1400T trimmer, covering safety instructions, assembly, engine information, operation, maintenance, troubleshooting, and parts. Learn how to safely operate and maintain your Weed Eater trimmer.</p>
	<p><u>Weed Eater 96114000406 Rotary Lawn Mower Repair Parts Manual</u></p> <p>This document provides a comprehensive repair parts manual for the Weed Eater 96114000406 Rotary Lawn Mower. It includes detailed diagrams, part numbers, and descriptions for all components, along with warranty information.</p>
	<p><u>Weed Eater Rotary Lawn Mower Model 961140007 Repair Parts Manual and Warranty Information</u></p> <p>Detailed repair parts list and warranty information for the Weed Eater Rotary Lawn Mower, Model 961140007. Includes part numbers, descriptions, and warranty terms.</p>
	<p><u>WEED EATER 2540/2560 Electric Blower Operator's Manual</u></p> <p>Comprehensive operator's manual for the WEED EATER 2540 and 2560 electric blowers, covering safety instructions, specifications, assembly, operation, maintenance, and customer assistance.</p>
	<p><u>Weed Eater 96112011503 Rotary Lawn Mower Repair Parts Manual</u></p> <p>Official repair parts manual for the Weed Eater Model 96112011503 Rotary Lawn Mower. Includes detailed parts diagrams, part numbers, warranty information, and service contact details.</p>
	<p><u>Weed Eater PE550 Instruction Manual - Operation, Safety, and Maintenance Guide</u></p> <p>Comprehensive instruction manual for the Weed Eater PE550 edger, covering safety guidelines, assembly, operation, maintenance, troubleshooting, and warranty information.</p>