

[Manuals.plus](#) /

› [Hasbro](#) /

› E.T. Electronic Furby Instruction Manual

Hasbro B000EO72WQ

E.T. Electronic Furby Instruction Manual

Model: B000EO72WQ

PRODUCT OVERVIEW

The E.T. The Extra Terrestrial Furby Doll, originally released in 2000 by Tiger Electronics, is an interactive electronic pet designed to communicate and respond to its environment. This model is known for its extensive vocabulary and ability to interact with other Furby units.

Key features include:

- Over 400 words in its vocabulary.
- Ability to communicate with other Furbys and Furby Babies.
- Animated eyes and mouth for expressive interaction.
- Glow feature in its finger and heart.



Image: The E.T. Electronic Furby doll, still in its original packaging from 2000. The packaging highlights "E.T. - Your Extra-Terrestrial Friend" and "From the makers of Furby." The doll itself is brown with large blue eyes, wearing a red hooded jacket, and its right hand is extended, pointing.

Setup and Initial Use

- Unboxing:** Carefully remove the E.T. Furby from its packaging. Retain the packaging for future storage or reference.
- Battery Installation:** Locate the battery compartment on the underside of the Furby. Using a small Phillips head screwdriver, open the compartment. Insert 4 "AA" alkaline batteries, ensuring correct polarity (+/-). Close the compartment securely.
- Activation:** Once batteries are installed, the Furby should begin to awaken. It may start to move its eyes, mouth, and speak its first words. If it does not activate, gently rock it back and forth or press the reset button (if available, typically a small recessed button requiring a paperclip).

Operating Instructions

The E.T. Furby is designed for interactive play. Its responses are based on sound, touch, and light.

- Speaking:** Speak clearly to your E.T. Furby. It will learn and respond over time, expanding its vocabulary. The more you interact, the more it will communicate.
- Touch Interaction:** Pet its head, tickle its belly, or hold it upside down to elicit different reactions. Observe its movements and sounds for cues.
- Light Features:** The E.T. Furby's finger and heart are designed to glow. This feature activates during certain interactions or when it expresses specific emotions.
- Communication with Other Furbys:** Place your E.T. Furby near other Furby or Furby Baby units. They are designed to communicate with each other, engaging in conversations and even singing together.
- Sleep Mode:** If left undisturbed, the E.T. Furby will eventually go to sleep to conserve battery life. You can wake it up by interacting with it.

Maintenance

- Cleaning:** To clean your E.T. Furby, gently wipe its surface with a soft, damp cloth. Do not immerse the toy in water or use harsh cleaning agents, as this can damage the electronic components.
- Battery Replacement:** When the Furby's responses become sluggish or it stops functioning, it's time to replace the batteries. Always replace all batteries at the same time with new ones of the same type.
- Storage:** When not in use for extended periods, remove the batteries to prevent leakage and corrosion. Store the Furby in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Solution
E.T. Furby does not turn on or respond.	Check battery installation; ensure correct polarity. Replace old batteries with new "AA" alkaline batteries. Ensure the battery compartment is securely closed.
E.T. Furby's responses are slow or garbled.	Batteries may be low; replace them. Ensure the environment is not excessively noisy, which might interfere with its sensors.

Problem	Solution
E.T. Furby does not communicate with other Furbys.	Ensure both Furbys are active and within close proximity. Check batteries in both units.

SPECIFICATIONS

- **Model:** E.T. Electronic Furby
- **ASIN:** B000EO72WQ
- **Manufacturer:** Tiger Electronics
- **Release Year:** 2000
- **Power Source:** 4 x "AA" Alkaline Batteries (not included)
- **Interactive Features:** Voice recognition, touch sensors, light-up finger and heart, communication with other Furby units.

WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct manufacturer support for this vintage product is not available in the provided data. For products of this age, warranty coverage may no longer be applicable. Please refer to the original product packaging or contact collector communities for further assistance.

© 2000 Tiger Electronics. All rights reserved. E.T. The Extra-Terrestrial © Universal Studios.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question