

Bruder 02218

Bruder Claas Disc 8550 C Plus Three Part Mower Instruction Manual

Model: 02218

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Bruder Claas Disc 8550 C Plus Three Part Mower (Model 02218). This highly realistic 1:16 scale accessory is designed to complement Bruder Pro-Series tractors and harvesters, enhancing imaginative play with its detailed functions.

Important Safety Information: Not suitable for children under 3 years due to small parts which may present a choking hazard. Recommended for ages 4 years and up.

SETUP

The Claas Disc 8550 C Plus Mower is designed for easy attachment to compatible Bruder Pro-Series tractors and harvesters. The unit consists of three main parts: a front mower and two rear mowers. No assembly is required for the mower unit itself.

Attaching the Mower

1. **Prepare the Tractor/Harvester:** Ensure your Bruder Pro-Series tractor or harvester is ready for accessory attachment.
2. **Attach Front Mower:** Securely connect the single front mower unit to the front hitch of the tractor.
3. **Attach Rear Mowers:** Connect the main three-part mower assembly to the rear hitch of the tractor. The two side mower units are integrated into this assembly.
4. **Verify Connection:** Ensure all parts are firmly attached to prevent detachment during play.



Image: The Claas Disc 8550 C Plus Mower attached to a Bruder tractor, showing the front and rear mower units in an operational configuration.



Image: The Claas Disc 8550 C Plus Mower attached to a Bruder harvester, demonstrating its versatility with different farm vehicles.

OPERATING INSTRUCTIONS

The Claas Disc 8550 C Plus Mower features several realistic functions for an engaging play experience.

Key Functions:

- **Front Mower Adjustment:** The front mower unit can be manually lowered and raised independently to simulate different cutting heights or transport positions.
- **Oscillating Suspension:** The mower features an oscillating suspension system designed to compensate for uneven ground, allowing for realistic movement over varied terrain.
- **Rotating Conditioners:** The conditioner units rotate via a direct drive system, mimicking the action of real agricultural machinery.
- **Folding for Transport/Storage:** The entire unit can be folded up for compact storage or transport.



Image: The Claas Disc 8550 C Plus Mower in its folded position, ready for transport or compact storage.



Image: The Claas Disc 8550 C Plus Mower fully extended in its operational position, ready for mowing tasks.

Video Demonstration

Your browser does not support the video tag.

Video: Official demonstration of the Bruder Claas Disc 8550 C Plus Three Part Mower, showcasing its features and how it attaches to a combine harvester. This video highlights the folding mechanism and the movement of the mower units.

MAINTENANCE

Proper care will ensure the longevity and optimal performance of your Bruder Claas Disc 8550 C Plus Mower.

- **Cleaning:** Wipe the toy with a damp cloth to remove dust and dirt. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the mower in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation. The folding mechanism allows for compact storage.
- **Inspection:** Periodically check for any loose or damaged parts. While designed for durability, rough play can cause wear.

TROUBLESHOOTING

If you encounter any issues with your Claas Disc 8550 C Plus Mower, refer to the following common solutions:

- **Mower not attaching securely:** Ensure the attachment points on both the mower and the tractor/harvester are clean and free from obstructions. Verify that the mower is correctly aligned with the hitch.
- **Moving parts are stiff:** Check for any debris or foreign objects obstructing the moving mechanisms. Gentle manipulation may help free stiff joints. Avoid forcing parts.
- **Parts appear damaged:** If any part is broken or significantly damaged, contact Bruder customer support for

assistance or spare parts information. Refer to the warranty section for details.

SPECIFICATIONS

Model Name	CLAAS Disc 8550 C Plus Three Part Mower
Model Number	02218
Brand	Bruder
Scale	1:16 Scale
Material	High-quality plastics (ABS)
Dimensions (L x W x H)	Approx. 9.3 x 19.2 x 3.5 inches (23.6 x 48.8 x 8.9 cm)
Weight	452 Grams
Recommended Age	4 years and upwards
Included Components	CLAAS Disc 8550 C Plus Three Part Mower Add On

WARRANTY INFORMATION

Bruder provides a **1-year manufacturer's warranty** against defects in materials and workmanship from the date of purchase. This warranty covers manufacturing faults but does not cover damage resulting from misuse, accidents, or normal wear and tear.

Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, spare parts, or inquiries regarding your Bruder Claas Disc 8550 C Plus Mower, please visit the official Bruder website or contact their customer service department. You can also refer to the [Bruder Store on Amazon](#) for additional product information.

When contacting support, please have your model number (02218) and proof of purchase available.