

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Eureka](#) /

› [Eureka Style OX Replacement Vacuum Cleaner Bags \(3-Pack\) Instruction Manual for Models 61230A, 61230C, 61230D, 61230F](#)

Eureka 61230A, 61230C, 61230D, 61230F, 6500, 6990, CV140

Eureka Style OX Replacement Vacuum Cleaner Bags Instruction Manual

For Models: 61230A, 61230C, 61230D, 61230F, 6500, 6990, CV140 Series Canister Vacuums

INTRODUCTION

This manual provides essential instructions for the proper installation, use, and maintenance of your Eureka Style OX Replacement Vacuum Cleaner Bags. These bags are designed to fit specific Eureka canister vacuum models, ensuring optimal performance and filtration.

Please read this manual thoroughly before installing or using the replacement bags to ensure correct usage and to prolong the life of your vacuum cleaner.

PRODUCT COMPATIBILITY

The Eureka Style OX Replacement Vacuum Cleaner Bags are compatible with the following Eureka vacuum cleaner models:

- Eureka 61230A
- Eureka 61230C
- Eureka 61230D
- Eureka 61230F
- Eureka 6500 Series Canister Vacuums
- Eureka 6990 Series Canister Vacuums
- Eureka CV140 Series Canister Vacuums

Using these bags with incompatible models may result in reduced performance or damage to your vacuum cleaner.

SETUP: INSTALLING THE REPLACEMENT BAG

- 1. Power Off and Unplug:** Before attempting any maintenance or installation, ensure your vacuum cleaner is turned off and unplugged from the electrical outlet to prevent accidental startup.
- 2. Locate Bag Compartment:** Identify the dust bag compartment on your Eureka canister vacuum. This is

typically located on the main body of the vacuum and may be secured by latches or a release button.

3. **Open Compartment:** Open the dust bag compartment. If there is an old bag present, carefully remove it. Dispose of the old bag according to local waste disposal guidelines.
4. **Insert New Bag:** Take a new Eureka Style OX replacement bag. Align the cardboard collar of the bag with the bag holder inside the compartment. The opening of the bag should fit securely over the inlet tube. Ensure the bag is fully seated and the collar is flush against the holder to prevent dust leakage.
5. **Close Compartment:** Gently fold the bag into the compartment, ensuring it is not creased or obstructing the closing mechanism. Close the dust bag compartment securely until you hear a click or feel it latch into place.
6. **Verify Installation:** Before operating, double-check that the compartment is fully closed and the bag is properly installed.



Image: A single Eureka Style OX replacement vacuum cleaner bag, showing the cardboard collar and opening for installation into a vacuum cleaner.

OPERATING GUIDELINES

Once the replacement bag is correctly installed, your vacuum cleaner is ready for operation. These bags are designed for dry pick-up only. Do not attempt to vacuum liquids or wet debris, as this can damage the vacuum and the bag.

Monitor your vacuum's performance. A full bag can reduce suction power. Refer to the Maintenance section for guidance on when to replace the bag.

MAINTENANCE: BAG REPLACEMENT

Regular replacement of your vacuum bag is crucial for maintaining optimal suction and filtration efficiency.

Replace the bag when:

- The bag full indicator on your vacuum cleaner illuminates or activates.
- Suction power noticeably decreases, even after checking for clogs in the hose or attachments.
- The bag appears visibly full or distended when you open the compartment.
- You notice a decrease in air quality or an unusual odor during vacuum operation, which may indicate a saturated filter bag.

Do not attempt to empty and reuse disposable bags, as this can compromise their filtration capabilities and lead to dust leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced Suction	Bag is full or improperly installed.	Replace the bag or ensure it is securely seated in the compartment. Check for clogs in the hose or attachments.
Dust Leakage	Bag not properly sealed or compartment not closed.	Ensure the bag's cardboard collar is flush against the inlet tube and the compartment door is fully latched.
Bag Does Not Fit	Incorrect bag model for your vacuum.	Verify your vacuum model number against the compatible models listed in this manual. Purchase the correct replacement bags.

SPECIFICATIONS

Brand: Eureka

Product Type: Replacement Vacuum Cleaner Bags

Material: Paper

Color: White

Number of Items: 3 bags per pack

Compatible Devices: Eureka Canister Vacuums (Models 61230A, 61230C, 61230D, 61230F, 6500 Series, 6990 Series, CV140 Series)

Product Dimensions: Approximately 8.1 x 6.5 x 0.4 inches (per bag, folded)

Item Weight: Approximately 3.2 ounces (per pack)


CUSTOMER SUPPORT

For further assistance, questions, or to purchase additional replacement bags, please visit the official Eureka website or contact Eureka customer service. Refer to your vacuum cleaner's original manual for specific model support information.

Manufacturer: Eureka

Related Documents - 61230A, 61230C, 61230D, 61230F, 6500, 6990, CV140

 	<p>Eureka 100 easyclean 2-in-1 Combi-Vac Owner's Manual & Guide Official owner's manual and guide for the Eureka 100 easyclean 2-in-1 Combi-Vac with Detachable Hand Vac. Includes assembly, usage, maintenance, troubleshooting, and warranty information. Hosted by Appliance Factory Parts.</p>
--	--

 <p>Eureka Yellow Jacket Compact Central Vac: Owners Manual & Installation Guide</p> <p>Comprehensive owners manual and installation guide for the Eureka Yellow Jacket Compact Central Vac system. Learn about safety, installation, maintenance, and troubleshooting for your central vacuum.</p>	
 <p>Eureka NEN180 Series Canister Vacuum Cleaner Owner's Guide</p> <p>Comprehensive owner's guide for the Eureka NEN180 series canister vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and warranty information.</p>	
 <p>Eureka NEN185 Series Canister Vacuum Cleaner Owner's Guide</p> <p>This owner's guide provides essential information for the Eureka NEN185 series canister vacuum cleaner, covering safety precautions, assembly, operation, maintenance, troubleshooting, and warranty details. Learn how to use and care for your Eureka vacuum for optimal performance.</p>	
 <p>Eureka 990 Series Canister Vacuum Cleaner Owner's Guide</p> <p>Comprehensive owner's guide for the Eureka 990 Series Canister Vacuum Cleaner, covering important safeguards, assembly, maintenance, troubleshooting, and warranty information.</p>	
 <p>Eureka Owner's Guide: V18C01A-80 Vacuum Cleaner Manual</p> <p>Comprehensive owner's guide for the Eureka V18C01A-80 bagless canister vacuum cleaner. Includes product overview, assembly, safety instructions, operation, maintenance, and disposal information.</p>	