

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Suncast](#) /

› [Suncast 129 Gallon Indoor/Outdoor Deck Box User Manual](#)

Suncast DB9750

Suncast 129 Gallon Indoor/Outdoor Deck Box User Manual

Model: DB9750 | Brand: Suncast

PRODUCT OVERVIEW

The Suncast 129 Gallon Deck Box is a versatile and durable storage solution designed for both indoor and outdoor use. Its robust construction ensures longevity and protection for your belongings. This deck box is ideal for organizing patio cushions, gardening tools, pool supplies, and other outdoor essentials, keeping them dry and secure. It also doubles as convenient extra seating.



Figure 1: The Suncast 129 Gallon Deck Box in Taupe, showcasing its closed design suitable for various outdoor settings.

SETUP AND ASSEMBLY

Assembly of the Suncast Deck Box is designed to be straightforward and requires no special tools. Components are typically marked for easy identification, ensuring a smooth setup process. Ensure all parts are present before beginning assembly. Follow the included instructions for snapping the panels and base into place securely.



Figure 2: Dimensions of the Suncast 129 Gallon Deck Box: 53.5"L x 27.5"W x 24"H, illustrating its generous size for storage.

OPERATING INSTRUCTIONS

The deck box features a hinged lid for convenient access to its contents. To open, simply lift the lid. The hinges are designed to hold the lid open, preventing it from falling back down during loading or unloading. To close, gently lower the lid until it securely latches. The design ensures a tight seal to protect items from the elements.



Figure 3: The deck box shown with its lid fully open, revealing ample space for storing patio cushions and other items.



Figure 4: An interior view of the deck box, demonstrating its capacity to hold diverse items such as sports equipment and gardening tools.

Maintenance

The Suncast Deck Box is constructed from water-resistant poly resin, designed to resist fading and rust. For general cleaning, simply wipe down the exterior with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these may damage the finish. Periodically check the hinges and lid for any debris that might impede smooth operation. The durable material ensures the box remains looking new for years with minimal upkeep.

Troubleshooting

Lid Not Closing Properly

Ensure no items are obstructing the lid's path or the sealing edges. Check for any debris accumulated along the rim of the box or on the underside of the lid. Verify that the hinges are properly aligned and free from damage. Applying a small amount of silicone lubricant to the hinges can improve closure if stiffness is present.

Water Inside the Box

While the deck box is water-resistant, extreme weather conditions or improper closure can lead to moisture ingress. Ensure the lid is fully closed and latched. Check for any cracks or damage to the poly resin material, especially along seams or the base. If damage is found, contact Suncast customer service for repair or replacement options.

SPECIFICATIONS

Feature	Detail
Brand	Suncast
Model Number	DB9750
Capacity	129 Gallons (488.32 Liters)
Product Dimensions	53.5" L x 27.5" W x 24" H
Material	Water-resistant Poly Resin (all-weather, UV-protective)
Color	Taupe
Opening Mechanism	Hinge
Maximum Weight Recommendation	300 Pounds (for seating)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Suncast website or the documentation included with your product. The manufacturer, Suncast Corporation, stands behind the durability and quality of their products. A user manual in PDF format is available for download: [Suncast Deck Box User Manual \(PDF\)](#).