

Leviton 89201-CHR



Leviton 89201-CHR 1-Gang Toggle Switch Wallplate User Manual

Model: 89201-CHR

1. INTRODUCTION

This manual provides instructions for the installation and maintenance of the Leviton 89201-CHR 1-Gang Toggle Switch Wallplate. This product is designed to cover a single toggle switch opening, offering a decorative and protective finish to your electrical installations. Please read these instructions carefully before proceeding with installation.

2. PRODUCT OVERVIEW

The Leviton 89201-CHR wallplate is a single-gang cover for toggle switches, crafted from genuine wood with a cherry finish. It is designed to provide a traditional and formal aesthetic to residential interiors.



Image 1: Leviton 89201-CHR 1-Gang Toggle Switch Wallplate. This image displays the front view of the cherry wood wallplate with a single opening for a toggle switch and two screw holes.

Key Features:

- Genuine wood construction with a cherry finish.
- Designed for a single toggle switch.
- Residential grade for durability and appearance.
- Provides a traditional and formal aesthetic.

3. SAFETY INFORMATION

WARNING: To avoid fire, shock, or death, always turn off power at the circuit breaker or fuse box before wiring or installing this product. Installation should be performed by a qualified electrician or in accordance with local electrical codes.

- Ensure the power supply to the switch is disconnected before beginning installation.
- Do not use if the product appears damaged.
- This product is for indoor use only.

4. PACKAGE CONTENTS

- 1 x Leviton 89201-CHR 1-Gang Toggle Switch Wallplate
- 2 x Mounting Screws (typically included with wallplate)

5. INSTALLATION INSTRUCTIONS

Follow these steps to install or replace your wallplate:

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the switch you are working on. Turn off the power completely. Verify that the power is off using a voltage tester.
2. **Remove Old Wallplate:** Carefully unscrew and remove the existing wallplate from the wall.
3. **Position New Wallplate:** Align the Leviton 89201-CHR wallplate over the toggle switch and the screw holes.
4. **Secure Wallplate:** Insert the provided mounting screws into the screw holes and gently tighten them until the wallplate is flush with the wall. Do not overtighten, as this can damage the wallplate or the electrical box.
5. **Restore Power:** Once the wallplate is securely installed, turn the power back on at the circuit breaker or fuse box.

If you are unsure about any step, consult a qualified electrician.

6. OPERATING INSTRUCTIONS

The Leviton 89201-CHR wallplate is a passive decorative and protective cover. It does not have operational functions. The toggle switch it covers operates as usual.

7. MAINTENANCE

To maintain the appearance of your cherry wood wallplate:

- Wipe with a soft, dry cloth to remove dust.
- For stubborn marks, use a slightly damp cloth with mild soap, then dry immediately.
- Avoid abrasive cleaners or harsh chemicals, as these can damage the wood finish.

8. TROUBLESHOOTING

As a decorative wallplate, operational troubleshooting is generally not applicable. If the wallplate does not fit correctly or appears loose after installation, ensure the mounting screws are properly aligned and tightened. If the underlying electrical switch is not functioning, consult the instructions for the switch itself or contact a qualified electrician.

9. SPECIFICATIONS


Attribute	Detail
Model Number	89201-CHR
Brand	Leviton
Material	Wood
Color	Cherry
Finish Type	Wood
Configuration	1-Gang (Single Toggle)
Installation Type	Screw-In
Product Dimensions	5.25 x 3.5 x 0.25 inches
Item Weight	2.4 ounces (0.15 Pounds)
UPC	078477128923






10. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Leviton product, please visit the official Leviton website or contact their customer service department. Leviton is committed to providing quality solutions and support for its products.

You can find more information and contact details on the [Leviton Brand Store](#).

Related Documents - 89201-CHR

	<p>Leviton QuickPort Flush Mount Wallplates Installation and Safety Guide</p> <p>Official installation and safety instructions for Leviton QuickPort Flush Mount Wallplates. Learn how to install, configure, and safely use these versatile wallplates for network and communication applications.</p>
---	---

	<p><u>My Leviton App Guide: Control Your Smart Home Devices</u></p> <p>Explore the My Leviton App Guide to easily enroll, integrate, and customize your Decora Smart Wi-Fi devices and Leviton Load Center with Smart Breakers for seamless smart home control.</p>
	<p><u>Leviton Toggle Slide Controls: Traditional Style, Modern Performance</u></p> <p>Explore Leviton's Toggle Slide Controls, including dimmers (TSL06, TSM10) and fan speed controls (TSF01). Featuring traditional design with modern functionality for various lighting and fan applications. Learn about features, specifications, and installation.</p>
	<p><u>Leviton Building Manager Online (BMO) Software Overview</u></p> <p>Discover Leviton's Building Manager Online (BMO) software, a robust, cloud-based energy management solution for commercial buildings. Explore features like energy visualization, tenant billing, advanced reporting, and code compliance tools, designed to optimize energy usage and reduce operational costs.</p>
	<p><u>Leviton GFCI Receptacle Installation and Testing Guide</u></p> <p>A comprehensive guide on how to install and test a Leviton SmartLock Pro GFCI Receptacle, including wiring instructions, safety precautions, and troubleshooting tips.</p>
	<p><u>Leviton TSL06 Toggle Dimmer LED Bulb Compatibility Guide</u></p> <p>Comprehensive compatibility guide for Leviton TSL06 Toggle Dimmer with various LED bulbs, detailing model numbers, wattage, and color temperature. Includes testing criteria and rating system explanation.</p>