

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Casio](#) /
- › [Casio G-Shock Mudman G9000-1V Digital Watch Instruction Manual](#)

**Casio G9000-1V**

# Casio G-Shock Mudman G9000-1V Digital Watch Instruction Manual

Model: G9000-1V



Image: Front view of the Casio G-Shock Mudman G9000-1V digital watch.

## PRODUCT OVERVIEW

The Casio G-Shock Mudman G9000-1V is a robust digital watch engineered for extreme conditions. Its Mud Resist construction protects against dirt and debris, making it ideal for demanding environments. Key features include shock resistance, 200-meter water resistance, and a Dual Illuminator backlight for enhanced visibility in low light. It also boasts advanced timekeeping functions such as dual stopwatches and a countdown timer, designed for precision and durability.

## INITIAL SETUP

### Setting the Time and Date

1. In Timekeeping Mode, press and hold the **ADJUST** button until the city code starts to flash.
2. Use the **FORWARD** and **REVERSE** buttons to select your desired city code (time zone).
3. Press the **MODE** button to cycle through the setting options: DST (Daylight Saving Time), 12/24-hour format, Seconds, Hour, Minute, Year, Month, Day.
4. Use the **FORWARD** and **REVERSE** buttons to change the flashing value.
5. Press the **ADJUST** button to exit the setting screen.

### Activating the Dual Illuminator

The Dual Illuminator provides simultaneous illumination of the LCD panel and the dial. To activate, press the **FLASH** button. You can configure the afterglow duration (3-second or 5-second) in the watch's settings.



Image: Casio G-Shock Mudman G9000-1V with its Dual Illuminator backlight activated, showing clear digital display in low light conditions.

## OPERATING INSTRUCTIONS

### Using the Stopwatches (STW1 & STW2)

The G9000-1V features two independent 1,000-hour stopwatches for simultaneous measurement. This allows for

versatile timing, such as timing a race and simultaneously tracking pit stop durations.

- To enter Stopwatch Mode, press the **MODE** button repeatedly until "STW1" or "STW2" appears.
- Press the **STOP/START** button to start/stop the stopwatch.
- Press the **RESET/SPLIT** button to record a split time or reset the stopwatch when stopped.

### Countdown Timer

The 24-hour countdown timer can be set in 1-minute or 1-hour increments and features an auto-repeat function with a progress beeper.

- Navigate to Countdown Timer Mode using the **MODE** button.
- Press and hold **ADJUST** to enter setting mode.
- Use **FORWARD** and **REVERSE** to set the desired countdown time.
- Press **ADJUST** to confirm settings.
- Press **STOP/START** to begin the countdown.

### Alarms and Hourly Time Signal

The watch includes four multi-function alarms and one snooze alarm, along with an optional hourly time signal.

- Access Alarm Mode via the **MODE** button.
- Use **FORWARD** to cycle through alarms (AL1, AL2, AL3, AL4, SNZ, SIG).
- Press **ADJUST** to toggle alarms ON/OFF or to set alarm times.

## MAINTENANCE AND CARE

### General Care

To ensure the longevity of your G-Shock Mudman, regularly clean the watch with a soft, damp cloth. Avoid exposing it to extreme temperatures or harsh chemicals. The mud-resistant construction helps prevent dirt ingress, but occasional cleaning of the exterior is recommended.

### Product Overview Video

Your browser does not support the video tag.

Video: An overview of the Casio G-Shock Mudman G9000-1V, showcasing its features and design. This video is provided by the merchant.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery or extreme temperature.	Replace battery (Lithium Ion, included). Allow watch to return to normal operating temperature.

Problem	Possible Cause	Solution
Buttons are difficult to press.	Mud-resistant structure requires firm button presses; dirt accumulation.	This is normal for Mudman models. Clean around buttons to remove any accumulated dirt.
Time is incorrect.	Incorrect city code or DST setting.	Adjust time and date settings as described in the "Initial Setup" section.

## SPECIFICATIONS

- **Model:** G9000-1V
- **Case Size (L× W× H):** 52 × 46.3 × 16.3 mm
- **Weight:** Approximately 4 ounces
- **Material:** Resin (Case and Band)
- **Water Resistance:** 200 meters (660 feet)
- **Shock Resistance:** Yes
- **Mud Resistance:** Yes
- **Backlight:** Auto Dual EL Backlights with Afterglow
- **Low Temperature Resistant:** Yes
- **World Time:** 29 time zones (48 cities), city code display, daylight saving on/off
- **Stopwatch:** 1/100 second stopwatch (two independent 1,000-hour stopwatches), Measuring modes: Elapsed time, split time, 1st-2nd place times
- **Countdown Timer:** Start time setting range: 1 minute to 24 hours (1-minute increments and 1-hour increments), Auto-repeat, progress beeper
- **Alarms:** Four Multi-function alarms & 1 snooze alarm
- **Hourly Time Signal:** Yes
- **Calendar:** Full auto-calendar
- **Time Formats:** 12/24 hour formats
- **Button Tone:** Button operation tone on/off
- **Flash Alert:** Yes
- **Battery:** 1 Lithium Ion battery (included)

## WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Casio website or the user guide provided with your product. A digital version of the user guide is often available online for download.

You can find the official user guide (PDF) [here](#).

For additional assistance or to purchase genuine replacement parts, please contact Casio customer service or visit

an authorized Casio service center.