

[Manuals.plus](#) /

› [REVLON](#) /

› REVLON 3 Barrel Jumbo Hair Waver Instruction Manual

REVLON RV084

REVLON 3 Barrel Jumbo Hair Waver Instruction Manual

Brand: REVLON | **Model:** RV084

1. PRODUCT OVERVIEW

The REVLON 3 Barrel Jumbo Hair Waver is designed to create deep, luxurious waves that last. Featuring Tourmaline Ceramic coating, it helps reduce heat damage by distributing heat evenly, sealing the hair cuticle, and boosting shine. Its unique extra-wide middle barrel produces the deepest, smoothest waves for a professional finish. With 30 heat settings up to 420°F, it offers precise control for all hair types. The waver also includes a tangle-free swivel cord and a locking ring for convenient storage.



Figure 1: REVLON 3 Barrel Jumbo Hair Waver (Grey)

2. IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance. Keep away from water. As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

- Always unplug this appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.

For complete safety guidelines, refer to the full User Manual PDF available at [REVLON User Manual PDF](#)

3. PRODUCT FEATURES

- **TOURMALINE CERAMIC COATING:** Helps reduce damage from over-styling with even heat distribution that helps seal the hair cuticle and boost shine.



Figure 2: Benefits of Tourmaline Ceramic Coating

- **LONG-LASTING WAVES:** Create deep, luxurious waves that last from early morning until late night with this 3-Barrel Tourmaline Ceramic Jumbo Waver.
- **CUSTOM STYLING:** Lets you style large sections of hair fast and the unique, extra-wide middle barrel produces the deepest, smoothest waves for a professional finish.
- **ALL HAIR TYPES:** Select the ideal styling level for your hair from 30 heat settings up to 420°F for precise control in all hair types.



©2020 Helen of Troy. All rights reserved.

Figure 3: Recommended Heat Levels for Different Hair Types

- **VERSATILE STYLING POWER:** Offers flexible styling power for natural, shiny waves with Tourmaline Ceramic Coating and a Tangle-Free Swivel Cord.



Figure 4: Icons representing 30 heat settings, flexible styling power, natural shiny waves, Tourmaline Ceramic Coating, and Tangle-Free Swivel Cord.

- **TRAVEL READY:** Tangle-free swivel cord and locking ring for convenient storage.



Figure 5: Diagram highlighting Jumbo Size, 30 Heat Settings, "ON" Indicator Light, Locking Ring, and Swivel Cord.

4. SETUP

1. **Unpack:** Carefully remove the REVLON 3 Barrel Jumbo Hair Waver from its packaging. Ensure all components are present and undamaged.

2. **Inspect:** Check the appliance and its cord for any signs of damage. Do not use if damaged.
 3. **Placement:** Place the waver on a heat-resistant, flat surface away from water or flammable materials.
 4. **Plug In:** Insert the plug into a standard electrical outlet.
-

5. OPERATING INSTRUCTIONS

1. **Power On:** Slide the ON/OFF switch to the "ON" position. The indicator light will illuminate.
 2. **Select Heat Setting:** Rotate the temperature dial to your desired heat setting (1-30). Refer to Figure 3 for recommended heat levels based on hair type. Allow the waver a few minutes to heat up.
 3. **Prepare Hair:** Ensure hair is clean, dry, and detangled. For best results, apply a heat protectant spray.
 4. **Section Hair:** Divide your hair into manageable sections, approximately 1-2 inches wide.
 5. **Waving Technique:**
 - Open the waver by squeezing the handle.
 - Place a section of hair between the barrels, starting close to the roots (but not touching the scalp).
 - Close the waver firmly, holding for 3-5 seconds. Adjust holding time based on desired wave intensity and hair type.
 - Release the waver and move down the same section of hair, overlapping the last wave to create a continuous pattern.
 - Repeat until the entire section is waved.
 6. **Cool Down:** Allow waves to cool completely before touching or styling to set the wave.
 7. **Power Off:** Once finished, slide the ON/OFF switch to the "OFF" position and unplug the appliance.
-

6. MAINTENANCE AND CARE

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the barrels and exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
 - **Storage:** When cool, press the barrels together and push the Locking Ring up to secure them for compact storage. Store in a cool, dry place, out of reach of children. Do not wrap the cord around the appliance.
-

7. TROUBLESHOOTING

- **Appliance Not Heating:**
 - Ensure the appliance is properly plugged into a working electrical outlet.
 - Check that the ON/OFF switch is in the "ON" position.
- **Waves Not Holding/Too Loose:**
 - Increase the heat setting (refer to Figure 3 for guidance).
 - Hold the waver on the hair section for a longer duration (e.g., 5-8 seconds).
 - Ensure hair is completely dry before waving.
 - Consider using a styling product (e.g., hairspray) after waving.
- **Hair Getting Snagged:**

- Ensure hair is thoroughly detangled before use.
- Use smaller, more manageable sections of hair.

8. SPECIFICATIONS

Feature	Detail
Brand	REVLON
Model Number	RV084
UPC	761318000846
Product Dimensions	3 x 6 x 16 inches
Item Weight	2 Pounds
Hair Type	All
Material	Ceramic Tourmaline
Heat Settings	30 settings, up to 420°F
Manufacturer	Helen of Troy

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official REVLON website or contact their customer service directly. Keep your purchase receipt for warranty claims.

You can also find the full User Manual (PDF) for detailed information:[Download User Manual](#)

© 2024 REVLON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question