

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BLACK+DECKER](#) /

› [BLACK+DECKER ACV1205 12V DC Cyclonic Auto Dustbuster Car Vacuum Cleaner Instruction Manual](#)

BLACK+DECKER ACV1205

BLACK+DECKER ACV1205 12V DC Cyclonic Auto Dustbuster Car Vacuum Cleaner Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and care of your BLACK+DECKER ACV1205 12V DC Cyclonic Auto Dustbuster Car Vacuum Cleaner. Please read these instructions thoroughly before first use and retain them for future reference.

Key Features:

- **12V DC Power:** Operates directly from your vehicle's cigarette lighter socket.
- **Cyclonic Action:** Maintains strong suction by keeping dust away from the filter.
- **Compact and Lightweight Design:** Easy to handle and store within your vehicle.
- **Extended Reach:** Includes a 5-meter power cable for accessing all areas of your car.
- **Versatile Accessories:** Equipped with various tools for comprehensive cleaning.

2. SAFETY INSTRUCTIONS

- Always ensure the vehicle engine is running when using the vacuum cleaner to prevent draining the car battery.
- Do not use the appliance to pick up water or other liquids.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the appliance with a damaged cord or plug.
- Ensure the filter is correctly installed before operation.
- Unplug the appliance from the cigarette lighter socket when not in use and before cleaning or maintenance.

3. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- BLACK+DECKER ACV1205 Vacuum Cleaner Unit
- Long Crevice Tool
- Short Crevice Tool
- SA Brush
- SA Hose
- Adaptor Floor Extension
- Storage Bag



Figure 3.1: BLACK+DECKER ACV1205 unit with all accessories including crevice tools, hose, brush, floor extension, and storage bag.

4. PRODUCT OVERVIEW



Figure 4.1: Main unit of the BLACK+DECKER ACV1205 Car Vacuum Cleaner.

The ACV1205 is designed for efficient car interior cleaning. Its ergonomic handle provides comfortable grip, and the transparent dust bowl allows for easy monitoring of debris levels. The power switch is conveniently located for quick operation.

5. SETUP

1. **Connect Power:** Insert the 12V DC power adapter firmly into your vehicle's cigarette lighter socket. Ensure the vehicle's engine is running to provide adequate power and prevent battery drain.



Figure 5.1: Plugging the vacuum into the car's 12V socket.

2. **Attach Accessories:** Select the appropriate cleaning attachment for the task. Push the desired accessory firmly onto the vacuum's nozzle or onto the SA Hose if extended reach is required.



Figure 5.2: The vacuum connects to a standard 12V cigarette lighter socket.

Setup Demonstration Video:

Your browser does not support the video tag.

Video 5.1: This video demonstrates how to connect the vacuum to your car's power outlet and attach various cleaning accessories for different tasks.

6. OPERATING INSTRUCTIONS

1. **Power On:** Once connected to the 12V socket, press the power switch located on the top of the vacuum cleaner to turn it on.

2. **Cleaning Surfaces:**

- **General Cleaning:** Use the main nozzle for larger debris on car seats and floor mats.



Figure 6.1: Using the vacuum for general cleaning on car seats.

- **Tight Spaces:** Attach the **Short Crevice Tool** for cleaning between seats, console gaps, and other narrow areas.



Figure 6.2: The crevice tool is effective for tight spots.

- **Deep Cleaning & Corners:** Connect the **SA Hose** and then the **Long Crevice Tool** or **Adaptor Floor Extension** for reaching under seats, into footwells, and other hard-to-access spots.




Figure 6.3: Utilizing the hose and long crevice tool for extended reach.

- **Delicate Surfaces & Vents:** Use the **SA Brush** attachment, either directly or with the SA Hose, for cleaning dashboards, air vents, and upholstery without scratching.



Figure 6.4: Cleaning car vents and delicate surfaces with the brush attachment.

3. **Power Off:** After cleaning, press the power switch to turn off the vacuum cleaner and unplug it from the cigarette lighter socket.

7. MAINTENANCE

Emptying the Dust Bowl:

1. Ensure the vacuum cleaner is switched off and unplugged from the vehicle.
2. Hold the unit over a waste bin.
3. Press the dust bowl release button (usually located near the nozzle) and detach the dust bowl from the main unit.
4. Carefully empty the contents into the waste bin.



Figure 7.1: The cyclonic action helps keep the filter clear for sustained suction.

Cleaning the Filter:

1. With the dust bowl detached, remove the filter assembly.
2. Tap the filter gently over a waste bin to dislodge any accumulated dust.
3. For thorough cleaning, the filter can be washed in warm, soapy water. Ensure the filter is completely dry before reassembling and using the vacuum cleaner.
4. Reassemble the filter into the dust bowl, then reattach the dust bowl to the main unit until it clicks securely into place.

Maintenance Demonstration Video:

Your browser does not support the video tag.

Video 7.1: This video illustrates the process of emptying the dust bowl and cleaning the filter for optimal performance.

8. STORAGE

After use, ensure the vacuum cleaner is clean and dry. Store the unit and all accessories in the provided storage bag. This protects the components and keeps them organized for future use.



Figure 8.1: The compact design and included bag make storage easy.

Storage Demonstration Video:

Your browser does not support the video tag.

Video 8.1: This video shows how to properly store the vacuum cleaner and its accessories in the provided bag.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not properly plugged into 12V socket. Vehicle engine not running. Blown fuse in vehicle's cigarette lighter socket.	Ensure plug is fully inserted. Start vehicle engine. Check and replace vehicle fuse if necessary.
Low suction power.	Dust bowl is full. Filter is clogged. Nozzle or hose is blocked.	Empty dust bowl. Clean or replace filter. Remove any blockages from nozzle or hose.
Motor runs but no suction.	Dust bowl not properly attached. Filter missing or incorrectly installed.	Ensure dust bowl is securely clicked into place. Install filter correctly.

10. SPECIFICATIONS

Feature	Specification
Model Name	ACV1205
Brand	BLACK+DECKER
Operating Voltage	12 Volts DC
Wattage	13 Watts
Suction Power	12.5 AW
Suction Pressure	340.0 mm/Water
Dust Bag Capacity	0.5 Liters
Filter Type	Cartridge
Cord Length	5 Meters (approx.)
Item Weight	0.9 Kilograms
Noise Level	80 Decibels
Form Factor	Handheld

11. WARRANTY AND CUSTOMER SUPPORT

Your BLACK+DECKER ACV1205 Car Vacuum Cleaner comes with a **1-year warranty** provided by the manufacturer from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

For any warranty-related issues, product feedback, or technical assistance, please contact BLACK+DECKER customer care:

- **Customer Care Number:** 1860-425-1111
- **Operating Hours:** Monday to Friday, 10 AM to 5 PM (except government holidays)

For more information, you may also visit the official BLACK+DECKER website.