



Manuals.plus /

› Unicorn /

› Unicorn Striker Dartboard Instruction Manual U79383

Unicorn U79383

Unicorn Striker Dartboard Instruction Manual

Model: U79383

INTRODUCTION

Thank you for choosing the Unicorn Striker Dartboard. This manual provides essential information for the proper setup, operation, and maintenance of your dartboard to ensure optimal performance and longevity. The Unicorn Striker is a high-quality bristle dartboard designed for competitive play, featuring a staple-free bullseye and SuperSlim wire fasteners to minimize bounce-outs.



Image: The Unicorn Striker Dartboard, showcasing its classic design with black, white, red, and green segments.

PRODUCT FEATURES

- **High-Quality Bristle Board:** Constructed from natural sisal fibers for durability and self-healing properties.
- **PDC Approved:** Approved by the Professional Darts Corporation, ensuring competition-grade quality.
- **Staple-Free Bullseye:** Eliminates staples around the bullseye for increased scoring area and reduced bounce-outs.
- **SuperSlim Wire Fasteners:** Features ultra-thin wire fasteners to maximize the scoring area and minimize dart deflection.
- **Round Wire Construction:** High-quality round wire construction for enhanced performance.
- **Adjustable Number Ring:** Allows for rotation to extend the dartboard's lifespan by distributing wear evenly.

SETUP AND INSTALLATION

Proper installation is crucial for the performance and safety of your dartboard. Follow these steps carefully.

1. Mounting Location

- Choose a sturdy wall or dartboard cabinet.
- Ensure adequate space around the dartboard for throwing and retrieving darts safely.
- Keep away from windows, doors, and areas with high foot traffic.

2. Mounting the Dartboard

The dartboard typically comes with a mounting bracket.

1. Attach the mounting bracket to the center of the back of the dartboard using the provided screws.
2. Mark the desired height on the wall. The center of the bullseye should be **1.73 meters (5 feet 8 inches)** from the floor.
3. Securely fasten the wall bracket to the marked spot on the wall using appropriate screws and wall anchors for your wall type.
4. Hang the dartboard onto the wall bracket, ensuring it is stable and level.

PLEASE NOTE:
Experience has shown that mechanical pins will greatly reduce the life of the dartboard.

TRY THE RUSS BRAY DARTS SCORER PRO APP
OFFICIALLY ENDORSED BY UNICORN, SCAN TO DOWNLOAD NOW!

SuperSlim
WIRE FASTENING SYSTEM
Système de fixation à fil métallique

NATURAL COMBED SISAL BOARD
Sisal's properties make it uniquely suitable for Dartboards -
Naturally lubricated fibres
Self-healing individual bristles
Immediate shape recovery
Consistent overall density
Resilient and durable

CIBLE EN SISAL PEIGNE NATUREL
Les propriétés du sisal le rendent particulièrement approprié pour les cibles de jeux de fléchettes -
Fibres lubrifiées naturellement
Poils individuels autocicatrisants
Rétablissement immédiat de la forme
Densité d'ensemble homogène
Résilient et durable

ADJUSTABLE NUMBER RING
Rotate the number ring regularly to even out areas of wear.

ANNEAU NUMÉRIQUE RÉGLABLE
Faire tourner régulièrement l'anneau numéroté pour répartir plus également les endroits d'usure.

STAPLE FREE BULLSEYE
Plein centre sans crampon

WAYS TO FINISH
PRO 3 DART FINISHES
the best option if you miss your first or second dart

Score	1st	2nd	3rd	Score	1st	2nd	3rd
100	120	120	0	100	120	120	0
99	120	119	0	99	120	119	0
98	120	118	0	98	120	118	0
97	120	117	0	97	120	117	0
96	120	116	0	96	120	116	0
95	120	115	0	95	120	115	0
94	120	114	0	94	120	114	0
93	120	113	0	93	120	113	0
92	120	112	0	92	120	112	0
91	120	111	0	91	120	111	0
90	120	110	0	90	120	110	0
89	120	109	0	89	120	109	0
88	120	108	0	88	120	108	0
87	120	107	0	87	120	107	0
86	120	106	0	86	120	106	0
85	120	105	0	85	120	105	0
84	120	104	0	84	120	104	0
83	120	103	0	83	120	103	0
82	120	102	0	82	120	102	0
81	120	101	0	81	120	101	0
80	120	100	0	80	120	100	0
79	120	99	0	79	120	99	0
78	120	98	0	78	120	98	0
77	120	97	0	77	120	97	0
76	120	96	0	76	120	96	0
75	120	95	0	75	120	95	0
74	120	94	0	74	120	94	0
73	120	93	0	73	120	93	0
72	120	92	0	72	120	92	0
71	120	91	0	71	120	91	0
70	120	90	0	70	120	90	0
69	120	89	0	69	120	89	0
68	120	88	0	68	120	88	0
67	120	87	0	67	120	87	0
66	120	86	0	66	120	86	0
65	120	85	0	65	120	85	0
64	120	84	0	64	120	84	0
63	120	83	0	63	120	83	0
62	120	82	0	62	120	82	0
61	120	81	0	61	120	81	0
60	120	80	0	60	120	80	0
59	120	79	0	59	120	79	0
58	120	78	0	58	120	78	0
57	120	77	0	57	120	77	0
56	120	76	0	56	120	76	0
55	120	75	0	55	120	75	0
54	120	74	0	54	120	74	0
53	120	73	0	53	120	73	0
52	120	72	0	52	120	72	0
51	120	71	0	51	120	71	0
50	120	70	0	50	120	70	0
49	120	69	0	49	120	69	0
48	120	68	0	48	120	68	0
47	120	67	0	47	120	67	0
46	120	66	0	46	120	66	0
45	120	65	0	45	120	65	0
44	120	64	0	44	120	64	0
43	120	63	0	43	120	63	0
42	120	62	0	42	120	62	0
41	120	61	0	41	120	61	0
40	120	60	0	40	120	60	0
39	120	59	0	39	120	59	0
38	120	58	0	38	120	58	0
37	120	57	0	37	120	57	0
36	120	56	0	36	120	56	0
35	120	55	0	35	120	55	0
34	120	54	0	34	120	54	0
33	120	53	0	33	120	53	0
32	120	52	0	32	120	52	0
31	120	51	0	31	120	51	0
30	120	50	0	30	120	50	0
29	120	49	0	29	120	49	0
28	120	48	0	28	120	48	0
27	120	47	0	27	120	47	0
26	120	46	0	26	120	46	0
25	120	45	0	25	120	45	0
24	120	44	0	24	120	44	0
23	120	43	0	23	120	43	0
22	120	42	0	22	120	42	0
21	120	41	0	21	120	41	0
20	120	40	0	20	120	40	0
19	120	39	0	19	120	39	0
18	120	38	0	18	120	38	0
17	120	37	0	17	120	37	0
16	120	36	0	16	120	36	0
15	120	35	0	15	120	35	0
14	120	34	0	14	120	34	0
13	120	33	0	13	120	33	0
12	120	32	0	12	120	32	0
11	120	31	0	11	120	31	0
10	120	30	0	10	120	30	0
9	120	29	0	9	120	29	0
8	120	28	0	8	120	28	0
7	120	27	0	7	120	27	0
6	120	26	0	6	120	26	0
5	120	25	0	5	120	25	0
4	120	24	0	4	120	24	0
3	120	23	0	3	120	23	0
2	120	22	0	2	120	22	0
1	120	21	0	1	120	21	0
0	120	20	0	0	120	20	0

Below 99 the game may be finished with only two darts.
* - Triple 20 - Double

3 DART IN HAND FINISHES
the better option if you miss your first or second dart

Score	1st	2nd	3rd	Score	1st	2nd	3rd
100	120	120	0	100	120	120	0
99	120	119	0	99	120	119	0
98	120	118	0	98	120	118	0
97	120	117	0	97	120	117	0
96	120	116	0	96	120	116	0
95	120	115	0	95	120	115	0
94	120	114	0	94	120	114	0
93	120	113	0	93	120	113	0
92	120	112	0	92	120	112	0
91	120	111	0	91	120	111	0
90	120	110	0	90	120	110	0
89	120	109	0	89	120	109	0
88	120	108	0	88	120	108	0
87	120	107	0	87	120	107	0
86	120	106	0	86	120	106	0
85	120	105	0	85	120	105	0
84	120	104	0	84	120	104	0
83	120	103	0	83	120	103	0
82	120	102	0	82	120	102	0
81	120	101	0	81	120	101	0
80	120	100	0	80	120	100	0
79	120	99	0	79	120	99	0
78	120	98	0	78	120	98	0
77	120	97	0	77	120	97	0
76	120	96	0	76	120	96	0
75	120	95	0	75	120	95	0
74	120	94	0	74	120	94	0
73	120	93	0	73	120	93	0
72	120	92	0	72	120	92	0
71	120	91	0	71	120	91	0
70	120	90	0	70	120	90	0
69	120	89	0	69	120	89	0
68	120	88	0	68	120	88	0
67	120	87	0	67	120	87	0
66	120	86	0	66	120	86	0
65	120	85	0	65	120	85	0
64	120	84	0	64	120	84	0
63	120	83	0	63	120	83	0
62	120	82	0	62	120	82	0
61	120	81	0	61	120	81	0
60	120	80	0	60	120	80	0
59	120	79	0	59	120	79	0
58	120	78	0	58	120	78	0
57	120	77	0	57	120	77	0
56	120	76	0	56	120	76	0
55	120	75	0	55	120	75	0
54	120	74	0	54	120	74	0
53	120	73	0	53	120	73	0
52	120	72	0	52	120	72	0
51	120	71	0	51	120	71	0
50	120	70	0	50	120	70	0
49	120	69	0	49	120	69	0
48	120	68	0	48	120	68	0
47	120	67	0	47	120	67	0
46	120	66	0	46	120	66	0
45	120	65	0	45	120	65	0
44	120	64	0	44	120	64	0
43	120	63	0	43	120	63	0
42	120	62	0	42	120	62	0
41	120	61	0	41	120	61	0
40	120	60	0	40	120	60	0
39	120	59	0	39	120	59	0
38	120	58	0	38	120	58	0
37	120	57	0	37	120	57	0
36	120	56	0	36	120	56	0
35	120	55	0	35	120	55	0
34	120	54	0	34	120	54	0
33	120	53	0	33	120	53	0
32	120	52	0	32	120	52	0
31	120	51	0	31	120	51	0
30	120	50	0	30	120	50	0
29	120	49	0	29	120	49	0
28	120	48	0	28	120	48	0
27	120	47	0	27	120	47	0
26	120	46	0	26	120	46	0
25	120	45	0	25	120	45	0
24	120	44	0	24	120	44	0
23	120	43	0	23	120	43	0
22	120	42	0	22	120	42	0
21	120	41	0	21	120	41	0
20	120	40	0	20	120	40	0
19	120	39	0	19	120		

Measure the throwing distance (oche) from the face of the dartboard to the throwing line. This distance should be **2.37 meters (7 feet 9.25 inches)** Mark this line clearly on the floor.




Image: The Unicorn Striker Dartboard with its overall diameter indicated as 46cm. This image helps visualize the physical size of the dartboard.

OPERATING INSTRUCTIONS

The Unicorn Striker Dartboard is designed for use with steel-tip darts. While some users report success with soft-tip darts with appropriate tips, steel-tip darts are recommended for optimal performance and longevity of the sisal fibers.

- Ensure darts are in good condition with sharp points.
- Aim for the desired segment. The high-quality sisal fibers are designed to close up after dart removal.
- Remove darts by twisting and pulling gently to avoid damaging the fibers.

Scoring

Standard dart games involve scoring based on where the dart lands. For assistance with scoring and game variations, consider using a dedicated dart scoring application.

The Russ Bray Darts Scorer Pro app is officially endorsed by Unicorn and can be a useful tool for keeping score and learning various dart games.



Image: The Unicorn Striker Dartboard highlighting its competition quality, round wire construction, SuperSlim wire fasteners, and staple-free bullseye. This image emphasizes the board's advanced features.

MAINTENANCE

Regular maintenance will prolong the life of your Unicorn Striker Dartboard.

- **Rotate the Number Ring:** To ensure even wear across the dartboard, periodically rotate the number ring. This allows different segments to be used as the '20' segment, which typically receives the most play. Simply unclip the number ring and reposition it.
- **Keep Dry:** Store the dartboard in a dry environment. Moisture can damage the sisal fibers.
- **Clean Gently:** If necessary, gently wipe the surface with a dry cloth. Avoid using water or cleaning agents.
- **Dart Condition:** Ensure your darts have sharp, burr-free points. Dull or damaged dart points can tear the sisal fibers.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Darts Bouncing Out:**

- Check dart points: Ensure they are sharp and not bent.
- Throwing technique: Ensure darts are thrown with sufficient force and proper angle.
- Board condition: While the Striker features SuperSlim wires to reduce bounce-outs, excessive wear in one area can sometimes lead to more bounce-outs. Rotate the number ring as described in the Maintenance section.

- **Darts Not Sticking:**

- Dart points: Verify points are sharp and clean.
- Board moisture: Ensure the dartboard is not damp, as moisture can affect sisal fiber density.

- **Board Appears Worn in One Area:**

- This is normal with frequent play. Rotate the number ring to distribute wear.

SPECIFICATIONS

Brand	Unicorn
Model Number	U79383
Material	Sisal
Color	Black/White/Red/Green
Product Dimensions	Diameter: 46 cm (18.1 inches), Thickness: 43 mm (1.7 inches)
Item Weight	1 Kilogram (2.2 lbs)
Shape	Round
Components Included	Unicorn Striker Bristle Board
PDC Approved	Yes
Staple-Free Bullseye	Yes

SAFETY INFORMATION

Warning: Darts are not toys. This product is intended for adult use. Keep out of reach of children.

- Always ensure a clear throwing area.
- Never throw darts at people or animals.
- Use caution when retrieving darts from the board.
- Inspect darts regularly for damage and replace as needed.

WARRANTY AND SUPPORT

Unicorn provides a **1-year availability for spare parts** for this product.

For any missing parts or queries regarding your Unicorn Striker Dartboard, please contact Unicorn directly.

Do not return the product to the store without prior communication.

Official Website: www.unicorn-darts.com

unicorn[®]

— THE BIG NAME IN DARTS —

Image: The Unicorn brand logo, featuring the company name and the tagline "THE BIG NAME IN DARTS".