Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fat Cat by GLD Products 64-3011

Fat Cat Storm 7-Foot Air Hockey Table User Manual

Model: 64-3011

Introduction

Thank you for choosing the Fat Cat Storm 7-Foot Air Hockey Table. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new air hockey table. Please read these instructions thoroughly before beginning assembly or use to ensure proper setup and enjoyment of your product.

Safety Information

- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- **Adult Assembly Required:** Assembly should be performed by adults. Keep children away during assembly.
- **Two-Person Lift:** The air hockey table is heavy (approximately 139 lbs). Always use two or more people when lifting or moving the table to prevent injury.
- **Power Tools:** Power tools are not recommended for assembly. If used, set to a LOW TORQUE to prevent overtightening, screw stripping, and damage to the table.
- **Stable Surface:** Ensure the table is placed on a stable, level surface. Use the built-in leg levelers to adjust for uneven floors.
- **Electrical Safety:** Ensure the power cord for the air blower is properly connected and routed to avoid tripping hazards. Do not operate with damaged cords or plugs.

Package Contents

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Fat Cat Storm 7-Foot Air Hockey Table (Main Unit)
- 4 x Pushers (Red)
- 4 x Pucks (Red)
- LED Electronic Scorer (Requires 3 AA batteries, not included)

- Assembly Hardware (Screws, washers, wrenches, etc.)
- Leg Levelers



Image: Four red pushers and four red pucks, ready for gameplay.

Assembly Instructions

Assembly typically takes approximately 60 minutes with a Philips screwdriver (not included). It is highly recommended to have two adults for assembly.

Step 1: Prepare the Assembly Area

Clear a spacious area for assembly. Place the table upside down on a soft, clean surface (e.g., the cardboard packaging) to prevent damage to the playing surface.



Image: Top-down view of the Fat Cat Storm air hockey table playing surface, showcasing the "Storm" graphic and pucks.

Step 2: Attach the Legs

Carefully attach the table legs to the underside of the table using the provided hardware. Ensure all screws are tightened securely, but do not overtighten. The legs feature built-in levelers for stability.



Image: Underside view of the air hockey table, illustrating the leg attachment points and internal support structure.

Video: For a visual guide on leg assembly, please refer to the official assembly video below.

Your browser does not support the video tag.

Video: Official assembly instructions for the Fat Cat Storm Air Hockey Table, demonstrating leg attachment.

Step 3: Carefully Flip the Table

With the help of another person, carefully flip the table over so it rests on its legs. Avoid dragging the table, as this can damage the legs or the playing surface.



Image: Two individuals carefully turning the air hockey table upright after leg assembly.

Step 4: Install the Electronic Scorer

Mount the LED electronic scorer to the designated area on the table. Secure it with the provided screws. Connect the power cable from the scorer to the main table unit. Insert 3 AA batteries (not included) into the scorer's battery compartment.



Image: Close-up view of the LED electronic scorer, showing its display and controls.

Operating Instructions

Powering On/Off

- Plug the table's power cord into a standard electrical outlet.
- Turn on the air blower using the switch located on the underside of the table.
- Turn on the electronic scorer using the ON/OFF button.

Using the Electronic Scorer

- The scorer automatically tracks goals.
- Adjust volume using the dedicated button.
- Set game timer for 10-minute, 15-minute, or unlimited play.
- Press the RESET button to clear scores and restart a game.

Gameplay

- Place a puck on the playing surface. The powerful 80 CFM motor creates a cushion of air for smooth, fast-paced play.
- Use the pushers to strike the puck into your opponent's goal.
- The dual-end puck return allows for continuous action.



Image: Two players actively playing air hockey on the table, demonstrating typical gameplay.

Maintenance

- **Cleaning the Playing Surface:** Wipe the playing surface with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Cleaning Pushers and Pucks:** Clean pushers and pucks regularly to maintain optimal glide.
- **Motor Care:** Ensure the air intake for the 80 CFM motor is free from dust and debris to maintain airflow.
- **Leg Levelers:** Periodically check and adjust leg levelers to ensure the playing surface remains perfectly balanced.
- **Storage:** When not in use for extended periods, store the table in a dry, temperature-controlled environment.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Airflow from Blower	Power cord unplugged; Blower switch off; Obstruction in air intake.	Check power connection; Turn blower switch ON; Clear any obstructions.
Electronic Scorer Not Working	Batteries dead or incorrectly inserted; Scorer switch off; Loose connection.	Replace batteries (3 AA); Turn scorer switch ON; Check cable connection.
Puck Not Gliding Smoothly	Insufficient airflow; Dirty playing surface or pucks; Uneven table.	Check blower for obstructions; Clean playing surface and pucks; Adjust leg levelers.
Table Wobbles	Uneven floor; Loose leg connections.	Adjust leg levelers; Re-tighten leg assembly screws.

Specifications

Model: 64-3011

Dimensions (L x W x H): 84" x 42" x 30.5" (7 ft L x 3.5 ft W x 2.5 ft H)

Weight: 139 lbs

Material: Metal, Plastic, Wood

Motor: 110V, 80 CFM Airflow

Scorer: LED Electronic (Requires 3 AA batteries)

Players: 2

Assembly Required: Yes



Image: Dimensional diagram of the Fat Cat Storm Air Hockey Table.

Warranty Information

This Fat Cat Storm Air Hockey Table comes with a**90-day warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from misuse,

abuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For assistance with assembly, missing parts, troubleshooting, or warranty claims, please contact GLD Products customer support. Refer to the contact information provided with your product packaging or visit the official Fat Cat by GLD Products website.

Online Resources: Visit the Fat Cat Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000GG7D2Q

More documents and user manuals: **https://manuals.plus/**