

[Manuals.plus](#) /

› [Victorinox](#) /

› Victorinox Swiss Army Men's Maverick II Watch Model 24135 User Manual

Victorinox 24135

Victorinox Swiss Army Men's Maverick II Watch Model 24135 User Manual

Swiss Quartz Stainless Steel and Rubber Sport Watch

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Victorinox Swiss Army Men's Maverick II Swiss Quartz Watch, Model 24135. Please read this guide thoroughly to ensure optimal performance and longevity of your timepiece.

Your Maverick II watch features a durable stainless steel case, a comfortable black rubber strap, a black unidirectional bezel, and luminous hands and hour markers for visibility. It is water-resistant to 100 meters (330 feet).

PRODUCT OVERVIEW





Figure 1: Front view of the Victorinox Swiss Army Maverick II Watch. Shows the black dial, luminous hands, and black rubber strap.




Figure 2: Angled view of the Victorinox Swiss Army Maverick II Watch, highlighting the stainless steel case and rubber strap texture.

The Victorinox Swiss Army Maverick II (Model 24135) is a robust sport watch designed for reliability and functionality. Key components include:

- **Crown:** Used for setting time and date.
- **Unidirectional Bezel:** Rotates in one direction, typically used for timing events.
- **Luminous Hands and Markers:** Enhance readability in low-light conditions.
- **Rubber Strap:** Provides comfort and durability for active use.
- **Stainless Steel Case:** Offers protection for the internal movement.

SETUP

1. Setting the Time

1. Gently pull the crown out to the first position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to engage the movement.

2. Wearing the Watch

Place the watch on your wrist and secure the rubber strap using the tang buckle. Ensure the fit is snug but comfortable, allowing for proper blood circulation and preventing excessive movement of the watch on your wrist.

OPERATING THE WATCH

1. Basic Timekeeping

Your Maverick II watch is a Swiss Quartz movement, providing accurate timekeeping. Once the time is set, the watch will run continuously until the battery requires replacement.

2. Using the Unidirectional Bezel

The black bezel rotates in a single direction (counter-clockwise). This feature is useful for timing events, such as dive times or elapsed time for other activities.

1. Align the zero marker on the bezel with the minute hand at the start of the event you wish to time.
2. As time passes, the minute hand will indicate the elapsed time against the bezel's markings.

3. Water Resistance

The watch is water-resistant to 100 meters (330 feet). This makes it suitable for snorkeling, swimming, and general water activities. **It is not suitable for diving.**

- Ensure the crown is fully pushed in before any contact with water.
- Do not operate the crown while the watch is wet or submerged.
- Avoid exposing the watch to hot water or steam, as this can compromise the seals.

MAINTENANCE

1. Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the case and strap with a soft, damp cloth.
- For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and thorough drying.
- Avoid using harsh chemicals or abrasive materials, which can damage the watch's finish.

2. Battery Replacement

Your quartz watch is powered by a battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by an authorized Victorinox service center or a qualified watchmaker to ensure proper sealing and maintain water resistance.

3. Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can protect it from dust and scratches.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Depleted battery	Replace battery (professional service recommended).
Incorrect time	Crown not fully pushed in; time not set correctly	Ensure crown is fully pushed in. Reset time as per "Setting the Time" instructions.
Condensation inside crystal	Compromised water resistance due to impact or seal degradation	Seek immediate professional service to prevent further damage.

SPECIFICATIONS

- **Model Number:** 24135
- **Movement:** Swiss Quartz
- **Case Material:** Stainless Steel
- **Case Diameter:** 43 Millimetres
- **Case Thickness:** 10 Millimetres
- **Band Material:** Rubber
- **Band Width:** 22 Millimetres
- **Dial Color:** Black
- **Display Type:** Analog
- **Water Resistance Depth:** 100 Metres (330 Feet)
- **Special Features:** Luminous Hands, Unidirectional Bezel
- **Weight:** 567 g




Figure 3: Watch size comparison chart. This image illustrates different watch case diameters in millimeters, ranging from 14-16mm up to 50-54mm, alongside 1-inch and 2-inch measurement references. The Maverick II has a 43mm case diameter.

WARRANTY AND SUPPORT

Victorinox Swiss Army watches are manufactured to the highest quality standards and undergo strict quality control. Your watch is covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty terms, conditions, and to locate an authorized service center, please refer to the warranty card included with your purchase or visit the official Victorinox website.

For technical assistance or service inquiries, please contact Victorinox customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000GGV9XK>

More documents and user manuals: <https://manuals.plus/>