

[Manuals.plus](#) /

> [Longines](#) /

> Longines Dolce Vita Stainless Steel Quartz Watch L5.655.4.16.6 User Manual

## Longines L5.655.4.16.6

# Longines Dolce Vita Stainless Steel Quartz Watch L5.655.4.16.6 User Manual

Model: L5.655.4.16.6

## INTRODUCTION

---

This manual provides essential instructions for the proper use, care, and maintenance of your Longines Dolce Vita Stainless Steel Quartz Watch, Model L5.655.4.16.6. Please read this guide carefully to ensure optimal performance and longevity of your timepiece.

## SETUP

---

### 1. Setting the Time

1. Gently pull the crown (located on the right side of the watch case) outwards to the first position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into its original position against the watch case. This will restart the movement.



Image: Front view of the Longines Dolce Vita watch, showing the dial, hands, and the crown on the right side of the rectangular case. The small seconds sub-dial is visible at the 6 o'clock position.

## 2. Adjusting the Bracelet

The stainless steel bracelet can be adjusted for a comfortable fit. It is recommended to have this adjustment performed by a qualified watchmaker or an authorized Longines service center to prevent damage to the bracelet or clasp mechanism.

## OPERATING YOUR WATCH

---

### Time Display

Your Longines Dolce Vita watch features an analog display with hour and minute hands, and a small seconds sub-dial. The watch is powered by a precise Swiss Quartz movement, ensuring accurate timekeeping.

### Water Resistance

This watch is water resistant to 30 meters (100 feet). This rating means the watch is suitable for splashes or brief

immersion in water, but it is **not** recommended for swimming, diving, or showering. Always ensure the crown is fully pushed in before any contact with water.

## MAINTENANCE

---

### Cleaning

To maintain the appearance of your watch, clean the case and bracelet regularly with a soft, dry cloth. For more thorough cleaning, especially after contact with saltwater, use a soft brush and soapy water, then rinse carefully with fresh water and dry thoroughly. Ensure the crown is fully closed before cleaning with water.

### Battery Replacement

Your quartz watch is powered by a battery. When the battery is depleted, the watch will stop running. Battery replacement should only be performed by an authorized Longines service center to ensure the watch's water resistance and proper functioning are maintained.

### Periodic Checks

It is advisable to have your watch checked every 3-5 years by an authorized Longines service center. This check includes inspecting the movement, seals, and water resistance to ensure optimal performance.



Image: Back view of the Longines Dolce Vita watch, showing the stainless steel case back with engravings and the intricate links of the bracelet.

### Storage

When not wearing your watch, store it in a dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box provides excellent protection.

## TROUBLESHOOTING

---

### Watch Not Running

- **Crown Position:** Ensure the crown is fully pushed in against the watch case. If it is pulled out, the watch will not run.
- **Battery Depletion:** If the watch stops completely, the battery may need replacement. Contact an authorized Longines service center.

### Incorrect Time

- Refer to the "Setting the Time" section under Setup to correctly adjust the time.

### Condensation Under Crystal

- If you notice condensation under the watch crystal, this indicates a potential issue with the watch's water resistance. Immediately contact an authorized Longines service center to prevent further damage.

## SPECIFICATIONS

---

<b>Model Number</b>	L5.655.4.16.6 (L56554166)
<b>Movement Type</b>	Swiss Quartz
<b>Case Material</b>	316L Surgical Grade Polished Stainless Steel
<b>Case Shape</b>	Rectangular
<b>Case Diameter</b>	26.00 mm
<b>Case Thickness</b>	7.00 mm
<b>Dial Color</b>	White
<b>Crystal Type</b>	Scratch Resistant Sapphire
<b>Band Material</b>	Stainless Steel
<b>Band Width</b>	20.00 mm
<b>Clasp Type</b>	Deployment Clasp
<b>Water Resistance</b>	30 meters (100 feet)
<b>UPC</b>	703200055114



Image: Close-up view of the watch's stainless steel case back, displaying engraved brand logo, model information, and water resistance details.

## WARRANTY INFORMATION

---

Your Longines Dolce Vita watch comes with a Two Year Limited Warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear. Please refer to the official warranty card included with your purchase for full terms and conditions.

## CUSTOMER SUPPORT

---

For any questions, service requests, or technical assistance regarding your Longines watch, please contact an authorized Longines service center or visit the official Longines website. Using unauthorized service providers may void your warranty.

You can find a list of authorized service centers on the official Longines website: [www.longines.com](http://www.longines.com)