

[Manuals.plus](#) /

› [Leviton](#) /

› Leviton Candelabra Base Lampholder 10028 Instruction Manual

Leviton 10028



Leviton Candelabra Base, One-Piece, Keyless, Incandescent, Urea Lampholder

MODEL 10028 INSTRUCTION MANUAL

1. Product Overview

The Leviton Model 10028 is a durable, one-piece, keyless lampholder designed for incandescent lamps with a candelabra base. Constructed with a urea phenolic body and an aluminum shell, this lampholder is suitable for various lighting applications. It features a 2-terminal screw terminal for secure wiring and pony cleat mounting for easy installation. This product is UL Listed and CSA Certified, ensuring compliance with safety standards.



Image 1.1: Leviton Candelabra Base Lampholder, Model 10028. This image displays the white, one-piece lampholder with its internal candelabra base and screw terminals.

Key Features:

- Cleat-type lampholder with candelabra base.
- One-piece, keyless design for simplicity.
- Durable urea phenolic body and aluminum shell.
- Designed for incandescent lamps up to 75W at 125V.
- UL Listed and CSA Certified for safety.

2. Safety Information

Always prioritize safety when working with electrical components. Failure to follow these instructions can result in electric shock, fire, or serious injury.

- **DANGER:** Turn OFF power at the circuit breaker or fuse box before installing, servicing, or removing the lampholder. Verify power is off using a voltage tester.
- This product is intended for indoor use only.
- Ensure all wiring connections are secure and comply with local electrical codes.
- Do not exceed the maximum wattage (75W) or voltage (125V) specified for this lampholder.
- If you are unsure about any part of the installation process, consult a qualified electrician.
- Keep the lampholder away from moisture and extreme temperatures.

3. Package Contents

- 1 x Leviton Candelabra Base, One-Piece, Keyless, Incandescent, Urea Lampholder (Model 10028)

4. Specifications

Attribute	Value
Brand	Leviton
Model Number	10028
Part Number	10028
Color	White
Material	Metal (Aluminum Shell), Urea (Body)
Finish Type	Painted
Base Material	Aluminum
Lamp Type	Incandescent
Light Source Type	Incandescent
Shade Color	White
Shade Material	Aluminum
Voltage	125 Volts
Wattage	75 watts (Max)
Bulb Shape Size	B10 (Candelabra)
Mounting Type	Pony Cleat Mounting
Installation Type	Screw In
Indoor/Outdoor Usage	Indoor
Item Weight	0.317 ounces
Product Dimensions (L x W x H)	2.3 x 3 x 3.9 inches

5. Installation

Follow these steps for safe and proper installation of your lampholder:

1. **Turn Off Power:** Locate the circuit breaker or fuse controlling the power to the installation area. Turn it OFF completely. Verify that the power is off using a voltage tester before proceeding.
2. **Prepare Wires:** Strip approximately 1/2 inch of insulation from the ends of the electrical wires (hot and neutral) that will connect to the lampholder.
3. **Connect Wires:** Loosen the screw terminals on the lampholder. Insert one stripped wire end under each screw terminal. Ensure no loose strands of wire are exposed. Tighten the screws firmly to secure the wires.
4. **Mount Lampholder:** Use appropriate screws (not included) to secure the lampholder to your desired surface through the pre-drilled mounting holes. Ensure it is mounted securely and stably.

5. **Install Bulb:** Once the lampholder is securely mounted and wired, carefully screw in a candelabra base incandescent bulb (max 75W) into the socket.
6. **Restore Power:** Turn the power back ON at the circuit breaker or fuse box. Test the light to ensure it functions correctly.

Note: Always ensure proper grounding if required by local electrical codes.

6. Operation

The Leviton Model 10028 is a keyless lampholder, meaning it does not have an integrated switch. Operation is controlled by an external switch connected to the circuit. Simply turn on the external switch to illuminate the bulb and turn it off to extinguish the light.

7. Maintenance

Regular maintenance helps ensure the longevity and safe operation of your lampholder:

- **Cleaning:** Before cleaning, always turn off power to the lampholder at the circuit breaker. Use a soft, dry cloth to wipe down the exterior. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically inspect the lampholder for any signs of damage, such as cracks in the housing, frayed wires, or corrosion on the terminals. If any damage is observed, turn off power immediately and replace the lampholder.
- **Bulb Replacement:** Ensure power is off before replacing a light bulb. Allow the old bulb to cool completely before removing it.

8. Troubleshooting

If your lampholder is not functioning as expected, consider the following common issues and solutions:

- **Light Does Not Turn On:**
 - Check if the circuit breaker is tripped or the fuse is blown. Reset the breaker or replace the fuse.
 - Ensure the light bulb is securely screwed into the socket and is not burnt out. Try a new bulb.
 - Verify that the external switch controlling the light is in the ON position.
 - Confirm that all wiring connections to the lampholder are secure and correct. (Turn off power before checking wiring).
- **Flickering Light:**
 - Ensure the bulb is tightly screwed in.
 - Check for loose wiring connections at the lampholder or the external switch. (Turn off power before checking wiring).
 - The bulb itself might be faulty or nearing the end of its life. Try a new bulb.
- **Burning Smell or Smoke:**
 - **Immediately turn off power at the circuit breaker.** Do not attempt to use the lampholder. This indicates a serious electrical issue. Contact a qualified electrician for inspection and repair.

9. Warranty and Support

Leviton products are manufactured to the highest quality standards and are backed by Leviton's commitment to customer satisfaction. For specific warranty information, technical support, or to explore other Leviton products,

please visit the official Leviton website or contact their customer service.

You can find more information and support at the [Leviton Brand Store on Amazon](#).

© 2024 Leviton Manufacturing Co., Inc. All rights reserved.
Model 10028 - Candelabra Base Lampholder

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000HJ96B8>

More documents and user manuals: <https://manuals.plus/>