



Manuals.plus /

› Westinghouse /

› Westinghouse 81592 Glass Shade Instruction Manual

Westinghouse 81592

Westinghouse 81592 Glass Shade Instruction Manual

INTRODUCTION

The Westinghouse 81592 Glass Shade is designed as a replacement or upgrade for various compatible lighting fixtures. This manual provides essential information for the safe installation, proper use, and maintenance of your glass shade to ensure its longevity and optimal performance.

SAFETY INFORMATION

- **Disconnect Power:** Always disconnect power to the light fixture at the circuit breaker before attempting any installation, removal, or maintenance.
- **Handle with Care:** Glass is fragile. Handle the shade with extreme care to prevent breakage and potential injury.
- **Secure Fastening:** Ensure the shade is securely fastened to the fixture to prevent it from falling.
- **Avoid Overtightening:** Do not overtighten screws, clips, or threaded rings, as this can crack or damage the glass.
- **Cool Down:** Allow any existing light bulbs to cool completely before handling the shade.

PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package:

- 1 x Westinghouse 81592 Glass Shade (White, 4.625" L x 5.75" W)



Image: The Westinghouse 81592 Glass Shade, featuring its white finish and round design, ready for installation.

SETUP AND INSTALLATION

Follow these steps carefully to install your glass shade:

1. **Preparation:** Turn off the power to the light fixture at the circuit breaker. Allow any existing bulbs to cool completely before proceeding.
2. **Remove Old Shade (if applicable):** Carefully remove the existing shade from your fixture. Observe how it was attached for reference.
3. **Inspect Fitter:** Confirm that your light fixture has a **3.25-inch fitter** designed to accommodate this shade.
4. **Position New Shade:** Gently place the Westinghouse 81592 Glass Shade onto the fixture's fitter.
5. **Secure Shade:** Secure the shade using the fixture's existing retention mechanism (e.g., screws, clips, or a threaded ring). Ensure the shade is snug but not under excessive pressure. *Do not overtighten.*
6. **Restore Power:** Once the shade is securely installed and you have confirmed its stability, restore power to the fixture at the circuit breaker.

OPERATING INSTRUCTIONS

The Westinghouse 81592 Glass Shade functions as a decorative and light-diffusing component for compatible lighting fixtures. Once properly installed, it requires no further operation beyond the normal use of your light fixture. Ensure that the wattage of the light bulb used does not exceed the fixture's maximum rating.

MAINTENANCE

Proper maintenance will help preserve the appearance and integrity of your glass shade:

- **Cleaning:** To clean the glass shade, ensure the power to the fixture is off and the shade is cool. Use a soft, damp cloth with mild soap and water. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can scratch or damage the glass finish. Dry thoroughly with a clean, soft, lint-free cloth.
- **Inspection:** Periodically inspect the shade for any signs of cracks, chips, or damage. If damage is found, replace the shade immediately to prevent potential hazards.

TROUBLESHOOTING

If you encounter any issues with your glass shade, consider the following:

- **Shade does not fit:** Verify that your light fixture has a **3.25-inch fitter**. This shade is specifically designed for that size. Compatibility with other fitter sizes is not guaranteed.
- **Shade is loose or wobbly:** Ensure the retention mechanism (screws, clips, or threaded ring) is properly tightened. If the mechanism is worn or damaged, it may need replacement or adjustment. Do not overtighten.
- **Glass appears cloudy or stained:** Refer to the cleaning instructions provided in the Maintenance section. Stubborn stains may require repeated cleaning with a mild glass cleaner.

SPECIFICATIONS

- **Model:** 81592
- **Color:** White
- **Shape:** Round
- **Dimensions (Width x Height):** 4.6 inches x 5.75 inches
- **Fitter Size:** 3.25 inches
- **Material:** Glass
- **Item Weight:** 3.2 ounces
- **Number of Items:** 1
- **Manufacturer:** Westinghouse
- **UPC:** 030721815928

WARRANTY AND SUPPORT

Warranty Information: This Westinghouse product comes with a manufacturer's warranty. For specific

details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your original purchase or visit the official Westinghouse website.

Customer Support: For assistance with installation, troubleshooting, or warranty claims, please visit the official Westinghouse website or contact their customer service department directly. You can also find more information and products at the Westinghouse Store on Amazon.