

manuals.plus /

- › [American Standard](#) /
- › [American Standard Amarilis 8391.000.295 Bidet Faucet Instruction Manual](#)

American Standard 8391.000.295

American Standard Amarilis 8391.000.295 Bidet Faucet Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your American Standard Amarilis 8391.000.295 2-Handle Fixture-Mounted Bidet Faucet. Please read these instructions carefully before beginning installation or use to ensure proper function and longevity of your product. This bidet faucet features durable brass construction, ceramic disc valves for drip-free performance, and the exclusive Speed Connect pop-up drain for simplified installation. Note that handles are sold separately.

SETUP AND INSTALLATION

Installation should be performed by a qualified professional. Ensure all local plumbing codes are followed.

Components Overview



Image Description: This image displays the core components of the American Standard Amarilis bidet faucet. It features the central satin nickel faucet body, a small lever for the pop-up drain mechanism, and two separate valve cartridges designed to accept handles (which are sold separately). The components are shown ready for fixture mounting.

1. **Prepare the Mounting Surface:** Ensure the bidet fixture has the necessary openings for a 2-handle, centerset installation.
2. **Install Valve Cartridges:** Insert the ceramic disc valve cartridges into their respective openings on the bidet fixture. These cartridges are designed for smooth handle operation.
3. **Mount the Faucet Body:** Secure the main faucet body to the bidet fixture.
4. **Connect Water Supply:** Attach hot and cold water supply lines to the appropriate connections on the faucet.
5. **Install Speed Connect Pop-Up Drain:** The exclusive Speed Connect drain system is designed for fewer parts and quicker installation. Follow the specific instructions provided with the drain assembly for proper sealing and operation.
6. **Install Vacuum Breaker:** The included vacuum breaker must be installed according to local plumbing codes to prevent back-siphonage.
7. **Attach Handles (Sold Separately):** Once the faucet body and valves are installed, attach the desired American Standard Amarilis handles (not included with this product) to the valve stems.
8. **Test for Leaks:** After installation, slowly turn on the water supply and check all connections for leaks.

OPERATING INSTRUCTIONS

The American Standard Amarilis bidet faucet is designed for intuitive operation with its two-handle configuration.

- **Water Flow Control:** Turn the hot and cold handles (sold separately) to adjust the water temperature and flow rate to your desired comfort level. The ceramic disc valves ensure smooth and precise control.
- **Pop-Up Drain Operation:** Use the small lever located on the faucet body to open and close the pop-up drain. Push down to close the drain and pull up to open it.

CARE AND MAINTENANCE

Proper care will maintain the finish and performance of your bidet faucet.

- **Cleaning the Finish:** Clean the satin nickel finish with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or polishes that could damage the finish.
- **Drip-Free Performance:** The ceramic disc valve cartridges are designed for a lifetime of drip-free performance. If dripping occurs, it may indicate a need for cartridge replacement or professional inspection.
- **Aerator Maintenance:** Periodically unscrew and clean the aerator (if applicable) to remove mineral deposits and maintain optimal water flow.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Faucet Drips	Worn ceramic disc cartridge or debris in cartridge.	Replace ceramic disc cartridge or flush the system. Consult a professional plumber.
Low Water Flow	Clogged aerator or partially closed shut-off valves.	Clean or replace aerator. Ensure water supply shut-off valves are fully open.
Leaks at Connections	Loose connections or damaged seals.	Tighten connections carefully. Inspect and replace seals or O-rings if damaged.

If you encounter issues not listed here or require further assistance, please contact American Standard customer support or a qualified plumber.

PRODUCT SPECIFICATIONS

Brand: American Standard

Model Number: 8391.000.295

Product Name: Amarilis 2-Handle Fixture-Mounted Bidet Faucet

Finish Type: Satin Nickel

Material: Brass (Faucet Body), Nickel (Finish), Brass (Handle Material)

Mounting Type: Fixture-Mounted (Centerset)

Number of Handles: 2 (Handles Not Included)

Included Components: Faucet Body, Pop Up Drain, Vacuum Breaker

Special Features: Lead Free, Pop Up Drain, Ceramic Disc Valve Cartridges

Item Weight: 7.4 pounds

Package Dimensions: 15.12 x 12.5 x 2.94 inches

UPC: 012611187568

Date First Available: November 23, 2008

WARRANTY INFORMATION

This American Standard Amarilis bidet faucet is covered by a **Limited Lifetime Warranty**. Please refer to the official American Standard warranty documentation for full terms and conditions. Retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT





For technical assistance, replacement parts, or warranty inquiries, please contact American Standard customer service. You can also visit the official American Standard store for more product information and support resources.


American Standard Store: [Visit Store](#)



© 2023 American Standard. All rights reserved.


Related Documents - 8391.000.295

	<p>American Standard Hampton Bidet Faucet Installation Guide</p> <p>Comprehensive installation instructions for the American Standard Hampton Bidet Faucet, highlighting its EverClean finish and SpeedConnect drain technology. This guide provides essential steps, required tools, and part identification for proper setup.</p>
	<p>American Standard Universal Rotary Drain Installation Instructions</p> <p>Detailed installation instructions for the American Standard Universal Rotary Drain, including model compatibility, tools required, and step-by-step assembly guides for bath and whirlpool installations.</p>
	<p>American Standard Universal Rotary Drain Installation Instructions</p> <p>Comprehensive installation guide for the American Standard Universal Rotary Drain, model series 1583 and Bath-Drain Series. Includes required tools, rough-in dimensions, parts list, and step-by-step assembly instructions for rotary bath waste and overflow with pop-up drain.</p>
	<p>American Standard 1599.205.XXX Series Over-the-Rim Drain Installation Instructions</p> <p>Comprehensive installation guide for the American Standard 1599.205.XXX Series Over-the-Rim Bath Waste and Overflow with Toe Tapper Drain Plug. Features include required tools, rough-in dimensions, step-by-step assembly, and part identification for a successful bathroom fixture installation.</p>



[American Standard Fairbury Single Control Kitchen Pull-Down Faucet Installation Instructions \(4005 Series\)](#)

Step-by-step installation guide for the American Standard Fairbury Single Control Kitchen Pull-Down Faucet, model 4005 Series. Includes recommended tools, assembly, water connections, testing, service, and care.



[American Standard IoT DetectInk NextGen Integrated Faucet Owners Manual](#)

Comprehensive owner's manual for the American Standard IoT DetectInk NextGen Integrated Faucet, including installation, setup, maintenance, troubleshooting, and compliance information for models 775B405, 775B505, and 775B605.