

El Paso 70190

El Paso 70190 Fajita Grill Instruction Manual

Model: 70190

INTRODUCTION

Thank you for purchasing the El Paso 70190 Fajita Grill. This appliance is designed to provide a convenient and enjoyable cooking experience for preparing fajitas and other grilled dishes. Please read this manual thoroughly before initial use to ensure safe operation and optimal performance. Keep these instructions for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your El Paso 70190 Fajita Grill:

- Grill Surface (Non-stick)
- Tortilla Warmer (with lid)
- Removable Base / Housing (Red plastic with chili-pepper handles)
- Adjustable Temperature Control Probe
- Marinade Tray
- Grease Drain
- Tongs (Included)



Figure 1: El Paso 70190 Fajita Grill. This image displays the complete fajita grill unit, featuring its distinctive red base with decorative yellow and green accents, a black non-stick grilling surface, and a circular tortilla warmer with a clear glass lid topped with a red chili pepper handle. The temperature control probe is visible connected to the side.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage if

desired.

2. **Clean:** Before first use, wash the grill surface, tortilla warmer lid, and marinade tray in warm, soapy water. Rinse thoroughly and dry completely. The removable base can be wiped clean with a damp cloth.
3. **Assemble:**
 - Place the grill surface and tortilla warmer into the red base. Ensure they are seated correctly.
 - Insert the adjustable temperature control probe firmly into the receptacle on the side of the grill unit.
 - Position the marinade tray under the grease drain opening.
4. **Placement:** Place the assembled fajita grill on a stable, heat-resistant, and dry surface, away from flammable materials. Ensure adequate ventilation.

OPERATING INSTRUCTIONS

1. **Preheat:** Plug the power cord into a standard 120V AC electrical outlet. Turn the temperature control knob to the desired setting. The indicator light will illuminate, signaling that the grill is heating. Allow 5-10 minutes for the grill to reach the set temperature. The light will cycle on and off to maintain the temperature.
2. **Grilling:**
 - Lightly coat the non-stick grill surface with cooking oil if desired, though it is not strictly necessary due to the non-stick coating.
 - Place food directly onto the hot grill surface. Cook according to recipe or until desired doneness is achieved.
 - Excess grease will drain into the marinade tray.
3. **Using the Tortilla Warmer:**
 - Place tortillas into the tortilla warmer section.
 - Cover with the glass lid to keep tortillas warm and pliable while the main ingredients are grilling.
4. **Adjusting Temperature:** Use the adjustable temperature control knob to increase or decrease the heat as needed during cooking.
5. **Finishing:** Once cooking is complete, turn the temperature control knob to the "OFF" position and unplug the appliance from the wall outlet. Allow the unit to cool completely before cleaning or storing.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and performance of your fajita grill.

1. **Disconnect and Cool:** Always unplug the grill and allow it to cool completely before cleaning.
2. **Remove Components:** Detach the temperature control probe. Remove the grill surface, tortilla warmer lid, and marinade tray from the base.
3. **Dishwasher Safe Parts:** The non-stick grill surface, tortilla warmer lid, and marinade tray are dishwasher safe for convenient cleaning.
4. **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive sponge or cloth. Rinse thoroughly and dry immediately. Do not use metal scouring pads or abrasive cleaners, as these can damage the non-stick coating.
5. **Base Cleaning:** Wipe the exterior of the red base with a damp cloth. Do not immerse the base or the temperature control probe in water or any other liquid.

6. **Storage:** Ensure all parts are clean and dry before storing. Store the appliance in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; temperature control not set.	Ensure power cord is securely plugged into a working outlet. Turn temperature control knob to a setting above "OFF".
Food sticks to the grill surface.	Insufficient preheating; damaged non-stick coating.	Allow adequate preheating time. Ensure non-stick coating is not scratched or damaged. Use a small amount of cooking oil if necessary.
Grill not heating evenly.	Temperature probe not fully inserted.	Ensure the temperature control probe is fully and securely inserted into the appliance receptacle.
Smoke or unusual odor during first use.	Protective coatings burning off.	This is normal for initial use. Ensure good ventilation. If smoke persists after initial use, discontinue use and contact customer support.

SPECIFICATIONS

Model: El Paso 70190 Fajita Grill

Power: 1300 Watts

Voltage: 120V AC

Dimensions: 14.43" W x 5.5" D x 5.5" H (approximately)

Weight: 12.6 pounds

Material: Plastic (housing), Non-stick coating (grill surface)

Color: Red

Special Features: Non-stick coating, Adjustable Temperature Control, Integrated Tortilla Warmer, Marinade Tray, Grease Drain

Included Components: Tongs

UPC: 829486701900, 735343910722, 688859701905

WARRANTY AND SUPPORT

The El Paso 70190 Fajita Grill comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or replacement parts, please contact the manufacturer, MBlock & Sons, Inc., or your retailer. Please have your model number (70190) and proof of purchase available.

Note: The warranty does not cover damage resulting from misuse, neglect, accident, alteration, or commercial use.