Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > DYMO /
- > DYMO LetraTag 100H Plus Handheld Label Maker Instruction Manual

DYMO LetraTag 100H Plus

DYMO LetraTag 100H Plus Handheld Label Maker Instruction Manual

Model: LetraTag 100H Plus | Brand: DYMO

Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your DYMO LetraTag 100H Plus Handheld Label Maker. Please read this manual thoroughly before using your device to ensure proper function and longevity.



Figure 1: DYMO LetraTag 100H Plus Handheld Label Maker with included tape cassettes.

SETUP

1. Battery Installation

- 1. Locate the battery compartment cover on the back of the label maker.
- 2. Slide the cover off to open the compartment.
- 3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
- 4. Replace the battery compartment cover.

Your browser does not support the video tag.

Video 1: Demonstrates battery installation and basic operation of the label maker.

2. Tape Cassette Installation

- 1. Open the tape compartment cover, usually located on the top or side of the device.
- 2. Insert a DYMO LetraTag LT tape cassette into the compartment, ensuring it clicks into place.
- 3. Close the tape compartment cover.





Figure 2: The label maker as it appears in its packaging, showing the tape cassettes.

3. Powering On/Off

- To power on, press the On/Off button.
- To power off, press the **On/Off** button again. The device features auto-off functionality to save power when not in use.

OPERATION

1. Typing Text

Use the QWERTY keyboard to type your desired label text. The graphical display allows you to preview your text and effects before printing.

2. Customizing Labels

The LetraTag 100H Plus offers various customization options:

- Font Sizes: Choose from 5 available font sizes.
- **Print Styles:** Select from 7 different print styles (e.g., bold, italic, outline).
- Box Styles: Apply one of 8 distinct box styles to your labels.
- **Symbols:** Insert various symbols using the dedicated symbol function.

Your browser does not support the video tag.

Video 2: Overview of the DYMO LetraTag series, demonstrating various features and applications.

3. Printing a Label

- 1. After typing and customizing your text, press the **Print** button.
- 2. The label will feed out from the side of the device.

4. Cutting and Applying the Label

1. Use the integrated manual cutter on the side of the device to cut the printed label.

- 2. Carefully peel the backing from the label to expose the adhesive.
- 3. Apply the label to a clean, dry surface.



Figure 3: Example of a label applied to a spice jar for kitchen organization.




Figure 4: A label applied to a metal storage container, demonstrating versatility.



Figure 5: Labels on bathroom or kitchen bottles for clear identification.

MAINTENANCE

1. Cleaning the Device

Regularly clean the print head and cutter blade with a soft, lint-free cloth to ensure optimal performance. Do not use abrasive cleaners or solvents.

2. Replacing Tape Cassettes

When the tape runs out or you wish to change tape types/colors, open the tape compartment, remove the old cassette, and insert a new one as described in the Setup section. For best performance, use authentic DYMO 1/2" LetraTag LT Labels.



Figure 6: Authentic DYMO LetraTag tape refills are available in various materials and colors.

3. Battery Replacement

When the battery low indicator appears on the display, replace the 2 AAA batteries as described in the Setup section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or incorrectly inserted.	Replace batteries with new 2 AAA batteries, ensuring correct polarity.
"Battery Low" message appears.	Batteries are running low.	Replace batteries with new 2 AAA batteries.
Poor print quality or blank labels.	Print head is dirty or tape cassette is empty/incorrectly installed.	Clean the print head. Ensure tape cassette is properly installed and has tape remaining.
Label jams.	Tape is misaligned or debris is in the cutting mechanism.	Open the tape compartment and clear any jammed tape. Clean the cutter blade.

SPECIFICATIONS

• Model: LetraTag 100H Plus

• Brand: DYMO

Printing Technology: ThermalPrinter Output: Monochrome

• Maximum Black and White Print Resolution: 300 dpi

• Maximum Media Size: 1/2" (0.47 in) Label

Included Components: Label Maker
Power: 2 AAA batteries (not included)

• Product Dimensions: 2.6"D x 3.1"W x 8.3"H

• Item Weight: 2.4 ounces

• Special Feature: Graphical display for text preview, auto-off function

WARRANTY & SUPPORT

Warranty Information

This product comes with a limited warranty. Please note that the warranty does not cover misuse of the product. For full warranty details, refer to the documentation included with your purchase or visit the official DYMO website.

Customer Support

For further assistance, technical support, or to purchase additional supplies, please visit the DYMO Store on Amazon or the official DYMO website.

Related Documents - LetraTag 100H Plus



DYMO LetraTag LT-100H Label Maker Quick Reference Guide

A quick reference guide for the DYMO LetraTag LT-100H label maker, covering setup, basic operations, label design, and warranty information.



DYMO LetraTag 80 Quick Start Guide

A comprehensive guide for the DYMO LetraTag 80 label maker, covering setup, operation, printing, and warranty information across multiple languages.



DYMO LetraTag 200B User Guide

User guide for the DYMO LetraTag 200B electronic label maker, covering setup, operation, maintenance, and troubleshooting.



DYMO Rhino™ 6000+ Label Maker Quick Start Guide and Features

Explore the capabilities of the DYMO Rhino™ 6000+ label maker, a versatile tool for creating durable and professional labels for electrical, network, and industrial applications. Learn how to label cables, panels, terminals, and more with clear, step-by-step examples.



DYMO LetraTag 200B Quick Start Guide

Get started with your DYMO LetraTag 200B label maker. This guide covers battery installation, label cassette insertion, and printing labels via the DYMO LetraTag Connect app.



DYMO LetraTag XR Label Maker User Manual

Comprehensive user manual for the DYMO LetraTag XR label maker, covering setup, operation, features, formatting, troubleshooting, and technical specifications. Learn how to create and print labels with various fonts, styles, and symbols.