

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer X-Focus LED Flashlight User Manual

Energizer 639809

Energizer X-Focus LED Flashlight User Manual

Model: 639809

INTRODUCTION

Thank you for choosing the Energizer X-Focus LED Flashlight. This compact and lightweight flashlight is designed for versatility and durability, making it ideal for various tasks from DIY projects to outdoor activities. It features an adjustable focus beam and a non-slip grip for comfortable and secure handling. This flashlight provides 37 lumens of light and has a beam range of 38 meters.

What's Included:

- Energizer X-Focus LED Flashlight
- 2 x Energizer MAX AA Alkaline Batteries



Image: The Energizer X-Focus LED Flashlight in its packaging, highlighting its features. The package displays the flashlight itself, two Energizer MAX AA batteries, and text indicating a 45-meter beam distance, adjustable focus, and a non-slip grip texture.

SETUP: BATTERY INSTALLATION

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert two (2) Energizer MAX AA alkaline batteries into the battery compartment, ensuring the positive (+) and negative (-) ends align with the markings inside the flashlight.
3. Screw the tail cap back on clockwise until it is securely tightened.

Important: Always use the correct size and type of battery specified by the manufacturer. Do not mix old and new

batteries, or different types of batteries.

OPERATING INSTRUCTIONS

Turning On/Off

Press the button located on the tail cap of the flashlight to turn the light on. Press the button again to turn the light off.

Adjusting Focus

The Energizer X-Focus LED Flashlight features an adjustable focus beam. To adjust the beam from a wide floodlight to a narrow spotlight, gently slide the head of the flashlight forward or backward.

- Slide forward for a more focused, narrow beam (spotlight).
- Slide backward for a wider, diffused beam (floodlight).

MAINTENANCE

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the light dims significantly or stops working. Always replace both batteries at the same time.
- **Storage:** If the flashlight will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	• Batteries are dead or low. • Batteries are inserted incorrectly. • Tail cap is loose.	• Replace with new batteries. • Check battery polarity and reinsert correctly. • Tighten the tail cap securely.
Light is dim.	• Batteries are low. • Lens is dirty.	• Replace with new batteries. • Clean the lens with a soft cloth.

SPECIFICATIONS

Model Number	639809
Light Source	LED
Luminous Intensity	37 Lumens
Beam Distance	38 meters
Power Source	2 x AA Alkaline Batteries (included)
Dimensions (L x W x H)	15.8 x 2.9 x 2.9 cm (6.22 x 1.14 x 1.14 inches)
Weight	90 grams (0.2 lbs)

Color	Black
Material	Plastic
Special Feature	Adjustable Focus, Non-slip Grip, Splash-resistant

Safety Information

- Do not look directly into the LED light.
- Keep out of reach of children.
- Do not dispose of batteries in fire; they may explode.
- Do not short-circuit batteries.
- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- This flashlight is splash-resistant, not waterproof. Do not submerge in water.

Warranty and Support

This product is covered by Energizer's standard warranty. For detailed warranty information, please refer to the packaging or visit the official Energizer website. For technical support or customer service inquiries, please contact Energizer customer support through their official channels.

Legal Disclaimer: The information provided in this manual is for informational purposes only and may not be exhaustive. It should not replace the information on the product packaging, which is authoritative, especially concerning any specific warnings or intolerances.

For recycling information regarding batteries and electronic products, please consult local regulations and recycling facilities.

