Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Classic Accessories 78932

Classic Accessories Veranda High Back Patio Chair Cover Instruction Manual

Model: 78932

1. Introduction

The Classic Accessories Veranda High Back Patio Chair Cover is designed to provide protection for your outdoor patio chairs against various elements. This cover features a durable Gardelle™ woven polyester fabric with a water-resistant laminated backing, ensuring your furniture remains protected.



Image 1: Classic Accessories Veranda High Back Patio Chair Cover. This image shows the cover installed on a patio chair, highlighting its design and fit.

2. Product Features

The Veranda High Back Patio Chair Cover incorporates several features for optimal performance and ease of use:

- **Material:** 100% woven Polyester with laminated Polyvinyl Chloride backing for water resistance.

- **Dimensions:** Designed to fit high back patio chairs approximately 25.5"L x 32.5"D x 34"H.
- **Gardelle Fabric System:** Features an elegant fabric top with a water-resistant laminated backing and a protective dark splash guard skirt.
- **Air Vents:** Integrated air vents help reduce inside condensation and minimize wind lofting.
- **Padded Handles:** For convenient fitting and removal of the cover.
- **Elastic Hem Cord:** Provides a tight and customizable fit around the base of the chair.
- **Adjustable Straps:** Secure the cover to the chair legs, preventing displacement in windy conditions.



Image 2: Feature Overview. This diagram illustrates key features such as air vents, padded handles, elastic hem cord, and adjustable straps for securing the cover.

3. Setup and Installation

3.1 Unpacking

Carefully remove the chair cover from its packaging. Inspect the cover for any visible damage or defects before

installation.

3.2 Placement

Position the cover over your high back patio chair. Use the padded handles located on the sides of the cover to assist with lifting and guiding it over the chair. Ensure the cover is centered and fully drapes over all sides of the chair.

3.3 Securing the Cover

- **Elastic Hem Cord:** Locate the elastic hem cord at the bottom edge of the cover. Pull the cord to tighten the cover around the base of the chair, creating a snug fit.
- **Adjustable Straps:** Secure the adjustable straps, typically located near the bottom corners, around the chair legs. Fasten the buckles and pull the straps to tighten, which helps prevent the cover from being lifted by wind.

4. Usage Guidelines

4.1 Air Circulation

The integrated air vents are designed to promote airflow, which helps reduce condensation buildup under the cover and minimizes the risk of mold or mildew. Ensure these vents are not obstructed.

4.2 Proper Fit

A proper fit is crucial for effective protection. The cover should fully enclose the chair, extending close to the ground. Adjust the elastic hem cord and straps to achieve the tightest possible fit, especially in areas prone to high winds.

5. Care and Maintenance

5.1 Cleaning

To clean your chair cover, wipe it down with a damp cloth and mild soap. Rinse thoroughly with water and allow it to air dry completely before storing or reinstalling. Do not machine wash or tumble dry, as this may damage the water-resistant coating.

5.2 Storage

When not in use, ensure the cover is clean and completely dry. Fold it neatly and store it in a cool, dry place away from direct sunlight to prolong its lifespan.

6. Troubleshooting

- **Cover blowing off in wind:** Ensure the elastic hem cord is tightened securely and all adjustable straps are fastened around the chair legs and pulled taut.
- **Water pooling on top:** While the cover is water-resistant, prolonged pooling can occur if the chair design creates flat surfaces. Ensure the cover is positioned to allow water to run off. Consider placing an object under the cover to create a peak for water drainage if necessary.
- **Condensation inside:** The cover includes air vents to minimize condensation. Ensure these vents are clear and not blocked. Proper air circulation is key to reducing moisture buildup.

7. Product Specifications

Model Number	78932
Dimensions (L x D x H)	25.5" x 32.5" x 34"
Material	100% Woven Polyester with Laminated PVC Backing
Color	Pebble/Bark/Earth
Item Weight	2.6 pounds
Closure Type	Elastic Hem Cord, Straps
Special Features	Adjustable, Durable, Water-Resistant, Waterproof

8. Warranty Information

This Classic Accessories Veranda High Back Patio Chair Cover is backed by a 3-year warranty covering parts and labor. For specific details regarding warranty claims or to register your product, please refer to the official Classic Accessories website or contact their customer service.

9. Customer Support

For further assistance, product inquiries, or support, please visit the official Classic Accessories website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000J60EV0

More documents and user manuals: **https://manuals.plus/**