

[Manuals.plus](#) /

› [Energizer](#) /

› Energizer Rechargeable AA NiMH Batteries (4-Count) Instruction Manual

Energizer 353149

Energizer Rechargeable AA NiMH Batteries (4-Count) Instruction Manual

Model: 353149



1. INTRODUCTION

Thank you for choosing Energizer Rechargeable AA NiMH Batteries. These high-capacity 2300mAh batteries are designed for repeated use, offering a reliable power source for your electronic devices. They are ideal for high-drain devices such as digital cameras, CD players, and handheld games.

This manual provides essential information on how to properly set up, operate, and maintain your batteries to ensure optimal performance and longevity.




Image 1.1: Packaging of Energizer Rechargeable AA NiMH Batteries, showing four batteries and product details.

2. SETUP

Before initial use, it is recommended to fully charge your Energizer Rechargeable AA NiMH batteries. Although they may come pre-charged, a full charge ensures maximum capacity from the start.

1. **Charging:** Insert the batteries into a compatible NiMH battery charger. Ensure correct polarity (+ and - terminals) as indicated on both the battery and the charger.
2. **First Charge:** Allow the batteries to charge completely according to your charger's instructions. This typically takes several hours depending on the charger model.

3. **Insertion into Device:** Once charged, insert the batteries into your electronic device, observing the correct polarity markings.

Note: Always use a charger specifically designed for NiMH batteries. Do not attempt to charge non-rechargeable batteries.

3. OPERATING INSTRUCTIONS

Energizer Rechargeable AA NiMH batteries are designed for consistent performance in various devices.

- **Device Compatibility:** These batteries are suitable for devices requiring AA size batteries. They are particularly effective in high-drain devices.
- **Battery Life:** The operational life of the batteries will vary depending on the device and its power consumption.
- **Recharging:** When device performance diminishes, remove the batteries and recharge them using a compatible NiMH charger.

Caution: Do not mix old and new batteries, or different types of batteries, in the same device. This can lead to leakage or damage.

4. MAINTENANCE

Proper maintenance extends the lifespan and performance of your rechargeable batteries.

- **Regular Recharging:** Recharge batteries when they are depleted. Avoid deep discharge for extended periods.
- **Storage:** For long-term storage, store batteries in a cool, dry place, ideally at room temperature. It is best to store them with a partial charge (around 50%).
- **Cleaning:** Keep battery terminals clean. Use a dry cloth to wipe away any dirt or residue.
- **Disposal:** Do not dispose of batteries in household waste. Recycle them at designated battery recycling centers.

5. TROUBLESHOOTING

If you encounter issues with your Energizer Rechargeable AA NiMH batteries, consider the following:

- **Batteries not charging:**
 - Ensure batteries are inserted correctly into the charger with proper polarity.
 - Verify the charger is plugged in and functioning.
 - Check if the batteries or charger terminals are dirty; clean if necessary.
- **Short battery life:**
 - Ensure batteries are fully charged before use.
 - The device might be a high-drain application, consuming power quickly.
 - Batteries have a limited number of charge cycles; consider replacement if they are very old.
- **Device not powering on:**
 - Check battery insertion for correct polarity.
 - Ensure batteries are fully charged.

- Test with a different set of known-good batteries to rule out device issues.

6. SPECIFICATIONS

Brand	Energizer
Model Number	353149
Battery Type	AA NiMH Rechargeable
Capacity	2300mAh
Voltage	1.2V (Nominal)
Recharge Cycles	Up to 1,000 times
Package Dimensions	4.57 x 3.15 x 0.63 inches
Item Weight	0.988 ounces (per battery, approximate)
Recommended Uses	Digital cameras, CD players, handheld games, and other high-drain devices.

7. WARRANTY INFORMATION

Energizer Rechargeable AA NiMH Batteries come with a lifetime limited warranty. For specific terms and conditions, please refer to the official Energizer warranty documentation or contact customer support.

8. SUPPORT

For further assistance, product information, or to contact customer service, please visit the official Energizer website or refer to the contact information provided on the product packaging.

You can also visit the Energizer Store online:[Energizer Official Store](#)



© 2025 Energizer. All rights reserved.

This manual is for informational purposes only. Energizer reserves the right to make changes to product specifications without prior notice.