

Cosco 11135CLGG1

Cosco 11135CLGG1 2-Step Folding Steel Step Stool Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective use of your Cosco 11135CLGG1 2-Step Folding Steel Step Stool. Please read all instructions carefully before assembly and use to ensure proper operation and to prevent injury.

SAFETY INFORMATION

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 200 pounds (90.7 kg).
- **Stable Surface:** Always place the step stool on a firm, level, and non-slip surface. Avoid uneven ground, wet floors, or loose rugs.
- **Locking Mechanism:** Ensure the top step locks securely into place before stepping onto the stool.
- **Proper Use:** Face the steps when climbing or descending. Maintain three points of contact (two feet and one hand, or one foot and two hands) at all times.
- **Reach Limits:** Do not overreach or lean too far to the side while on the stool. Keep your body centered between the side rails.
- **Children and Pets:** Keep children and pets away from the step stool during use and storage.
- **Inspection:** Before each use, inspect the step stool for any damage, loose parts, or wear. Do not use if damaged.

SETUP AND ASSEMBLY

The Cosco 2-Step Folding Steel Step Stool requires minimal assembly, primarily unfolding it for use.

1. Remove the step stool from its packaging.
2. Place the folded stool on a flat, stable surface.
3. Grasp the top handle and carefully pull the front and back sections apart until the stool is fully extended.
4. Ensure the top step's locking mechanism engages securely. You should hear or feel a click, indicating it is locked in.

the open position.

5. Verify that all four feet are firmly on the ground and the stool is stable before use.



This image displays the Cosco 2-Step Folding Steel Step Stool in its open, ready-to-use position. Key dimensions are indicated: 17.9 inches for the overall width, 17.3 inches for the depth, and 28.2 inches for the total height. The stool features two black, ribbed steps and a white steel frame.

OPERATING INSTRUCTIONS

Follow these steps for safe operation of your step stool:

1. **Unfold and Lock:** As described in the Setup section, unfold the stool completely and ensure the top step's locking mechanism is engaged.
2. **Positioning:** Place the stool directly in front of the area you need to reach. Ensure there is enough clear space around the stool for safe movement.
3. **Climbing:** Step onto the lower step first, ensuring your foot is fully on the step. Then, carefully step onto the upper

step. Always face the steps.

- 4. **Maintaining Balance:** Keep your weight centered. Avoid sudden movements or reaching too far to the sides.
- 5. **Descending:** Carefully step down from the top step to the lower step, then to the floor. Always face the steps.
- 6. **Folding for Storage:** To fold, disengage the top step lock (if applicable, refer to specific product design for release mechanism) and bring the front and back sections together until the stool is flat.

MAINTENANCE

- **Cleaning:** Wipe the step stool with a damp cloth and mild detergent. Avoid abrasive cleaners or solvents that could damage the finish or materials.
- **Inspection:** Regularly check all joints, rivets, and feet for tightness, wear, or damage. Ensure the slip-resistant feet are intact and provide good traction.
- **Storage:** Store the folded step stool in a dry place, away from extreme temperatures and direct sunlight, to prolong its lifespan.

TROUBLESHOOTING

Issue: Stool feels unstable or wobbly.

Solution: Ensure the stool is placed on a completely flat and level surface. Check that the top step's locking mechanism is fully engaged. Inspect the feet for any damage or uneven wear.

Issue: Stool is difficult to fold or unfold.

Solution: Ensure no debris is obstructing the hinges. Apply a small amount of silicone-based lubricant to the hinge points if movement is stiff. Always disengage the top step lock before attempting to fold.

SPECIFICATIONS

Model Number	11135CLGG1
Brand	Cosco
Material	Alloy Steel
Color	Cool Gray
Number of Steps	2
Maximum Weight Capacity	200 Pounds (90.7 kg)
Item Weight	7.4 Pounds (3.36 kg)
Product Dimensions (Unfolded)	17.9" W x 17.3" D x 28.2" H (45.5 cm W x 43.9 cm D x 71.6 cm H)
Maximum Height	28.13 Inches (71.45 cm)
Special Features	Lightweight, Resistant, Foldable
Specific Uses	Light cleaning and height assistance in household environments

WARRANTY AND SUPPORT

This Cosco 2-Step Folding Steel Step Stool comes with a**10-year limited parts warranty**. For warranty claims,

replacement parts, or technical support, please contact Cosco customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, visit the official Cosco website or refer to the contact information provided with your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question