

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Oster](#) /

> [Oster A5 Professional Turbo 2-Speed Pet Grooming Clippers Instruction Manual](#)

Oster 78005314003

Oster A5 Professional Turbo 2-Speed Pet Grooming Clippers

Model: 78005314003 | Brand: Oster

[Overview](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

[& Support](#)

1. OVERVIEW

The Oster Professional Turbo A5 Heavy Duty Animal Grooming Clippers are designed for efficient and precise grooming of pets and livestock. Featuring a robust 2-speed universal motor, these clippers deliver up to 4,000 strokes per minute (SPM), allowing them to manage thick, coarse, and even heavily matted hair with ease. The motor operates quietly to ensure a more comfortable grooming experience for the animal. With two versatile speed settings, users can select a low speed for detailed work in sensitive areas or a high speed for rapid trims and full body shave-downs. The clippers are compatible with all Oster A5 detachable blades and come equipped with a #10 CryogenX blade, blade oil, clipper grease, a cleaning brush, and replacement carbon brushes.



Figure 1: Oster A5 Professional Turbo 2-Speed Pet Grooming Clippers.

2. KEY FEATURES

- **Powerful 2-Speed Universal Motor:** Delivers 3,000 SPM for precision and 4,000 SPM for maximum power, suitable for various coat types and grooming tasks.
- **Detachable A5 Blade System:** Allows for quick and easy blade changes, enhancing versatility and maintenance.
- **CryogenX Blade:** Includes a detachable #10 CryogenX blade, known for durability and performance.
- **Wider Blade Sweep:** Designed for faster clipping, especially effective on thick and coarse hair.
- **Quiet Operation:** Universal motor engineered for reduced noise, contributing to a more pleasant grooming experience.
- **Comprehensive Kit:** Comes with blade oil, clipper grease, a cleaning brush, and replacement carbon brushes for immediate use and maintenance.



Figure 2: Detailed features of the Oster A5 Clippers.

3. SETUP

3.1 Attaching and Detaching Blades

1. Ensure the clipper is turned off and unplugged before handling blades.
2. To detach a blade, locate the small lever or button near the blade assembly. Press or slide it to release the blade.
3. Gently lift the blade off the clipper.
4. To attach a new blade, align the blade with the clipper's drive lever and snap it into place. Ensure it is securely seated.

3.2 Blade Selection

Choosing the correct blade size is crucial for effective grooming and desired coat length. Refer to the blade compatibility chart below to select the appropriate CryogenX blade for your animal's coat type and the specific area being groomed.

Easy-change
CryogenX blade

Detachable
A5 blade system

Powerful, universal motor

Impact-resistant construction

Ribbed body for easy handling

2 speed settings

10-foot professional
grade power cord



Figure 3: Oster Professional Products Buying Chart for Dog Blades.

4. OPERATING INSTRUCTIONS

4.1 Powering On and Speed Settings

1. Plug the clipper into a suitable power outlet.
2. Locate the power switch, typically on the side or end of the clipper.
3. Select the desired speed:
 - **Low Speed (3,000 SPM):** Ideal for precision work, sensitive areas, and animals that may be nervous about grooming.
 - **High Speed (4,000 SPM):** Provides maximum power for faster trims, full body shave-downs, and tackling thick or matted coats.

4.2 Grooming Tips

Proper preparation and technique are essential for a smooth and safe grooming experience:

- **Prepare the Coat:** Always bathe, dry, brush, and remove any mats from the animal's coat before clipping.
- **Secure the Pet:** Have the pet stand on a towel or non-slip surface to ensure stability and make cleanup easier.
- **Examine Skin:** Before clipping, check the skin for any cuts, lumps, or sores and avoid these sensitive areas.
- **Maintain Skin Tension:** Pull the skin tight to create a flat surface for smooth, even strokes. Never clip into a fold of skin.



professional
series

**For dogs, cats, horses,
and livestock**

**Powerful motor
for all kinds of grooming
tasks and varying coats**

Figure 4: Essential grooming tips for optimal results.

4.3 Grooming Demonstration

Video 1: A professional groomer demonstrates the use of Oster A5 clippers on a dog, showcasing various grooming techniques and blade applications.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Oster A5 clippers.

5.1 Blade Cleaning and Lubrication

1. **Clean Blades:** After each use, remove the blade and use the included cleaning brush to remove any trapped hair. For a deeper clean, use a blade wash solution (sold separately) by immersing the running blade in the solution for a few seconds.
2. **Lubricate Blades:** Apply a few drops of blade oil (included) to the teeth and bearing surfaces of the blade. This reduces friction, prevents overheating, and extends blade life.
3. **Grease Clipper:** Periodically apply clipper grease (included) to the internal moving parts as instructed in the detailed manual to ensure smooth operation.
4. **Check Carbon Brushes:** The clippers include replacement carbon brushes. Consult the full manual for instructions on when and how to replace them to maintain motor efficiency.

6. TROUBLESHOOTING

If you encounter issues with your Oster A5 clippers, consider the following common solutions:

- **Clipper Not Turning On:** Ensure the power cord is securely plugged into both the clipper and a functional electrical outlet. Check for any damage to the cord.
- **Blades Pulling Hair:** This often indicates dull blades or insufficient lubrication. Clean and oil the blades thoroughly. If the problem persists, replace the blade.
- **Clipper Overheating:** Excessive heat can be caused by dirty or unlubricated blades, or prolonged use. Clean and oil the blades. Allow the clipper to cool down. Consider using a blade coolant spray (sold separately) during extended grooming sessions.
- **Reduced Cutting Performance:** Ensure the blade is correctly attached and not loose. Clean out any hair buildup from the blade and motor area. Lubricate the blades.
- **Unusual Noise/Vibration:** Check that the blade is properly seated. Ensure all screws are tight. If the noise persists, it may indicate an internal issue requiring professional service.

For more detailed troubleshooting, please refer to the complete product manual or contact Oster customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Turbo A5
Item Model Number	78005314003
Brand Name	Oster
Power Source	Corded Electric
Motor Type	Heavy-Duty Universal Motor
Speed Settings	2 Speeds (3,000 SPM & 4,000 SPM)
Blade System	Detachable A5 Blade System
Included Blade	#10 CryogenX Blade
Recommended Uses	Grooming dogs, cats, horses, and livestock; managing heavy or matted coats.
Hair Type Compatibility	Thick
Blade Material	Stainless Steel

Feature	Detail
Item Dimensions (L x W x H)	10.5 x 2.87 x 5.8 inches
Item Weight	2.05 Pounds
Cord Length	12 feet
UPC	034264416918
Manufacturer	Jarden Consumer Solutions

8. WARRANTY AND SUPPORT

The Oster A5 Professional Turbo 2-Speed Pet Grooming Clippers come with a **1-year parts and labor manufacturer warranty**. For warranty claims, technical support, or additional product information, please visit the official Oster Store or contact their customer service department.

Visit the [Oster Store](#) for more products and support resources.