

Inter Link 50500450

Interlink Plato Desk Instruction Manual

Model: 50500450

1. INTRODUCTION

Thank you for choosing the Interlink Plato Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

The Interlink Plato Desk is designed for versatility and comfort, featuring a height-adjustable and tiltable writing surface. It includes practical features such as a basket tray for storage, a pencil tray, and a satchel holder.



Figure 1: The Interlink Plato Desk, showcasing its design with an accompanying chair and storage unit.

2. SAFETY INFORMATION

- Always follow the assembly instructions precisely to ensure structural integrity and safety.

- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the desk or its storage components. Refer to specifications for weight limits.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- When adjusting the height or tilt, ensure no objects or body parts are in the path of moving components to prevent pinching or injury.
- Place the desk on a level and stable surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk tabletop (Beech Veneer MDF)
- Metal frame components (legs, crossbars)
- Height adjustment mechanisms
- Tilt adjustment mechanism
- Basket tray
- Pencil tray
- Satchel holder
- Assembly hardware (screws, bolts, nuts, Allen key, flat wrench)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly typically requires two people and approximately one hour. All parts are numbered and individually packaged for ease of identification. A power drill may be helpful for attaching metal brackets to the tabletop, though a screwdriver is sufficient.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify against the package contents list.
2. **Assemble Base Frame:** Connect the metal leg components using the provided hardware. Ensure all connections are firm but do not fully tighten screws until the entire frame is assembled.
3. **Attach Tabletop:** Secure the tabletop to the assembled base frame. Pay close attention to the orientation of the tabletop to ensure proper alignment for the tilt mechanism.
4. **Install Height Adjustment Mechanism:** Integrate the height adjustment components into the leg structure as per the diagrams.
5. **Install Tilt Mechanism:** Attach the tilt mechanism to the tabletop and frame.
6. **Attach Accessories:** Secure the basket tray, pencil tray, and satchel holder to their designated positions on the desk frame.
7. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts. Do not overtighten.




Figure 2: Desk dimensions (Width: 46.46", Depth: 28.35", Height: 36.61" max).

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The Interlink Plato Desk features a height-adjustable design, allowing the tabletop to be set between 62 cm (24.4 inches) and 93 cm (36.6 inches). To adjust the height:

1. Locate the height adjustment knobs or levers on the desk legs.
2. Loosen the mechanisms on both legs simultaneously.
3. Carefully raise or lower the tabletop to the desired height. Ensure both sides are adjusted evenly.
4. Tighten the adjustment mechanisms securely on both legs to lock the desk at the new height.

5.2. Tilt Function

The desk's writing surface can be tilted to various angles for ergonomic comfort, especially useful for drawing or reading. To adjust the tilt:

1. Locate the tilt adjustment mechanism, typically at the front edge of the tabletop.
2. Lift the front edge of the tabletop to engage the tilt mechanism.
3. Select the desired tilt angle by resting the tabletop in one of the available notches or positions.

4. To return the tabletop to a flat position, lift it to its highest tilt point, which will disengage the mechanism, allowing it to lay flat.



Figure 3: The desk with its tiltable surface and integrated storage features.

5.3. Using Accessories

- **Basket Tray:** Located beneath the tabletop, this perforated metal tray provides storage for books, documents, and other items.
- **Pencil Tray:** Integrated into the front edge of the tabletop, this tray is designed to hold pens, pencils, and small stationery items.
- **Satchel Holder:** A hook-like attachment on the side of the desk frame, designed to hold a schoolbag or satchel. It can be mounted on either side of the desk.



Figure 4: The desk featuring the satchel holder, useful for keeping bags off the floor.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the beech veneer or metal finish.
- **Inspections:** Periodically check all screws, bolts, and connections to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Wood Care:** The beech veneer surface can be maintained with furniture polish suitable for wood veneers, applied sparingly.
- **Metal Care:** The silver-grey lacquered metal parts can be cleaned with a mild detergent solution if necessary, then wiped dry.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk feels unstable or wobbly.	Loose fasteners; uneven floor; incorrect assembly.	Check and tighten all screws and bolts. Ensure the desk is placed on a level surface. Use shims if necessary. Review assembly instructions to confirm correct installation.

Problem	Possible Cause	Solution
Difficulty adjusting height.	Adjustment mechanisms are too tight or stiff; uneven adjustment.	Ensure adjustment knobs/levers are fully loosened before attempting to move. Adjust both legs simultaneously and evenly. Apply a small amount of silicone-based lubricant to moving parts if stiffness persists.
Tabletop tilt mechanism not engaging/disengaging properly.	Obstruction; mechanism misalignment.	Check for any objects obstructing the mechanism. Ensure the tabletop is lifted fully to reset the mechanism when returning to flat.

8. SPECIFICATIONS

Model Number	50500450
Brand	Inter Link
Dimensions (W x D x H)	115 cm x 73 cm x 62-93 cm (46.46"D x 28.35"W x 36.61"H)
Materials	MDF, Beechwood veneer, Metal (silver-grey lacquer)
Color	Natural
Item Weight	27.7 Kilograms
Features	Height-adjustable, Tilttable writing surface, Basket tray, Pencil tray, Satchel holder
Assembly Required	Yes
Certifications	GS seal for stability and product safety

9. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or contact the retailer. For product support, missing parts, or technical assistance, please contact Inter Link customer service through their official website or the contact information provided at the point of purchase.

Manufacturer: Interlink

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question