

Altec Lansing BX1020

Altec Lansing BX1020 2-Piece Music and Gaming Speaker System

Instruction Manual

INTRODUCTION

Thank you for purchasing the Altec Lansing BX1020 2-Piece Music and Gaming Speaker System. This system is designed to provide clear and powerful audio for your CD player, MP3 player, video gaming system, or personal computer. This manual provides essential information for setting up, operating, and maintaining your new speaker system.

PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- Two (2) Altec Lansing BX1020 Satellite Speakers
- One (1) Power Adapter
- Audio Input Cable (attached to one speaker)



Image: Contents of the Altec Lansing BX1020 package, showing the two speakers, power adapter, and the product box.

SETUP INSTRUCTIONS

1. **Speaker Placement:** Position the two satellite speakers on either side of your computer monitor or audio source for optimal stereo separation. Ensure they are on a stable, flat surface.
2. **Connect Speakers:** The left speaker connects to the right speaker via an integrated cable. Ensure this connection is secure.
3. **Connect Audio Source:** Locate the audio input cable (3.5mm stereo jack) attached to one of the speakers. Plug this cable into the headphone jack or audio output port of your computer, MP3 player, CD player, or gaming console.
4. **Connect Power:** Insert the power adapter cable into the DC input jack on the back of the main speaker (the one with controls). Plug the power adapter into a standard electrical outlet.



Image: The Altec Lansing BX1020 speaker system, showing the primary speaker with its control panel and the secondary speaker.

OPERATING INSTRUCTIONS

- **Power On/Off:** The power button is located on the front panel of the main speaker. Press it to turn the speakers on or off. A blue LED indicator will illuminate when the speakers are powered on.
- **Volume Control:** Rotate the "Volume" knob clockwise to increase the audio output and counter-clockwise to decrease it.
- **Tone Control:** Adjust the "Tone" knob to modify the bass and treble response of the audio. Turning it clockwise generally increases treble, while counter-clockwise increases bass.
- **Headphone Jack:** A 3.5mm headphone jack is provided on the front panel. Plugging headphones into this jack will mute the speakers and route audio to your headphones.
- **Auxiliary Input:** An "Aux In" port (3.5mm) is available on the front panel for connecting an additional audio device without disconnecting the primary audio source.



Image: A direct front view of both Altec Lansing BX1020 speakers, highlighting the control knobs and ports on the right speaker.

MAINTENANCE

To ensure the longevity and optimal performance of your Altec Lansing BX1020 speaker system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Do not use liquid cleaners, aerosols, or abrasive chemicals, as these may damage the finish or internal components.
- **Dust Removal:** Periodically use a soft brush or compressed air to gently remove dust from the speaker grilles and control knobs.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and audio sources, and store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Keep the speakers away from water and other liquids. Do not place beverages or liquid containers on or near the speakers.

TROUBLESHOOTING

If you encounter issues with your speaker system, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speakers.	Speakers not powered on.	Ensure power button is pressed and blue LED is lit.
	Volume too low.	Increase the "Volume" knob.
	Audio cable disconnected or faulty.	Check all audio connections. Try a different audio cable if available.
	Headphones plugged in.	Unplug headphones from the front jack.
	Audio source muted or volume low.	Check volume and mute settings on your audio source (computer, MP3 player, etc.).

Problem	Possible Cause	Solution
Distorted or unclear sound.	Volume set too high. Tone control setting. Poor audio source quality.	Reduce the "Volume" knob. Adjust the "Tone" knob to find a balanced sound. Test with a different audio source or audio file.
Power indicator light is off.	Speakers not plugged in. Power outlet not working. Power adapter faulty.	Ensure power adapter is securely plugged into the speaker and the wall outlet. Test the outlet with another device. Contact Altec Lansing support if you suspect a faulty power adapter.

SPECIFICATIONS

Key technical specifications for the Altec Lansing BX1020 speaker system:







Product Type	Speaker System
Model Number	BX1020
System Components	2 Speakers (2.0 Stereo System)
Total Power Output	6 Watts
Driver Size (per Satellite)	One 2.5-inch full range driver
Connectivity	Wired (3.5mm audio input)
Color	Black/Silver
Dimensions (LxWxH)	7.6 x 12.7 x 10.2 Centimeters (approx. 3 x 5 x 4 inches)
Item Weight	885 grams (approx. 1.95 lbs)
Power Source	Corded Electric

WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service for your Altec Lansing BX1020 speaker system, please refer to the official Altec Lansing website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

Official Altec Lansing Website: www.alteclansing.com



	<p>Altec Lansing ATP3 Computer Speaker System User Guide and Setup</p> <p>Comprehensive user guide for the Altec Lansing ATP3 computer speaker system, covering specifications, setup instructions, safety precautions, and control usage.</p>
	<p>Altec Lansing AL Nanobuds 2.0 (MZ5000) Quick Start Guide</p> <p>Quick start guide for Altec Lansing AL Nanobuds 2.0 (MZ5000) wireless earbuds. Learn about Bluetooth pairing, touch controls, charging, power management, and troubleshooting.</p>
	<p>Altec Lansing ACS65i Amplified Speaker System User Guide</p> <p>User guide for the Altec Lansing ACS65i amplified speaker system. This document provides detailed instructions on setup, operation, safety precautions, specifications, and warranty information for multimedia computer audio applications.</p>
	<p>Altec Lansing IMW1020 HydraMicro Wireless Speaker Quick Start Guide</p> <p>Get started with your Altec Lansing IMW1020 HydraMicro Everythingproof Wireless Speaker. This quick start guide provides instructions on setup, Bluetooth pairing, controls, charging, and True Wireless Stereo (TWS) pairing.</p>
	<p>Altec Lansing ACS33BW Three-Piece Powered Audio System User Guide</p> <p>Comprehensive user guide for the Altec Lansing ACS33BW three-piece powered audio system, covering setup, connections, specifications, and troubleshooting. Includes safety information and warranty details.</p>
	<p>Altec Lansing Mini H2O IMW258 Rugged Bluetooth Speaker Quick Start Guide</p> <p>This quick start guide provides essential instructions for setting up, pairing, charging, and controlling the Altec Lansing Mini H2O IMW258 rugged Bluetooth speaker, including call management and music playback.</p>

