Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nissan Quest

1998 Nissan Quest Owners Manual

Your comprehensive guide to operating and maintaining your vehicle.

Introduction

This manual provides detailed information regarding the operation, maintenance, and care of your 1998 Nissan Quest. To ensure safe and trouble-free driving, please read this manual thoroughly and keep it in your vehicle for future reference. Familiarizing yourself with the contents will help you understand the features and capabilities of your vehicle, promoting a safer and more enjoyable driving experience.

Setup and Initial Familiarization

Before operating your Nissan Quest, it is important to familiarize yourself with its primary controls and features. This section covers initial adjustments and basic functions.

Dashboard Layout and Indicators

Understand the instrument panel, warning lights, and gauges. Each indicator provides crucial information about your vehicle's status. Refer to the specific section on the instrument panel for a detailed explanation of each light and gauge.

Seat and Mirror Adjustments

- **Seats:** Adjust the driver's seat for optimal comfort and control. Locate the levers for forward/backward movement, recline, and height adjustment (if equipped).
- **Mirrors:** Adjust the side mirrors and rearview mirror to provide clear visibility of the areas around your vehicle. Ensure the side mirrors are properly aligned before driving.

Steering Wheel and Pedal Positions

Ensure the steering wheel is adjusted to a comfortable height and distance, allowing full visibility of the instrument panel. Confirm that you can comfortably reach and operate the accelerator, brake, and clutch pedals (if manual transmission) without stretching.

Operating Your Vehicle

This section details the procedures for starting, driving, and utilizing the various systems of your 1998 Nissan Quest.

Starting the Engine

1. Ensure the parking brake is engaged.
2. For automatic transmission, place the shift lever in 'P' (Park) or 'N' (Neutral). For manual transmission, place the shift lever in 'N' and depress the clutch pedal.
3. Insert the key into the ignition and turn it to the 'START' position. Release the key once the engine starts.

Driving Controls

- **Lights:** Operate the headlight switch for low beams, high beams, and parking lights.
- **Wipers:** Use the wiper stalk to control windshield wipers and washers.
- **Climate Control:** Adjust temperature, fan speed, and air distribution using the climate control panel.
- **Audio System:** Refer to the dedicated section for instructions on operating the radio, CD player, and other audio features.

Maintenance and Care

Regular maintenance is crucial for the longevity and performance of your Nissan Quest. Follow the recommended service schedule.

Scheduled Maintenance

Refer to the maintenance schedule provided in this manual for recommended service intervals, including oil changes, tire rotations, and inspections. Adhering to this schedule helps prevent major issues and maintains vehicle efficiency.

Fluid Checks

- **Engine Oil:** Check oil level regularly using the dipstick. Add oil if necessary, ensuring the correct type is used.
- **Coolant:** Verify coolant level in the reservoir when the engine is cool.
- **Brake Fluid:** Ensure brake fluid is between MIN and MAX marks.
- **Power Steering Fluid:** Check the level in the reservoir.
- **Windshield Washer Fluid:** Keep the reservoir filled for clear visibility.

Tire Care

Maintain correct tire pressure as specified on the tire placard (usually located on the driver's side door jamb). Inspect tires for wear and damage regularly. Rotate tires according to the maintenance schedule.

Troubleshooting Common Issues

This section provides guidance for addressing minor operational problems you might encounter.

Engine Will Not Start

- **Battery:** Check battery terminals for corrosion and ensure connections are tight. If the battery is dead, jump-start the vehicle.
- **Fuel:** Ensure there is sufficient fuel in the tank.

- **Ignition:** Verify the key is fully inserted and turned correctly.

Warning Lights Illuminated

If a warning light illuminates on the instrument panel, consult the specific section in this manual for its meaning and recommended action. Some lights may indicate a serious issue requiring immediate attention from a qualified technician.

Brakes Squealing or Grinding

This often indicates worn brake pads. Have the brake system inspected by a professional as soon as possible to ensure safe operation.

Specifications

Key technical specifications for the 1998 Nissan Quest.

Category	Specification
Engine Type	V6 (specific displacement may vary by trim)
Fuel Type	Unleaded Gasoline
Transmission	Automatic (Manual optional on some trims)
Fuel Tank Capacity	Approximately 76 liters (20 US gallons)
Tire Size	Refer to tire placard on vehicle
Curb Weight	Approximately 1,700 kg (3,750 lbs)

Note: Specific specifications may vary based on trim level and optional equipment. Always refer to the vehicle's labels for precise information.

Warranty and Support

As this manual pertains to a 1998 model year vehicle, original manufacturer warranties may no longer be active. However, for any service or parts inquiries, it is recommended to contact an authorized Nissan dealership or a certified automotive technician.

Contacting Nissan Support

For general inquiries or to locate an authorized service center, please visit the official Nissan website for your region or consult your local Nissan dealership. They can provide information on parts availability, service procedures, and any applicable recalls for your vehicle model.
Online Resources: Nissan Canada Official Website (or your regional equivalent)

© 1998 Nissan Motor Co., Ltd. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000MG9DO6

More documents and user manuals: **https://manuals.plus/**