

[Manuals.plus](#) /

› [Microsoft](#) /

› Microsoft Reclusa Gaming Keyboard User Manual

Microsoft 9VU-00001

Microsoft Reclusa Gaming Keyboard User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Microsoft Reclusa Gaming Keyboard. Please read this manual thoroughly to ensure proper use and to maximize your gaming and computing experience.



Figure 1: Microsoft Reclusa Gaming Keyboard. This image displays the full keyboard from an elevated angle, showcasing its ergonomic design, blue ambient backlighting on the keys, and the integrated wrist rest. The Microsoft logo is visible at the top center.

SETUP

1. Connecting the Keyboard

The Microsoft Reclusa Gaming Keyboard connects to your computer via a standard USB port.

- Locate an available USB port on your computer.
- Plug the USB connector from the keyboard into the USB port.
- The operating system will automatically detect and install the necessary drivers.

The keyboard features a smart cabling system, allowing you to manage the USB cable length by stowing away excess cable when not in use or shortening it as needed.

2. Attaching the Wrist Rest

For enhanced comfort during extended use, the Reclusa keyboard includes a detachable wrist rest.

- Align the wrist rest with the bottom edge of the keyboard.
- Gently push the wrist rest until it clicks securely into place.
- To remove, apply gentle pressure and pull the wrist rest away from the keyboard.

3. Software Installation (Razer Reclusa Configurator)

To unlock the full customization capabilities of your Reclusa keyboard, install the Razer Reclusa Configurator software. This software allows for macro programming and profile management.

- Insert the provided installation CD into your computer's optical drive, or download the latest software from the official Microsoft support website.
- Follow the on-screen instructions to complete the installation.
- Once installed, launch the Razer Reclusa Configurator to begin customizing your keyboard settings.

OPERATING THE KEYBOARD

1. Key Features Overview

- **Ambient Backlighting:** The keys feature cool blue ambient backlighting, ensuring visibility in low-light conditions. This backlighting is always active when the keyboard is connected.
- **Hyperresponse Gaming Key Action:** Designed for maximum response with minimal latency, providing a tactile and efficient typing and gaming experience.
- **Integrated USB Ports:** Two gold-plated USB connector ports are built into the keyboard, maximizing connectivity and maintaining transmission integrity for peripherals.

2. Programmable Buttons and Profiles

The Reclusa keyboard features 12 custom-programmable buttons, including two 360-degree jog-dials and two bumper buttons conveniently located on each side of the keyboard. These can be configured using the Razer Reclusa Configurator software.



Figure 2: Left side programmable buttons. This close-up view highlights the programmable L1-L5 buttons and a jog-dial located on the left side of the keyboard, designed for quick access to macros and functions.

- **Customization:** Use the Razer Reclusa Configurator to assign macros, key functions, or application shortcuts to the 12 programmable buttons.
- **Profiles:** Store up to five different profiles within the software. Each profile can have a unique set of button assignments, tailored for different games or applications.
- **On-the-Fly Gaming Detection:** The software can automatically switch to the appropriate profile when a specific game or application is launched, providing seamless transitions between your customized settings.
- **Jog-Dials:** The two 360-degree jog-dials can be programmed for various functions, such as volume control, scrolling, or macro activation.



Figure 3: Right side jog-dial and numeric keypad. This image focuses on the right side of the keyboard, showing the numeric keypad and

the additional jog-dial, which can be customized for various functions.

MAINTENANCE

Proper care and maintenance will extend the life of your Microsoft Reclusa Gaming Keyboard.

- **Cleaning:**
 - Disconnect the keyboard from your computer before cleaning.
 - Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard.
 - Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.
 - Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.
- **Liquid Spills:** In case of a liquid spill, immediately disconnect the keyboard from your computer. Turn it upside down to drain any liquid and allow it to dry completely before reconnecting. Do not attempt to use the keyboard while it is wet.

TROUBLESHOOTING

If you encounter issues with your Microsoft Reclusa Gaming Keyboard, refer to the following common solutions:

Problem	Possible Solution
Keyboard is not responding.	• Ensure the USB cable is securely connected to both the keyboard and the computer. • Try plugging the keyboard into a different USB port. • Restart your computer. • Check device manager for driver issues.
Backlighting is not working.	• Verify the keyboard is properly connected and receiving power. • The Reclusa's backlighting is always on when connected; if it's off, check the connection.
Programmable buttons/macros are not working.	• Ensure the Razer Reclusa Configurator software is installed and running. • Verify that the correct profile is active for the application or game you are using. • Re-program the buttons within the software to ensure settings are saved correctly.
Keys are sticky or unresponsive.	• Clean the keyboard as described in the Maintenance section, paying attention to individual keys. • Avoid eating or drinking near the keyboard to prevent spills.

If these solutions do not resolve your issue, please contact Microsoft Support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	9VU-00001
Brand	Microsoft
Connectivity Technology	USB
Keyboard Description	QWERTY
Special Features	Lighting, Programmable Keys, Detachable Wrist Rest
Color	Black
Material	Plastic
Product Dimensions	21.69"L x 9.29"W x 2.4"H (approx. 55.1 x 23.6 x 6.1 cm)
Item Weight	4.28 pounds (approx. 1.94 kg)
Included Components	Reclusa Gaming Keyboard, Detachable Wrist Rest

WARRANTY AND SUPPORT

Microsoft products are designed with quality and reliability in mind. For information regarding the warranty coverage for your Microsoft Reclusa Gaming Keyboard, please refer to the warranty card included with your product or visit the official Microsoft support website.

For technical assistance, driver downloads, or further inquiries, please visit the official Microsoft Support website or contact their customer service department. Keep your product model number (9VU-00001) handy when seeking support.

Microsoft Support Website: support.microsoft.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question