

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Stagg](#) /

› [Stagg CPK01 Children's Percussion Kit User Manual](#)

Stagg CPK01

Stagg CPK01 Children's Percussion Kit User Manual

Comprehensive instructions for the safe and proper use of your Stagg CPK01 Children's Percussion Kit.

1. PRODUCT OVERVIEW

The Stagg CPK01 Children's Percussion Kit is designed to introduce young musicians to a variety of percussive sounds. This kit includes a selection of instruments crafted from wood, plastic, and metal, suitable for beginner proficiency levels.

Kit Components:

- One chromed triangle (4 x 0.8 inches) with beater
- One pair of 4-inch wood claves
- One 6-inch pretuned wood tambourine with 4 jingles
- One pair of wooden maracas
- One wooden tube shaker
- One plastic egg shaker
- One wooden 4-pair jingles stick
- One pair of chromed finger cymbals
- One set of wrist bells



Image 1.1: All components of the Stagg CPK01 Children's Percussion Kit displayed individually.



Image 1.2: The Stagg CPK01 Children's Percussion Kit with instruments grouped.

2. SETUP

The Stagg CPK01 Children's Percussion Kit requires minimal setup. Follow these steps to prepare the instruments for use:

- 1. Unpack:** Carefully remove all instruments from their packaging.
- 2. Inspect:** Examine each instrument for any signs of damage or loose parts. If any instrument appears damaged, discontinue use and contact customer support.
- 3. Verify Components:** Ensure all listed components from the 'Product Overview' section are present.
- 4. Clean (Optional):** Before first use, you may gently wipe down wooden and plastic parts with a dry, soft cloth.

No assembly is required for any of the instruments in this kit.

3. OPERATING INSTRUCTIONS

Each instrument in the Stagg CPK01 kit offers a unique sound and playing method. Adult supervision is

recommended during use, especially for younger children.

Individual Instrument Use:

- **Chromed Triangle:** Hold the triangle by the string loop. Use the metal beater to strike the side of the triangle to produce a clear, ringing sound. Experiment with striking different parts for varied tones.
- **Wood Claves:** Hold one clave loosely in the palm of one hand, allowing it to resonate. Use the other clave to strike the first one firmly to create a sharp, clicking sound.
- **Wood Tambourine:** Hold the tambourine by its frame. Shake it to make the jingles rattle, or strike the head with your hand or fingers for a drum-like sound combined with jingle effects.
- **Wooden Maracas:** Hold a maraca by its handle and shake it rhythmically to produce a soft, rustling sound.
- **Wooden Tube Shaker:** Hold the wooden tube and shake it to create a gentle, percussive rattling sound.
- **Plastic Egg Shaker:** Hold the egg shaker and shake it to produce a soft, consistent rattling sound.
- **Wooden Jingles Stick:** Hold the stick by its handle and shake it to activate the jingles, creating a bright, shimmering sound.
- **Chromed Finger Cymbals:** Hold one cymbal in each hand by the attached strap. Strike the edges of the cymbals together to produce a clear, sustained ringing sound.
- **Wrist Bells:** Secure the wrist bells comfortably around a child's wrist. Movement of the arm will cause the bells to jingle.

4. MAINTENANCE

Proper care and maintenance will extend the life of your percussion kit.

Cleaning:

- **Wooden and Plastic Parts:** Wipe with a dry or slightly damp, soft cloth. Do not use harsh chemicals or abrasive cleaners. Avoid immersing wooden instruments in water.
- **Metal Parts (Triangle, Finger Cymbals, Jingles):** Polish with a soft, dry cloth. If necessary, a very mild metal polish designed for musical instruments can be used sparingly, ensuring no residue is left.
- **Tambourine Head:** If the tambourine head is made of natural skin, avoid getting it wet. Wipe gently with a dry cloth.

Storage:

- Store all instruments in a dry place, away from direct sunlight and extreme temperatures (both hot and cold).
- Keep instruments in their original packaging or a dedicated storage container to prevent loss or damage.

5. TROUBLESHOOTING

This section addresses common concerns you might encounter with your percussion kit.

- **Missing Parts:** If any components are missing upon unpacking, please contact the retailer or Stagg customer support immediately.
- **Minor Damage (e.g., small crack in wood):** For minor cosmetic damage that does not affect playability or safety, the instrument may still be used. However, if an instrument is broken, has sharp edges, or poses a choking hazard, discontinue use immediately to prevent injury.

- **Dull Sound:** Ensure instruments are clean and free of debris. For wooden instruments, ensure they are not exposed to excessive moisture or dryness, which can affect resonance.

6. SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- **Adult Supervision:** This product is intended for children and should always be used under direct adult supervision.
- **Choking Hazard:** Some small parts, such as the triangle beater or individual jingles, may pose a choking hazard. Not suitable for children under 3 years of age without close supervision.
- **Not for Oral Use:** Instruments are not toys for chewing or putting in the mouth.
- **Inspect Regularly:** Periodically check all instruments for any signs of wear, breakage, or loose components that could create sharp edges or small parts. Discontinue use if damage occurs.
- **Proper Use:** Use instruments only as intended for musical play. Avoid throwing or striking instruments against hard surfaces other than for their intended musical purpose.

7. SPECIFICATIONS

Feature	Detail
Brand	Stagg
Model Number	CPK01
UPC	705235936543
Item Weight	1.98 pounds
Product Dimensions (L x W x H)	3.54 x 3.54 x 3.54 inches
Material Type	Plastic, Wood
Proficiency Level	Beginner
Manufacturer	Stagg
Date First Available	August 6, 2012

8. WARRANTY AND SUPPORT

Warranty Information:

For detailed information regarding the warranty for your Stagg CPK01 Children's Percussion Kit, please refer to the official Stagg website or the warranty documentation provided at the time of purchase. Warranty terms and conditions may vary by region and retailer.

Customer Support:

If you have any questions, require assistance, or need to report an issue with your product, please contact your retailer or visit the official Stagg website for customer support options. You can often find contact information and

FAQs on the manufacturer's website.

Stagg Official Website: Visit the Stagg Store on Amazon

© 2023 Stagg. All rights reserved. Information subject to change without notice.

Related Documents - CPK01



Fellow Stagg Pour-Over Kettle: Safety, Use, and Brewing Guide

Comprehensive safety and usage guide for the Fellow Stagg Pour-Over Kettle, including brewing instructions and compatibility information.